

# TOSHIBA


FILE NO. 810-200867GR

## SERVICE MANUAL



# Combination 15 LCD TV and DVD Video Player TELETEXT

# 15SLDT2



The above model is classified as a green product (\*1), as indicated by the underlined serial number. This Service Manual describes replacement parts for the green product. When repairing this green product, use the part(s) described in this manual and lead-free solder (\*2).

For (\*1) and (\*2), see the next page.

(\*1)

## GREEN PRODUCT PROCUREMENT

The EC is actively promoting the WEEE & RoHS Directives that define standards for recycling and reuse of Waste Electrical and Electronic Equipment and for the Restriction of the use of certain Hazardous Substances. From July 1, 2006, the RoHS Directive will prohibit any marketing of new products containing the restricted substances.

Increasing attention is given to issues related to the global environmental. Toshiba Corporation recognizes environmental protection as a key management tasks, and is doing its utmost to enhance and improve the quality and scope of its environmental activities. In line with this, Toshiba proactively promotes Green Procurement, and seeks to purchase and use products, parts and materials that have low environmental impacts.

Green procurement of parts is not only confined to manufacture. The same green parts used in manufacture must also be used as replacement parts.

(\*2)

## LEAD-FREE SOLDER

This product is manufactured using lead-free solder as a part of a movement within the consumer products industry at large to be environmentally responsible. Lead-free solder must be used in the servicing and repair of this product.

### **WARNING**

**This product is manufactured using lead free solder.**

### **DO NOT USE LEAD BASED SOLDER TO REPAIR THIS PRODUCT !**

The melting temperature of lead-free solder is higher than that of leaded solder by 86°F to 104°F (30°C to 40°C). Use of a soldering iron designed for lead-based solders to repair product made with lead-free solder may result in damage to the component and or PCB being soldered. Great care should be made to ensure high-quality soldering when servicing this product — especially when soldering large components, through-hole pins, and on PCBs — as the level of heat required to melt lead-free solder is high.

EU Conformity Statement



"This product is marked with "CE" and complies therefore with the applicable harmonized European standards listed under the Low Voltage Directive 2006/95/EC and the EMC Directive 2004/108/EC."

Responsible for CE-marking is TOSHIBA INFORMATION SYSTEMS (U.K.) LTD, Toshiba Court, Weybridge Business Park, Addlestone Road, Weybridge, Surrey, KT15 2UL, United Kingdom

# TOSHIBA

**Следующая информация только для государств - членов ЕС :**

Данный символ означает, что этот продукт не может рассматриваться в качестве бытовых отходов. Удостоверившись, что утилизация продукта произведена правильным образом, Вы тем самым поможете предотвратить потенциальные негативные последствия для окружающей среды и здоровья человека, которые в противном случае могли бы быть вызваны неправильной утилизацией. За более детальной информацией о переработке данного продукта обращайтесь в Ваш местный офис компании, в центр по утилизации бытовых отходов или в магазин, где товар был приобретен.



**Following information is only for EU-member states:**

The use of the symbol indicates that this product may not be treated as household waste. By ensuring this product is disposed of correctly, you will help prevent potential negative consequences for the environment and human health, which could otherwise be caused by inappropriate waste handling of this product. For more detailed information about recycling of this product, please contact your local city office, your household waste disposal service or the shop where you purchased the product.



J51C0121A SH


# TOSHIBA

Модель 15SLDT2  
MODEL 15SLDT2

Руководство по эксплуатации  
USER GUIDE



Только для дисков с региональными кодами /   
Region / discs only



**Совмещенный цветной ЖК телевизор с плоским 15" кинескопом DVD-проигрыватель ТЕЛЕТЕКСТ**

**Combination 15 LCD TV and DVD Video Player TELETEXT**

## ENGLISH

### IMPORTANT

Unauthorized recording of copyright television programmes, films, video tapes and other materials may infringe on the rights of copyright owners and be contrary to copyright laws.

### WARNING

To prevent fire or shock hazard, do not expose this equipment to rain or moisture.


### MAINS SUPPLY

This unit is designed to operate from AC 220V~240V 50Hz household mains supply.

### CAUTION:

THIS UNIT IS A CLASS 1 LASER PRODUCT. HOWEVER THIS UNIT USES A VISIBLE LASER BEAM WHICH COULD CAUSE HAZARDOUS RADIATION EXPOSURE IF DIRECTED. BE SURE TO OPERATE THE PLAYER CORRECTLY AS INSTRUCTED.

THE FOLLOWING CAUTION LABEL IS LOCATED ON THE REAR PANEL OF THE UNIT.



WHEN THIS UNIT IS PLUGGED INTO THE AC OUTLET, DO NOT PLACE YOUR EYES CLOSE TO THE DISC SLOT AND OTHER OPENINGS TO LOOK INTO THE INSIDE OF THIS UNIT.

USE OF CONTROLS OR ADJUSTMENTS OR PERFORMANCE OF PROCEDURES OTHER THAN THOSE SPECIFIED HEREIN MAY RESULT IN HAZARDOUS RADIATION EXPOSURE.

DO NOT OPEN COVERS AND DO NOT REPAIR YOURSELF. REFER SERVICING TO QUALIFIED PERSONNEL.

## Features

- TV
  - Auto Channel Memory
  - On-Screen Programming
  - Picture Control Adjustments
  - Auto Power Shut Off
  - On Screen 5 Language Display
- DVD Player
  - Digital Audio Jack (Coaxial)
  - Multi-Language
  - Multi-Angle
  - Repeat Playback
- Memory/Random Playback
- ZOOM
- Adjustable Aspect Ratio
- Parental Control
- Digital output for Dolby Digital (AC-3) and DTS
- Playback DVD discs (Region 5 / Region All), Video CDs and Audio CDs
- MP3/JPEG/DivX® CD Playback
- PAL & NTSC DVDs playback
- A-B Repeat playback

## Contents

<b>PREPARATION</b>	Locating desired scene.....	24
Precautions.....	Marking desired scenes.....	25
Location of controls.....	Repeat playback.....	26
Remote control.....	A-B Repeat playback.....	26
Antenna connection.....	Program playback.....	27
Connection to Satellite Receiver.....	Random playback.....	27
Connections to other equipment.....	Changing angles.....	28
	Title selection.....	28
<b>TV OPERATION</b>	DVD menu.....	28
Auto setup.....	Changing soundtrack language.....	29
Guide to using the menu system.....	Subtitles.....	29
On-screen Language Selection.....	To turn off the PBC.....	30
Auto tuning.....	Disc status.....	30
Changing the order of stored channels.....	MP3/JPEG/DivX® and Audio CD operation.....	31
Manual tuning.....	Repeat, random and program playback using file browser.....	35
Basic Operation.....		
Teletext.....	<b>FUNCTION SETUP</b>	
Stereo reception with the built-in tuner.....	Customizing the function settings.....	37
Picture format.....	Temporary cancel the rating level by DVD disc.....	40
Adjusting the AV colour setting.....		
Other convenience functions.....	<b>ADDITIONAL INFORMATION</b>	
	Language code list.....	41
<b>DISC PLAYBACK OPERATION</b>	Understanding the Power Return feature.....	42
Disc.....	Problems and troubleshooting.....	42
Playing a disc.....	Reception disturbance.....	43
Zooming.....	Specifications.....	43

\* This product incorporates copyright protection technology that is protected by method claims of certain U.S. patents and other intellectual property rights owned by Macrovision Corporation and other rights owners. Use of this copyright protection technology must be authorized by Macrovision Corporation and is intended for home and other limited viewing uses only unless otherwise authorized by Macrovision Corporation. Reverse engineering or disassembly is prohibited.

\* Manufactured under license from Dolby Laboratories. Dolby and the double-D symbol are trademarks of Dolby Laboratories.

\* Manufactured under license under U.S. Patent #: 5,451,942 & other U.S. and worldwide patents issued & pending. DTS and DTS Digital Out are registered trademarks and the DTS logos and Symbol are trademarks of DTS, Inc. © 1996-2007 DTS, Inc. All Rights Reserved.

\* Unauthorized recording of copyrighted television programs, films, video cassettes and other materials may infringe the rights of copyright owners and be contrary to copyright laws.

\* DivX, DivX Certified, and associated logos are trademarks of DivX, Inc. and are used under license.

ENGLISH

**NOTES ON MOISTURE CONDENSATION**

Moisture condensation damages the unit. Please read the following carefully.

Moisture condensation occurs, for example, when you pour a cold drink into a glass on a warm day. Drops of water form on the outside of the glass. In the same way, moisture may condense on the head drum or the optical pick-up lens inside this unit, one of the most crucial internal parts of the unit.

■ **Moisture condensation occurs during the following cases.**

- When you bring the unit directly from a cold place to a warm place.
- When you use the unit in a room where you just turned on the heater, or a place where the cold wind from the air conditioner directly hits the unit.
- In summer, when you use the unit in a hot and humid place just after you move the unit from an air conditioned room.
- When you use the unit in a humid place.

■ **Do not use the unit when moisture condensation may occur.**

If you use the unit in such a situation, it may damage discs and internal parts. Remove the disc, connect the mains lead of the unit to the mains power outlet, turn on the unit, and leave it for two or three hours. After two or three hours, the unit will have warmed up and evaporated any moisture. Keep the unit connected to the mains power outlet and moisture condensation will seldom occur.

**HEADPHONE WARNING**

Loud music can damage your hearing irreversibly, therefore do not set the volume to a high level when listening through headphones, particularly for extended listening periods.

**SOME DOS AND DON'TS ON THE SAFE USE OF EQUIPMENT**

This equipment has been designed and manufactured to meet international safety standards but, like any electrical equipment, care must be taken if you are to obtain the best results and safety is to be assured. So, please read the points below for your own safety. They are of a general nature, intended to help you with all your electronic consumer products and some points may not apply to the goods you have just purchased.

\*\*\*\*\*

- DO** read the operating instructions before you attempt to use the equipment.
- DO** ensure that all electrical connections (including the mains plug, extension leads and inter-connections between the pieces of equipment) are properly made and in accordance with the manufacturer's instructions. Switch off and withdraw the mains plug before making or changing connections.
- DO** consult your dealer if you are ever in doubt about the installation, operation or safety of your equipment.
- DO** be careful with glass panels or doors on equipment.
- DO** place the unit close to the AC outlet, and keep the mains plug within reach.

\*\*\*\*\*

- DON'T** remove any fixed cover as this may expose dangerous voltages.
- DON'T** obstruct the ventilation openings of the equipment with items such as newspapers, tablecloths, curtains, etc. Overheating will cause damage and shorten the life of the equipment.
- DON'T** allow electrical equipment to be exposed to dripping or splashing, or objects filled with liquids, such as vases, to be placed on the equipment.
- DON'T** place hot objects or naked flame sources such as lighted candles or nightlights on, or close to equipment. High temperatures can melt plastic and lead to fires.
- DON'T** use makeshift stands and NEVER fix legs with wood screws - to ensure complete safety always fit the manufacturer's approved stand or legs with the fixings provided according to the instructions.
- DON'T** use equipment such as personal stereos or radios so that you are distracted from the requirements of traffic safety. It is illegal to watch television whilst driving.
- DON'T** listen to headphones at high volume, as such use can permanently damage your hearing.
- DON'T** leave equipment switched on when it is unattended unless it is specifically stated that it is designed for unattended operation or has a stand-by mode. Switch off using the switch on the equipment and make sure that your family know how to do this. Special arrangements may need to be made for infirm or handicapped people.
- DON'T** continue to operate the equipment if you are in any doubt about it working normally, or if it is damaged in any way -switch off, withdraw the mains plug and consult your dealer.

**ABOVE ALL**

- NEVER let anyone especially children push anything into holes, slots or any other opening in the case - this could result in a fatal electrical shock;
- NEVER guess or take chances with electrical equipment of any kind
- it is better to be safe than sorry!

\*\*\*\*\*


**WHERE TO INSTALL**

Locate the television away from direct sunlight and strong lights, soft, indirect lighting is recommended for comfortable viewing. Use curtains or blinds to prevent direct sunlight falling on the screen.

Place on a sturdy platform, the mounting surface should be flat and steady. It should then be secured to the wall with a sturdy tie using the clip on the back of the stand, or secured to the platform using the fixing strap located underneath the table top stand, this will prevent it from falling over.


The LCD display panels are manufactured using an extremely high level of precision technology, however sometimes some parts of the screen may be missing picture elements or have luminous spots. This is not a sign of a malfunction.

Make sure the television is located in a position where it cannot be pushed or hit by objects, as pressure will break or damage the screen, and that small items cannot be inserted into slots or openings in the case.



**VENTILATION**

The unit emits heat when in operation. Do not place any covers or blankets on the unit, this may cause overheating. Do not block ventilation holes, or set up near radiators. Do not place in direct sunshine. When placing on a shelf leave 10 cm (4 inches) free space around the entire unit.



**PLEASE TAKE NOTE**


**EXCLUSION CLAUSE**

Toshiba shall under no circumstances be liable for loss and/or damage to the product caused by:


- i) fire;
- ii) earthquake;
- iii) accidental damage;
- iv) intentional misuse of the product;
- v) use of the product in improper conditions;
- vi) loss and/or damage caused to the product whilst in the possession of a third party;
- vii) any damage or loss caused as a result of the owner's failure and/or neglect to follow the instructions set out in the owner's manual;
- viii) any loss or damage caused directly as a result of misuse or malfunction of the product when used simultaneously with associated equipment;

Furthermore, under no circumstances shall Toshiba be liable for any consequential loss and/or damage including but not limited to the following, loss of profit, interruption of business, the loss of recorded data whether caused during normal operation or misuse of the product.


If stationary images generated by text services, channel identification logos, computer displays, video games, on screen menus, etc. are left on the television screen for any length of time they could become conspicuous, it is always advisable to reduce both the brightness and contrast settings.




**Left side**




**Rear**





		PAGE
EJECT	Eject a disc	22
TV/DVD	Select to operate TV or DVD	12, 22
SLEEP	Sleep Timer	16
⏻ (On/Standby)	Sub Power on/off	12
0-9	Direct channel selection of TV	16
	Input setting	24, 27
	Enter a security code	39
DISPLAY	Display TV or DVD operation status	16, 30
MUTE	Mute	16
SUBTITLE	Set the Subtitle of a DVD disc	29
INPUT	Select an input source	9
DVD MENU	Select menu of a DVD disc	28
	Display JPEG thumbnail list	33
TOP MENU	Select title of a DVD disc	28
	Return to JPEG file browser	33
VOL +/-	Volume Up/Down	16
AUDIO SELECT	Change sound track language of DVD/VCD	18, 29
CH RTN	Channel return	16
ZOOM	Zoom	24
⏸	Hold (Teletext)	17
⏸	Teletext on/off	17
⏸	Cursor buttons	11
P (Programme) +/-	Select channel of the TV	16
ENTER	Enter information in the menu/ Select option in the menu	12, 37
CH LIST	Display the channel list	16
MENU	Display menu of setup	12
SETUP	Display menu of setup	37
EXIT	Exit the menu screen	12
CANCEL	Cancel input data in the setting mode	24, 25, 27, 39
RETURN	Remove DVD setup menu	37, 40
PLAY	Playback	22
STOP	Stop	22
SKIP ⏮	Skip chapter/track to reverse direction	23
REV ⏮	Reverse search playback	23
⏮	Reveal (Teletext)	17
FF ⏭	Forward search playback	23
⏭	Sub page (Teletext)	17
SKIP ⏭	Skip chapter/track to forward direction	23
⏭	Select text position when viewing Teletext	17
SLOW ⏪	Slow motion playback to reverse direction	23
PAUSE	Still picture	22
PLAY MODE	Select playback mode	27
SLOW ⏩	Slow motion playback to forward direction	23
Four coloured buttons	Access the Teletext	17
MARKER	Index for DVD/VCD	25
ANGLE	Change playback angle of a DVD disc	28
	Rotate JPEG picture	33
REPEAT A-B	Repeat playback between A and B	26
JUMP	Locating desired scene	24
PIC SIZE	Select picture format	19


Battery installation



Battery cautions

- Use two "R03/AAA/UM-4" size penlight batteries for the remote control.
- If the remote control does not operate correctly, or if the operating range becomes reduced, replace batteries with new ones.
- Do not mix old and new batteries.
- Weak batteries can leak and severely damage the remote control transmitter. Always remove batteries if they become weak or if the remote control is not to be used for an extended period of time.
- Dispose of batteries in a designated disposal area. Never throw batteries into a fire.

Effective distance of the remote control transmitter




- Note:**
- When direct sunlight, an incandescent lamp, fluorescent lamp or any other strong light shines on the remote sensor, the remote operation may be unstable.
  - When there is an obstacle between the unit and the transmitter, the remote control transmitter may not operate.


Antenna connection/Connection to Satellite Receiver

**Recommended connection direction:**  
 ① Connect antenna cable first.  
 ② Connect the SCART cable afterwards.  
 If the SCART cable is connected first, the connection of antenna cable becomes difficult.

**Antenna connection**  
 Connect an indoor or outdoor antenna to the antenna jack at the rear panel as shown below. For all antenna circuit problems, please consult your local dealer.




**Connection to Satellite Receiver**  
 Connect with Satellite receiver as shown below. Select the TV-Program on the satellite receiver. To do this, use the remote control of the satellite receiver. You cannot store the station again in the unit which already stored in satellite receiver.




Connections to other equipment


**Input Selection**  
 Press **INPUT** to view a signal from another device connected to your unit, such as a VCR, camcorder or games console. You can select each input source depending on which input jacks you used to connect your devices. To select the video input source, press / . Then press **ENTER** within 6 seconds.



**1. To connect the unit to a VCR**  
 Select AV1 to use the TV as a monitor.



**2. To connect the unit to a Video camera or a Games console**



Connect the Video camera (or games console) to the TV unit using the appropriate RCA / Phono AV cables (or S-Video if applicable). Select AV2-input mode.

- Note:**
- If you have a camcorder with S-video, use an S-video cable instead of a standard video cable. Do not connect both a standard video cable and an S-video cable at the same time, or the picture performance will be unacceptable.
  - When you input the PAL-M signal to AV2 input, select AV COLOUR setting to AUTO otherwise the monochrome images will be displayed.

**3. To connect the unit to another TV set (ie. a widescreen set)**  
 Connect this unit to the other TV set using the SCART connection. You should select the external input setting on the other TV, eg. AV/EXT/etc.

**4. Setting of Scart socket**

**1** Press **TV/DVD** to select the TV mode and then press **MENU**. The menu will appear on the screen. Press or to select [SETUP] menu. Press or to select AV1 OUTPUT, then press **ENTER**.

**2** Press or to select TV or MONITOR.

**TV:** AV1 will output the channel position that the internal tuner is set to.  
**MONITOR:** AV1 will output the picture currently displayed on the TV screen.




**3** Press **EXIT** to return to the normal screen.

## Connections to other equipment

The exact arrangement you use to interconnect various video and audio components to the unit is dependent on the model and features of each component. Check the Owner's Manual provided with each component for the location of video and audio inputs and outputs.

### Using an AV Amplifier with built-in digital surround

If you are using an Amplifier with a built-in digital surround sound decoder (such as Dolby Digital / DTS / MPEG / etc.), you can connect it as shown below.




#### Note:

- When you make the connections above, make sure that the power of all units is switched off at the mains.
- Some DTS decoders which do not support DVD-DTS interface may not work properly with the unit.
- When playing DTS encoded material, the sound will only be available through the Coaxial Digital Audio Output jack.

## Auto setup

Your unit has an Automatic installation which makes installation in your unit easy. When you turn on the unit for the first time, the Automatic installation routine is activated. Using this routine, you can select the on-screen language and automatically search for and store all available channels of suitable signal strength in the correct order.

The Automatic station presetting feature is for the set's built-in tuner only. If you have a device such as a digital decoder (eg. Satellite or Digital Terrestrial) connected (see page 8), you would need to tune it separately according to its own instructions.



#### Note:

- To cancel the Auto Tuning, press **MENU** during the process.

**THE AUTOMATIC TUNING PROCESS WILL ONLY START BY ITSELF THE FIRST TIME YOU SWITCH THE UNIT ON. TO RESTART AUTO TUNING, SEE PAGE 13.**






#### Preparation:

Press **TV/DVD** (On/Standby) on the unit.

- AUTO INSTALLATION** menu will appear. Press or to select **LANGUAGE**, then press **ENTER**. Press or to select desired language. Then press **ENTER**.
- Press or to select **COUNTRY**, then press **ENTER**. Press or to select your country. Then press **ENTER**.
- Press or to select **AUTO TUNING**, then press **ENTER**.
- The confirmation message will appear. Check the your antenna connection, then press **ENTER**. Your TV will now automatically tune in all available channels.

#### Note:

- Please be patient - the Auto Tuning process can take several minutes to complete.
- When the programme on the screen stops changing and the sound is heard, the search process is complete.



## Guide to using the menu system/On-screen Language Selection

Make sure the antenna connection and mains supply are connected as per the description on page 8.

#### Preparation:


Turn on the unit with the **TV/DVD** (On/Standby) button on the unit. The **TV/DVD** (On/Standby) indicator will light up in green.

To change the unit to standby mode, press **TV/DVD** (On/Standby) on the remote control. **TV/DVD** (On/Standby) indicator will change from green to red. To turn on the unit from standby mode, press **TV/DVD** (On/Standby) on the remote control again.


In standby mode, you can also turn the unit on with **P** (Programme) / on the unit or **P +/-** on the remote control. To turn off the unit completely, press **TV/DVD** (On/Standby) button on the unit and disconnect the mains power supply.

### Guide to using the menu system

- Press **TV/DVD** to select the TV mode and then press **MENU**. The menu will appear on the screen.



- Press or to view the 3 menu options: **PICTURE**, **AUDIO** or **SETUP**.



- Press or to select whichever item you require. The function will be activated by pressing **ENTER**.

#### Note:


- Some of the menus have more than one page of items - a scroll bar indicates that you can scroll down or up to select other items.

- Press **EXIT** to return to the normal screen.


### On-screen Language Selection

This unit has 5 different languages for menu set up which can be selected through the On-Screen Display: English (ENGLISH), German (DEUTSCH), Spanish (ESPAÑOL), Italian (ITALIANO) or Russian ( ).

- Press **TV/DVD** to select the TV mode and then press **MENU**. The menu will appear on the screen. Press or to select **SETUP** menu.



- Press or to select **LANGUAGE**, then press **ENTER**. Press or to select the desired language, then press **ENTER**.



- Press **EXIT** to return to the normal screen.


#### Note:

- If no buttons are pressed for more than approx. 60 seconds, the menu screen will disappear automatically.
- If you have already successfully selected your preferred language at the Auto Installation stage, you do not need to go through the procedure above.

## Auto tuning

Perform this feature to search for and store new TV programmes after the Automatic installation (see page 11).

This unit has 18 different countries for menu set up which can be selected through the On-Screen Display: UK, Germany, France, Spain, Italy, Belgium, Netherlands, Switzerland, Austria, Portugal, Finland, Poland, Czech Republic, Hungary, Slovenia, Greece, Russia, Turkey or Other.



#### Note:

- After the automatic tuning process is finished, 48.20MHz will be set to the unused channel.



#### Preparation:

Please ensure that all the connections have been made correctly (see page 8). If you need to restart the automatic tuning process, see the following procedure below.

- Press **TV/DVD** to select the TV mode and then press **MENU**. The menu will appear on the screen. Press or to select **SETUP** menu.
- Press or to select **AUTO TUNING**, then press **ENTER**.
- Press or to select **COUNTRY**, then press **ENTER**. Press or to select your country, then press **ENTER**.
- Press or to select **START**, then press **ENTER**. The automatic tuning will search for available broadcasts and store the channels in the correct order. During the search process, the sound is muted. When the auto tuning is finished, the normal TV screen will appear.


#### Note:

- When you select "UK", the automatic tuning will search for UHF broadcasts only.
- When you select "FRANCE", COLOUR SYSTEM is set as SECAM and SOUND SYSTEM is set as L/L for all broadcasts.



## Changing the order of stored channels

The Automatic station presetting stores the stations found in a specific order. This will normally be the correct order. However, you can change the station position if you want.



**Note:**

- When allocating your channels, we recommend to start with CH 1 then continue with the other channels afterwards.

- Press TV/DVD to select the TV mode and then press MENU. The menu will appear on the screen. Press or to select (SETUP) menu.
- Press or to select CH ALLOCATION, then press ENTER.



- Press or to select desired option, then press ENTER.

### Description about each setting option:

**SORT:** Press or to select the channel that you want to move, then press ENTER. Press or to select the position that you want to move the channel to, then press ENTER.

**ERASE PROGRAM:** Press or to select the channel that you want to erase, then press ENTER.

**SKIP:** Press or to select the channel that you want to skip, then press ENTER. \* mark will appear.

**CH LABEL:** Press or to select channel that you want to rename, then press ENTER. Press or to select character, then press . The cursor will move to the next position. Press ENTER to set the channel label.

- After setting each option, press EXIT to return to the normal screen.




## Manual tuning

The Auto Tuning usually stores all available stations in the reception area. If some stations have poor reception, they may not be stored - however, you can store these stations manually if you wish.







**Example:** Preset the ZDF on program position 2.

**Preparation:** Select program position 2.



**The Fine Tuning adjustment**  
Under a normal receiving condition, the station-search will stop automatically at the best receiving position. That picture will appear without disturbance. This receiving position will be memorized automatically. The Fine Tuning cannot be memorized additionally. In rare case of bad receiving condition, the station-search might not stop at the best receiving position. That picture will appear with disturbance, e.g. waving lines. Only in this rare case, use the Fine Tuning to tune the concerned station manually. Refer to step 6 on the right.

- Press TV/DVD to select the TV mode and then press MENU. The menu will appear on the screen. Press or to select (SETUP) menu.
- Press or to select MANUAL TUNING, then press ENTER.
- Press or to select COLOUR SYSTEM, then press ENTER. Press or to select AUTO, PAL or SECAM, then press ENTER. Please note that PAL should be selected for use in UK.
- Press or to select SOUND SYSTEM, then press ENTER. Press or to select AUTO, B/G, I, D/K or L/L, then press ENTER. **Note:**
  - Select L/L when you receive a SECAM broadcast. If you select AUTO, the broadcast cannot be received.
  - Sometimes when AUTO is selected, no sound is output. If this happens, select an option other than AUTO.
- Press or to select SEARCH, then press ENTER. Press (search for lower frequency) or (search for higher frequency). The auto search begins. It will stop at each station that has a good reception. Press or again until you receive a clear ZDF picture, then press ENTER.
  - If you want to stop the search, press ENTER.
- Press or to select FINE, then press ENTER. Press or to tune until the station is adjusted to the best position. Then press ENTER.
- Repeat the steps 3 and 6 to preset other TV stations.
- Press EXIT to return to the normal screen.



ENGLISH

15

14

## Basic Operation

### Channel selection

- With the numbered buttons. Example: No. 2: Press 0 and within 2 seconds, press 2. The station, CH 2 will appear. No. 29: Press 2 and within 2 seconds, press 9. The station, CH 29 will appear.
- Press P (Programme) +/- to select a channel. This takes approx. 2 seconds. If the auto search only stored 5 stations, only these 5 channels will appear. Skipped channels will not appear (see page 14).
- Press CH LIST to display CH LIST. Press or to select the desired program, then press CH LIST to display the selected program.

### Note:

- In case that the channels exclude preset frequency in "COUNTRY" selected by "AUTO INSTALLATION" will be stored in CH LIST, those channel names are displayed as "-----".

### Channel return

CH RTN button allows you to go back to the last selected channel. Press this button again to return to the channel you were watching.

### Volume adjusting

Press VOL +/- to adjust the volume. The volume level indicator disappears after 4 seconds.

### MUTE

Press MUTE. The sound will be turned off completely. "MUTE" will appear for approx. 4 seconds. The muting can be released by pressing MUTE again or VOL +/-.

### Information display

Press DISPLAY. Channel number and picture size setting will appear for approx. 4 seconds.



### SLEEP TIMER

To set the sleep timer, press SLEEP "SLEEP" and the minutes will appear. Each time you press SLEEP, the SLEEP time shown will change in the order of 120, 110, 100, 90, 80, 70, 60, 50, 40, 30, 20, 10, 0. After the sleep time is programmed, the display will disappear after approx. 4 seconds. To confirm the sleep time setting, press SLEEP once and the remaining time will be momentarily displayed.



### To cancel the sleep timer:

Press SLEEP repeatedly until "0" appears.

**Note:**

- If the built-in tuner does not receive anything (e.g. if no antenna is connected) during TV-operation, then the unit will change to standby after approx. 15 minutes.

16

## Teletext

Teletext is sent page by page. This unit is able to automatically store up to 256 pages, but they can only be accessed once they have been stored. This can take a few moments.

### Fasttext/TOPText

The Fasttext/TOPText is teletext with a special directory. On the lower part of the screen there are four different coloured fields (red, green, yellow and blue). These fields lead directly to the pages shown within. The coloured buttons on the remote control correspond to the coloured fields. Press the appropriate coloured button in order to activate the desired colour field.

### Switch on / off Teletext

Teletext is not transmitted by all channels. Select a channel that shows teletext. Press . You will now see a teletext page. (If "100" is shown without any text information, it may mean that the channel you have selected does not support teletext.) Press again in order to switch off teletext.



### Note:

- You cannot select any other channels as long as teletext is switched on. Switch teletext off when you want to switch over to another channel.

### Select Page

Press P + or - until the page you desire appears. Or ... enter the requested page number by using the 10 Number Buttons. And if you mistype something, just enter the complete 3-digit wrong page number then enter the desired number again. Or ... press one of the coloured teletext buttons so that a page from Fasttext/TOPText is shown.

### Hold Pages


Some pages are divided up into subpages by the channel. Subpages are automatically shown in turn, as they are transmitted. In order to hold the page, press . Press again in order to display the next subpage.

### Directly Select Subpages

You can directly select the subpages if required.

### Example:

Page 128 from Teletext comprises of 2 subpages. In the right upper corner you will, for example, see 1/2. That means that page one of 2 subpages is being shown at the moment.



Press in order to select subpage 2. 4 dashes (---) are shown. Enter 0 0 2. It can take a minute before subpage 0002 appears. Press again in order to switch off the subpage feature. You can only select other teletext pages when the subpage feature is switched off.

### Enlargement

In order to enlarge the display, press . Either the upper or lower half of the screen is enlarged. Each time you press you switch between the display of the upper or lower half of the screen or the full picture.

### Answering Quiz Questions

Some pages contain quiz questions with concealed answers. Press in order to show the answers.

### Page 100


Press ENTER in order to show page 100.

ENGLISH

17


## Stereo reception with the built-in tuner

The built-in Tuner can detect and receive NICAM stereo broadcasts automatically.



### NICAM stereo sound reception:

- Press **TV/DVD** to select the TV mode and then press **MENU**. The menu will appear on the screen. Press **4** or **5** to select **[NICAM]** (AUDIO) menu.
- Press **4** or **5** to select **NICAM**, then press **ENTER**. Press **4** or **5** to select **AUTO** or **OFF**. Select **OFF** if you want to revert to standard mono FM audio reception.
- Press **EXIT** to return to the normal screen.



### The following types of broadcast are possible with NICAM transmissions

"NICAM ST" illuminates for approx. 4 seconds when a NICAM STEREO broadcast signal is received.

"NICAM M1" illuminates for approx. 4 seconds when a NICAM MONO A broadcast signal is received.

"NICAM M1/M2" illuminates for approx. 4 seconds when a NICAM MONO A and MONO B broadcast signal is received.

This will be displayed for approx. 4 seconds if a NICAM signal is received when the "NICAM OFF" option is selected.

### Stereo reception in Germany

"STEREO" illuminates for approx. 4 seconds when a STEREO broadcast signal is received.

When 2-channel sound reception is available, you can select your preferred audio with the **AUDIO SELECT** button.

Each time you press **AUDIO SELECT**, the sound channel will switch to the alternative channel available.

### NICAM 2-channel sound reception (not available in Germany)



### 2-channel sound reception in Germany




- Note:**
- In case of bad reception, the stereo sound also can be disturbed.
  - Sometimes if reception is poor, the NICAM stereo sound may not be received correctly. In case of 2 channel sound reception, you can select the desired sound with **AUDIO SELECT**.

## Picture format/Adjusting the AV colour setting

The broadcaster may transmit a **Wide Screen Signalling (WSS)** signal which can determine the correct picture width and set it automatically when the **AUTO** setting is used. If you want to change this setting, you can select from the formats listed below.

The **AV colour setting** affects the **AV inputs only** - the TV's tuner is not affected. Please refer to page 9 for more information about connecting other equipment.



- Note:**
- Using the Picture format function to change the size of the displayed image (i.e. changing the height/width ratio) for the purposes of public display or commercial gain may infringe on copyright laws.

### Picture format


**AUTO**  
Press **PIC SIZE** repeatedly until **AUTO** appears.

- Note:**
- When the **PICTURE SIZE** is set to **AUTO**, the aspect ratio will automatically change according to the **Wide Screen Signalling (WSS)** signal, if it is available. This may be either transmitted by the broadcasting TV channel, or via a recording from a VCR etc. Any WSS signal received will only be effective in the **AUTO** mode - however, some DVD players / Digital Decoders etc. will automatically switch the aspect ratio via the **SCART** input (Pin 8 switching), even if **AUTO** is not selected. In any case if you want to change to a different aspect ratio to the one selected automatically, you can change it by pressing **PIC SIZE**.

### Manual format setting

Press **PIC SIZE** repeatedly to scroll through the following options.

- 4:3**  
This mode shows a 4:3 picture in its original size.
- 16:9**  
This mode is used with 16:9 signals from a Digital decoder, DVD player or other external source.



### Adjusting the AV colour setting

- Press **TV/DVD** to select the TV mode and then press **MENU**. The menu will appear on the screen. Press **4** or **5** to select **[SETUP]** menu.
- Press **4** or **5** to select **AV COLOUR**, then press **ENTER**. Press **4** or **5** to select **AUTO**.
- If **AUTO** option does not work, press **4** or **5** to select your desired colour system setting (e.g. NTSC-3.58).
- Press **EXIT** to return to the normal screen.



- Note:**
- PAL** is the colour system used in Germany. NTSC 3.58 is used in the USA. PAL 60 used in Germany handled video recorders, which play NTSC video tape recording.
  - DVD players that play NTSC DVDs (i.e. multi-region/region code-free), can produce different signals according to each particular model - the following signals may be output from the player: PAL, SECAM, NTSC 3.58, NTSC4.43 and PAL60. If possible, select RGB on the DVD player as the output signal instead of any of these types, and connect the DVD player to TV with a **SCART** cable.

## Other convenience functions

You can change the default settings to convenience use.

Icon	Selected Items	Setup hint
	PICTURE PREFERENCE	SPORTS Bright and dynamic picture (factory-set) STANDARD Standard picture quality (factory-set) MOVIE Movie-like picture setting (factory-set) MEMORY Your personal preferences
	BRIGHTNESS / CONTRAST / COLOUR / TINT(NTSC) / SHARPNESS	You can adjust the picture to your preference. The "TINT(NTSC)" option can be selected if one of the AV sockets, and NTSC or AUTO has been selected for the AV COLOUR option.
	COLOUR TEMPERATURE	Bluish (COOL) / Neutral (MEDIUM) / Reddish (WARM)
	BLUE BACK	ON / OFF You can set the TV to automatically change to a blue screen and mute the sound if the signal is weak or absent.
	BACKLIGHT	You can use the Back light feature to adjust the screen brightness for improved picture clarity.
	RESET	Select "RESET" to reset PICTURE PREFERENCE, BRIGHTNESS, CONTRAST, COLOUR, TINT(NTSC), SHARPNESS, COLOUR TEMPERATURE and BACKLIGHT to the factory preset values.
	NICAM	See page 18.
	BASS / TREBLE / BALANCE	You can adjust the sound quality to your preference.
	RESET	Select "RESET" to reset BASS, TREBLE and BALANCE to the factory preset values.
	AUTO TUNING	See page 13.
	MANUAL TUNING	See page 15.
	CH ALLOCATION	See page 14.
	LANGUAGE	See page 12.
	AV1 OUTPUT	See page 9.
	AV COLOUR	See page 19.
	RESET TV SETTING	Press <b>ENTER</b> to enter the RESET TV SETTING screen. Press <b>4</b> or <b>5</b> to select "YES", then press <b>ENTER</b> . Reset the TV function will now begin, and this unit will automatically turn off.

## Disc


The region number of this unit is 5. If region numbers, which stand for their playable area, are printed on your DVD video disc and you do not find **[5]** or **[ALL]**, disc playback will not be allowed by the player. (In this case, the unit will display an error message on-screen.)

### Playable Discs

- The loaded Disc (DVD-Video, Video-CD, Audio-CD and MP3/JPEG/DivX®-CD) will be recognized automatically.
- The suitable Disc-formats are: DVD, DVD-R/RW (Video format only), CD, and CD-R/RW.
- Some DVD-R/RW and CD-R/RW discs may be incompatible.
- Do not play DVD-ROM, DVD-Audio, CDV, CD-G or Photo CD to prevent accidental erasure of pre-recorded material.
- This unit can play an 8cm disc. Please do not use a disc adapter. It may cause trouble.
- Please do not insert any disc of an irregular shape into the unit, as it may interfere with the function of the unit. You may not be able to remove it.
- Please do not use after market accessories, such as a ring protector, as this may cause trouble with the operation of the unit.
- Some DVDs are copy protected and forbid dubbing onto video tape. Picture distortion will occur. This is not a defect of this unit.

### Title

When two or more movies are recorded on a disc, the disc is divided into two or more sections. Each section is called a "TITLE".



### Chapter

The titles can be subdivided into many sections. Each section is called a "CHAPTER".



### Track


Video CD/audio CD can contain several items. These are assigned to tracks.

### On handling Discs

- Do not touch the playback side of the disc.
- Do not attach paper or tape on the discs.

### Removing Disc from Case

Be sure to hold the edge of disc. Do not touch the surface of the disc. Pick up the disc gently from the case.




- Do not scratch the disc.
- Do not get dirt on the surface of the disc.
- Do not stick a label or adhesive tape on the disc.
- Do not drop or bend the disc.

### On Storing Discs

- Store the disc in the case to avoid risk of scratches, dirt or damage.
- Do not leave disc exposed to direct sunlight or in hot or humid places.

### On Cleaning Discs

- Fingerprints and dust on the disc may cause picture and sound deterioration. Wipe the disc from the centre outwards with a soft cloth. Always keep the disc clean.
- If you cannot wipe off the dust with a soft cloth, wipe the disc lightly with a slightly moistened soft cloth and finish with a dry cloth.
- Do not use any type of solvent such as thinner, benzene, commercially available cleaners or antistatic spray for vinyl LPs. It may damage the disc.





**Basic playback (DVD/VCD/Audio CD)**

**Preparation:**  
When you want to enjoy the sound of discs from the audio system, turn on the audio system and select the input connected to the unit.

**1 Press (On/Standby) to turn on the unit.**  
The STANDBY indicator on the front of the unit will light up in green.

**2 Press TV/DVD on the remote control to select the DVD mode.**  
The DVD startup screen will appear on the screen.



**3 Load a disc in the disc slot.**

- Load the disc in the disc slot with the label side facing forward. (If the disc has a label.) Hold the disc without touching either of its surfaces, align it with the guides, and place it in position.
- If a disc is inserted during some modes other than DVD mode, it may switch to DVD mode and then playback may be begun automatically.
- Do not load a disc which is unplayable in this unit.

**4 On the TV-screen, "" changes to "Reading" and then playback commences.**



- A menu screen will appear on the TV screen if the disc has a menu feature.
- Press / to select title, then press ENTER. Title is selected and play commences.

**CAUTION**  
Keep your fingers well clear of the disc slot when disc is loading or unloading. Neglecting to do so may cause serious personal injury.

**5 Press STOP to end playback.**

- The unit records the stopped point, depending on the disc. "" appears on the screen. Press **PLAY** to resume playback (from the scene point).
- If you press **STOP** again ("" appears on the screen.), the unit will clear the stopped point.

**To start playback in the stop mode**  
Press **PLAY**.

**To pause playback (still mode)**  
Press **PAUSE** during playback.

To resume normal playback, press **PLAY**.

- The sound is muted during still mode.

**To stop playback**  
Press **STOP**.

**To remove the disc**  
Press **EJECT**.

Remove the disc after the disc comes out.

**Note:**  
• If the unit does not operate properly: Static electricity, etc., may affect the player's operation. Disconnect the mains lead once, then connect it again.

You can play discs at various speeds.

**Playing in fast reverse or fast forward directions (DVD/VCD/Audio CD)**

Press **REV** or **FF** during playback.

**REV:** Fast reverse playback  
**FF:** Fast forward playback

- Each time you press **REV** or **FF**, the playback speed changes.
- To resume normal playback Press **PLAY**.
- Note:**
  - The unit mutes sound during reverse and forward scan of DVD/VCD/Audio CD discs.
  - The playback speed may differ depending on the disc.
  - You can use fast reverse/fast forward playback for DivX® CD.

Press **SLOW** (Reverse) or (Forward) during playback.

- Each time you press the button, the slow-motion speed changes.
- To resume normal playback Press **PLAY**.
- Note:**
  - The sound is muted during slow-motion playback.
  - You can use slow motion playback for DivX® CD.
  - Reverse slow does not work on VCD.

**Playing frame by frame (DVD/VCD)**

Press **PAUSE** during still playback.

- Each time you press **PAUSE**, the picture advances one frame.
- To resume normal playback Press **PLAY**.
- Note:**
  - The sound is muted during frame by frame playback.
  - You can use frame by frame playback for DivX® CD.

**Locating a chapter or track (DVD/VCD/Audio CD)**

Press **SKIP** or repeatedly to display the chapter or track number you want.

- To locate succeeding chapters or tracks.
- Playback starts from the beginning of the current chapter or track.
- When you press twice in quick succession, playback starts from the beginning of the preceding chapter or track.

- Note:**
- If a non-compatible disc is loaded, "Incorrect Disc", "Region Code Error" or "Parental Error" will appear on the TV screen according to the type of loaded disc. In this case, check your disc again (see pages 21 and 39).
  - Some discs may take a minute or so to start playback.
  - When you set a single-faced disc label downwards (i.e. the wrong way up), "Reading" will appear on the display for a few minutes and then "Incorrect Disc" will continue to be displayed.
  - Some discs may not work the resuming facility.
  - Resuming cannot function when you play a PBC-featured Video CD while the PBC is on. To turn off the PBC, see page 30.
  - Some playback operations of DVDs may be intentionally fixed by software producers. Since this unit plays DVDs according to the disc contents the software producers designed, some playback features may not be available. Also refer to the instructions supplied with the DVDs.
  - Do not move the unit during playback. Doing so may damage the disc.
  - Use the **EJECT** button to unload and eject the disc.
  - Do not put any objects other than discs on the disc slot. Doing so may cause the unit to malfunction.
  - In many instances, a menu screen will appear after playback of a movie is completed. Prolonged display of an on-screen menu may damage your television set, permanently etching that image onto its screen. To avoid this, be sure to press (On/Standby) on the remote control once the movie is completed.
  - There may be a slight delay between the button is pressed and the function activates.
  - A prohibition symbol "X" may appear at the upper right of the screen. This symbol means either the feature you tried is not available on the disc, or the unit cannot access the feature at this time. This does not indicate a problem with the unit.

- To obtain a higher quality picture  
Occasionally, some picture noise not usually visible on the TV screen during a normal broadcast may appear while playing a DVD video disc. It is due to high resolution pictures on these discs which include a lot of information. The amount of noise depends on the TV you use with this unit. You should generally reduce the sharpness adjustment on your TV when viewing DVD video discs.

**Zooming/Locating desired scene**

**Zooming (DVD/VCD)**

This unit will allow you to zoom in on the frame image. You can then make selections by switching the position of the frame.

**1 Press ZOOM during playback.**

The centre part of the image will be zoomed in. Each press of **ZOOM** will change the ZOOM Q1 (x 1.3), Q2 (x 1.5) and Q3 (x 2.0).

**2 Press /// to view a different part of the frame.**

You may move the frame from the centre position to UP, DOWN, LEFT or RIGHT direction.

**3 In the zoom mode, press ZOOM repeatedly to return to a 1:1 view (Q Off).**

- Note:**
- You can select the Pause or Slow in the zoom mode.
  - Some discs may not respond to zoom feature.
  - Zoom function can be used for DivX® CD.

**Locating desired scene (DVD/VCD/Audio CD)**

Use the title, chapter and time recorded on the DVD disc to locate the desired point to playback. In the case of VCD/CD discs, time and track are used to locate the desired point to playback. To check the title/track, chapter and time, press **DISPLAY**.

**1 Press JUMP during playback or resume stop mode.**

**2 Press or to select the "Title/Track", "Chapter" or "Time".**

**3 Press Number buttons (0-9) to input the number.**

**4 Press ENTER. Playback starts.**

- If you input a wrong number, press **CANCEL**.
- Refer to the package supplied with the disc to check the numbers.

**Note:**

- When you change the title, playback starts from Chapter 1 of the selected title.
- Some discs may not work in the above operation.

**Note:**

- In case of the Audio CD and Video-CD, only Track and Time can be selected.
- In case of the Video-CD playback with PBC, the JUMP does not work. Turn off the PBC (see page 30).
- Only Time search function can be used for DivX® CD.

**Marking desired scenes**

The unit stores the points that you want to watch again up to 3 points. You can resume playback from each scene.

**Marking the scenes (DVD/VCD/Audio CD)**

**1 Press MARKER during playback.**

**2 Select the blank Marker using or . Then press ENTER at the desired scene.**

- Repeat this procedure to set the other 2 scenes.

**3 Press MARKER to clear this display.**

**Note:**

- Some discs may not work with the marking operation.
- The marking is cancelled when you eject the disc or turn the power off.
- Some subtitles recorded around the marker may fail to appear.
- In case of Video CD with PBC, Marker function is prohibited.
- Marker function does not work with MP3/JPEG/DivX® CD.

**Returning to the scenes (DVD/VCD/Audio CD)**

**1 Press MARKER during playback or stop mode.**

**2 Press or to select the Marker 1-3.**

**3 Press ENTER.**

Playback starts from the marked scene.

**To cancel the Marker**  
Follow the above steps 1-2, then press **CANCEL**.

**Note:**

- In case of the Audio CD and Video-CD, only Track and Time can be selected.
- In case of the Video-CD playback with PBC, the JUMP does not work. Turn off the PBC (see page 30).
- Only Time search function can be used for DivX® CD.

## Repeat playback/A-B Repeat playback

### Repeat playback (DVD/VCD)

**1** Press **PLAY MODE** during playback or stop mode.




**2** [DVD] Press **ENTER** repeatedly to select "Chapter" or "Title".



The unit automatically starts repeat playback after finishing the current title or chapter.

[Video CD]

Press **▼** to select "Repeat". Press **ENTER** repeatedly to select "Track" or "All".



The unit automatically starts repeat playback after finishing the current track.

• If you set the repeat mode during stop mode, press **PLAY** to start Repeat playback.

**3** Press **PLAY MODE** again to clear the screen.

#### ■ To resume normal playback

Select Repeat: "Off" in step 2.

#### Note:

- Some discs may not work with the repeat operation.
- In case of Video CD with PBC, Repeat function is prohibited during playback.
- Chapter/Track repeat function is cancelled whenever **SKIP** **◀** or **▶** is pressed.

### A-B Repeat playback (DVD/VCD/ Audio CD)

A-B repeat playback allows you to repeat selection between two selected points.

**1** Press **REPEAT A-B** during playback.



The start point is selected.



**2** Press **REPEAT A-B** again.



The end point is selected. Playback starts at the point that you selected. Playback stops at the end point and returns to Point A automatically, then starts again.



#### ■ To resume normal playback

Press **REPEAT A-B** again.



"Off" appears on the screen.

#### Note:

- In A-B Repeat mode, subtitles near the A or B locations may not be displayed.
- You may not be able to set A-B Repeat for the scenes that include multiple angles.
- A-B Repeat playback does not work when Repeat playback is activated.
- You may not be able to set A-B Repeat during certain scenes of the DVD.
- A-B Repeat does not work with an interactive DVD and MP3/JPEG CDs.
- In case of Video CD with PBC, A-B Repeat is prohibited.

## Program playback/Random playback

You can arrange the playback order of tracks on the disc and the unit can also select tracks at random and play them back. These features work for Video CD.

For Audio CD and MP3/JPEG/DivX® CD, please see "Random playback (Audio CD/MP3/JPEG/DivX®)" on page 35 and "Program playback (Audio CD/MP3/JPEG/DivX®)" on page 36.

### Program playback (VCD)

**1** Press **PLAY MODE** during stop mode.



**2** Press **▲/▼** to select "Mode", then press **ENTER** repeatedly to select "Program".



**3** Press **▲/▼/◀/▶** to select the programming position. Use **Number buttons (0-9)** to input the track numbers.



• If you input a wrong number, press **CANCEL**.



**4** Press **◀/▶** to return to the left column, then press **▲/▼** to select the "Program Playback" and press **ENTER**.

The programs you selected will start to playback in order.

- To resume normal playback, select Mode: "Off" in step 2.



#### To change the program

1. Select Mode to "Program" (as step 2), press **◀/▶/▲/▼** to select the track number you want to change, then press **CANCEL**.

2. Press **Number buttons (0-9)** to input the new track number.

#### To clear the program one by one

Select Mode to "Program", press **◀/▶/▲/▼** to select the track number. Then press **CANCEL**.

#### To clear all the programs

At the left column, press **▲/▼** to select "Clear Program". Then press **ENTER**.

#### Note:

- In case of Video CD with PBC, you cannot set Program playback.
- The program is cancelled when you eject the disc or turn the power off.

### Random playback (VCD)

**1** Press **PLAY MODE** during playback or stop mode.



**2** Press **▲/▼** to select "Mode", then press **ENTER** repeatedly to select "Random".



**3** Press **PLAY**.



The Random Playback will start.

- If you set "Random" during playback mode, Random playback will begin after the track that is currently being played has ended.
- To resume normal playback, select Mode: "Off" in step 2.

#### Note:

- In case of Video CD with PBC, you cannot set Random function during playback.

## Changing angles/Title selection/DVD menu

### Changing angles (DVD)

When playing back a disc recorded with multi-angle facility, you can change the angle that you are viewing the scene from.

**1** Press **ANGLE** during playback.



The current angle will appear.



**2** Press **ANGLE** repeatedly until the desired angle is selected.



#### Note:

- Depending on the DVD, you may not be able to change the angle even if multi-angles are recorded on the DVD.

### Title selection (DVD)

Two or more titles are recorded on some discs. If the title menu is recorded on the disc, you can select the desired title.

**1** Press **TOP MENU** during playback.



Title menu appears on the screen.

**2** Press **▲/▼/◀/▶** to select the desired title.



**3** Press **ENTER** or **PLAY**.



The playback of the selected title will start.

#### Note:

- Depending on the DVD, you may not be able to select the title. Depending on the DVD, a "title menu" may simply be called a "menu" or "title" in the instructions supplied with the disc.

### DVD menu (DVD)

Some DVDs allow you to select the disc contents using the menu.

When you playback these DVDs, you can select the subtitle language, soundtrack language, etc. using the menu.

**1** Press **DVD MENU** during playback.



The DVD menu appears on the screen.

- Press **DVD MENU** again to resume playback at the scene when you pressed **DVD MENU**.

**2** Press **▲/▼/◀/▶** to select the desired item.



**3** Press **ENTER**.



The menu continues to another screen. Repeat steps 2 and 3 to set the item completely.

#### Note:

- Depending on the DVD, you may not be able to resume playback from the scene point when you press **DVD MENU**.

## Changing soundtrack language/Subtitles


### Changing soundtrack language (DVD/VCD)

You can select the language when you play a multilingual disc.


**1** Press **AUDIO SELECT** during playback.



The current soundtrack language will appear.



**2** Press **AUDIO SELECT** repeatedly until the desired language is selected.



- The on screen display will disappear after a few seconds.

#### ■ In case of Video CD playback

Audio type changes as follows each time you press **AUDIO SELECT**.




#### Note:

- If the desired language is not heard after pressing the button several times, the language is not recorded on the disc.
- The selected soundtrack language is cancelled when you eject the disc. The initial default language or available language will be heard if the disc is played back again.
- If you select DTS in playing DTS-encoded disc, no sound will be heard.

### Subtitles (DVD)

When playing back a disc recorded with subtitles, you can select the subtitle language or turn the subtitle off.

**1** Press **SUBTITLE** repeatedly during playback until the desired language is selected.



**2** To turn off the subtitle, press **SUBTITLE** until "Off" appears.





- The on screen display will disappear after a few seconds.

#### Note:

- Depending on the DVD, you may not be able to change subtitles, or to turn subtitles on or off.
- While playing a DVD, the subtitle may change when you loaded or eject the disc.
- In some cases, a selected subtitle language may not be changed immediately.

## To turn off the PBC/Disc status

### To turn off the PBC (VCD)


- Press **PLAY MODE** in the stop mode.  

- Press **▲/▼** to select "Mode", then press **ENTER** repeatedly until "Off" appears.  

- Press **PLAY MODE** again to clear the screen.

#### To turn on the PBC

Follow the above steps 1-2, then press **ENTER** repeatedly until "PBC" appear.

### Disc status (DVD/VCD)

With press of **DISPLAY**, the status of the disc will appear on the screen.  
To cancel the display, press **DISPLAY** again.



## MP3/JPEG/DivX® and Audio CD operation

This unit can play back the MP3/JPEG/DivX®-data which has been recorded on CD-R or CD-RW. Audio CD also can be played back. To produce the MP3/JPEG/DivX®-data, you need a Windows-PC with CD-RW drive and a MP3/JPEG/DivX®-encoding Software (not supplied). The Apple-HFS-System cannot be played.

#### Note:

- This unit requires discs/recordings to meet certain technical standards in order to achieve optimal playback quality. Pre-recorded DVDs are automatically set to these standards. There are many different types of recordable disc formats (including CD-R containing MP3 files). Given the fact that technology in this area is still maturing, Toshiba cannot guarantee that all genre of recordable discs will produce optimal playback quality. The technical criteria set out in this owner's manual are meant as a guide only. Please be advised that you must obtain permission from the applicable copyright owners to download copyrighted content, including music files, in any format, including the MP3 format, prior to the downloading thereof. Toshiba has no right to grant and does not grant permission to download any copyrighted content.

### MP3/JPEG/DivX® CD data information

#### Limitations on MP3/JPEG/DivX® CD playback

- MP3/JPEG/DivX® CD is the disc that is standardized by ISO9660, its file name must include 3-digits extension letters, ".mp3", ".jpg", ".div", ".divx", ".avi".
- MP3/JPEG/DivX® CD must be corresponded to the ISO standardized files.
- This unit can read 2000 files per disc. If one disc has more than 2000 files, it reads up to 2000 files, the remaining files will be omitted.
- MP3/JPEG/DivX® CDs cannot be used for the purpose of recording.
- If the CD has both audio tracks and MP3/JPEG/DivX® files, only audio tracks are played.
- It may take more than one minute for this unit to read MP3/JPEG/DivX® files depending on its structure.
- Music recorded by "Joliet Recording Specification" can be played back, the file name is displayed (within 15 letters) on the screen. Long file names will be condensed.
- The music files recorded by "Hierarchical File System" (HFS) cannot be played.

#### Limitations on display

- The maximum number for display is 15 letters. Available letters for display are the following: capital or small alphabets of A through Z, numbers of 0 through 9, and \_ (under score).
- Other letters than those above are replaced in hyphen.

#### To playback MP3/JPEG/DivX® CD in the recorded order

- Use MP3/JPEG/DivX® software that records data alphabetically or numerically.
- Name each file including two-digit or three-digit number (ex. "01" "02" or "001" "002").
- Refrain from making too many sub-folders.

#### CAUTION:

- Some MP3/JPEG/DivX® CDs cannot be played back depending on the recording conditions.
- The CD-R/RW that has no music data or non MP3/JPEG/DivX® files cannot be played back.

#### Standard, sampling frequency and the bit rate:

##### MP3





MPEG-1 Audio  
32kHz, 44.1kHz, 48kHz  
32kbps ~ 320kbps (constant bit rate or variable bit rate)  
The recommend recording setting for a high-quality sound is 44.1kHz of sampling frequency and 128kbps of constant bit rate.

##### DivX® video


DivX® version: DivX® 3, 4, 5, and 6 (specifically 3.1.1, 4.1.2, 5.0.2, 5.0.5, 5.1.1, 5.2.1, 6.0 at Home Theater profile).  
Audio format: MPEG1 Layer2 (MP2), MPEG1 Layer3 (MP3)  
Sampling frequencies: 32kHz, 44.1kHz, 48kHz  
Bit rate: 32kbps ~ 320kbps  
Resolution: Max 720 x 576 (at 25fps), Max 720 x 480 (at 30fps)

## MP3/JPEG/DivX® and Audio CD operation

### MP3 and Audio CD playback

- Load an Audio CD or a disc on which MP3 files have been recorded in the disc slot.
  - A file browser screen will appear on the screen.  

  - Press **▲/▼** to select file.  

  - Press **ENTER**. The selected file starts playing back.  

  - Press **STOP** to end playback.  

- In case the current directory includes more than 8 files, press **▲** or **▼** to scroll in the file list.
  - To see contents in folder, select the folder and then press **ENTER**. To return to the parent directory, select "Go Up ..." then press **ENTER**.
  - When **PLAY** is pressed after the file browser displayed, playback begins automatically starting from the first file. In this case, if the first file is an MP3 file, only MP3 files are played back in order. If the first file is a JPEG file, the first JPEG file is played back. If the first file is a DivX® file, the first DivX® file is played back. If there is no file at a root directory, playback does not begin automatically.
  - The unit records the stopped point. "■" appears on the screen. Press **PLAY** to resume playback (from the scene point).
  - If you press **STOP** again or unload the disc, the unit will clear the stopped point.

#### About file browser



#### Note:

- In the case of a CD containing a mixture of MP3, JPEG and DivX® files, the files are played back by selecting them from the file browser.
- MP3 file on the Kodak Picture CD is not recognized on this unit.

#### Note:

- During MP3 playback, you cannot use Jump and A-B Repeat functions.
- You can use Repeat (Track or All), Random and Program playback for MP3 playback (see "Repeat, random and program playback using file browser" on pages 35 and 36).








#### Select Files

The file type to make it display in the file browser can be chosen.

- Press **◀** or **▶** to select "Select Files" at right column in the file browser.
- Press **ENTER**, then press **▲** or **▼** to select file type from the list (Music, Picture or Movie).
- Press **ENTER** to add/remove check mark. Checked file type will be displayed in the file browser.
- Press **RETURN** to save the setting.

## MP3/JPEG/DivX® and Audio CD operation

### JPEG playback





- Load a JPEG disc in the disc slot.
  - A file browser screen will appear on the screen.  

  - Press **▲/▼** to select the file. To display a thumbnail list, press **DVD MENU**. Press **◀/▶/▲/▼** to select the desired file. (To return to the file browser, press **TOP MENU**).  
  

  - Press **ENTER** or **PLAY**. The selected picture appears on the screen.  

- Rotating an image**  
You can rotate an image by 90 degrees. Press **ANGLE** during playback of the image.  
 or  appears on the screen.
- Zooming an image**  
Zoom function also can be used in viewing JPEG files. Press **ZOOM** (see "Zooming (DVD/VCD)" on page 24).
- Press **STOP** to end playback.  
  
The file browser appears on the screen. If you want to watch the other file, repeat steps 3 ~ 4.

### Slide show playback





The slide show enables you to view pictures (files) one after another automatically.

#### Preparation:

Set "JPEG Interval" setting to "5 Seconds", "10 Seconds" or "15 Seconds" (see page 38).

- Select your desired starting file for the slide show in step 3 on the left.  

  - Press **ENTER** or **PLAY** to start slide show from the selected file.  

- If you press **PAUSE** during the slide show, the slide show stops temporary. "II" appears briefly on the screen. Press **PLAY** or **SKIP** again to resume the slide show.
  - If the picture appears upside down or sideways, press **ANGLE** repeatedly until it's right side up.  
 or  appears on the screen.
  - When the slide show playback finished, the file list appears.
  - To stop the slide show, press **STOP**. The file browser appears.
- Note:**
- During JPEG playback, you cannot use Jump and A-B Repeat functions.
  - When an image exceeds 5760 x 3840 pixels, the entire image (preview window or thumbnail list) may not be displayed on a screen.
  - It may have a longer interval due to the size of data.

**DivX® playback**


- 1 Load a disc on which DivX® files have been recorded in the disc slot.
- 2 A file browser screen will appear on the screen.
 
- 3 Press ▲/▼ to select file.
 
  - When PLAY has been pressed after the file browser displayed, playback begins automatically starting from the first file. In this case, if the first file is a JPEG file, the first JPEG file is played back. If the first file is a DivX® file, the first DivX® file is played back. If the first file is an MP3 file, only MP3 files are played back in order. If there is no file at a root directory, playback does not begin automatically.
- 4 Press ENTER or PLAY. The selected DivX® movie will be played back on the screen.
 
- 5 Press STOP to end playback.
 
  - The unit records the stopped point. "■" appears on the screen. Press PLAY to resume playback (from the scene point).
  - If you press STOP again or unload the disc, the unit will clear the stopped point. To watch the other file, repeat steps 3 ~ 4.

**Note:**  
• This unit cannot playback DivX® file with WMA sound.

**Playing DivX® VOD content**

DivX® VOD content is protected by DRM (Digital Rights Management) system. This restricts playback of content to specific registered devices.

If the incorrect DRM file is loaded, "Authorization Error This player is not authorized to play this video." will appear on the screen.






When you attempt to play DivX® VOD, the number of plays is limited and the right message will appear on the screen. If you wish to play it, select "Yes".

- If the number of plays goes over the limit, then "Rental Expired" will be displayed. In this case, the file will not be played.

**Note:**  
• In order to play DivX® VOD content on this unit, you first need to register the unit with registration code. See page 40.

**Repeat playback (Audio CD/MP3/JPEG/DivX®)**




- 1 In the file browser, press ◀/▶/▲/▼ to select "Repeat" in stop mode.
 
- 2 Press ENTER repeatedly to select "Track" or "All".
 
- 3 Press PLAY.
 

The unit automatically starts repeat playback after finishing the current track.

■ To resume normal playback  
Select Repeat : "Off" in step 2.

- Note:**
- The repeat function is cancelled when you eject the disc or turn the power off.
  - Track repeat function is cancelled whenever SKIP ◀◀ or ▶▶ is pressed.
  - The function of A-B Repeat can be used for DivX® CD. See "A-B Repeat playback (DVD/VCD/Audio CD)" on page 26.

**Random playback (Audio CD/MP3/JPEG/DivX®)**


- 1 In the file browser, press ◀/▶/▲/▼ to select "Mode" in stop mode.
 
- 2 Press ENTER to select "Random".
 
- 3 Press PLAY.
 


The random playback will start.


■ To resume normal playback  
Select Mode : "Off" in step 2.


- Note:**
- The random function is cancelled when you eject the disc or turn the power off.

**Program playback (Audio CD/MP3/JPEG/DivX®)**


- 1 In the file browser, press ◀/▶/▲/▼ to select "Edit Mode" in stop mode, then press ENTER.
 

When "Edit Mode" is in black colour, you can mark the files which you want to add into Program list.
  - 2 Press ◀/▶/▲/▼ to select the file you want to add into the program list.
 

Press ENTER. Selected file was marked. Repeat this procedure to select the other files.
  - 3 Press ◀/▶/▲/▼ to select "Add To Program". Then press ENTER. All marked files are added into the program list.
 

When you finish storing the files you want into the Program list, select "Edit Mode" again and press ENTER to release edit mode.
  - 4 Press ▲/▼ to select "Program View", then press ENTER. Program View shows only the programmed files that you have added in step 2.
 


**Program View**









**Browser View**
  - 5 In the Program View, press PLAY. The files start to playback in programmed order that were added by you.
    - To remove file from program list in stop mode In the Edit Mode, switch to Program View. Select the files you want to remove in stop mode, then press ENTER. Select "Clear Program" and press ENTER. Marked file is removed from program list.
- Note:**  
• The program function is cancelled when you eject the disc or turn the power off.

You can change the default settings to customize performance to your preference.

**Setting procedure**

- 1 Press SETUP in stop mode.
 


The following on-screen display appears.


- 2 Press ▲ or ▼ to select the desired section, then press ▶ or ENTER.
 
- 3 First option will be highlighted. Press ▲ or ▼ to select the desired option.
 
- 4 Then press ▶ or ENTER. The selectable settings will appear.
 
- 5 Change the selection using ▲ or ▼, by referring to the corresponding pages 38 ~ 40. Press ENTER to save the setting.
 
  - Repeat steps 3 and 5 to change other option.
  - To select another section, go back to step 2 by pressing ◀ repeatedly.
- 6 To clear SETUP screen, press SETUP or RETURN.
 

**Setting details**

Section	Option	Details	Page
	Menu	To select the language of "Menu", "Subtitle" and "Audio" if more than one language is available on the disc.	38
	Subtitle		
	Audio		
	TV Screen	To select a picture size according to the aspect ratio of your TV.	39
	Display	To turn On or Off the operational status display on the screen.	
	Picture Mode	To select a preferred picture mode from "Video", "Film" or "Auto".	
	Night Mode	To select On or Off for Night Mode.	39
	Digital Out	To select a digital output sound format corresponding to your system connection.	
	Parental	To select a preferred parental level for the parental setting.	40
	Password	To change the password.	
	DivX(R) VOD	To display your 8-character registration code.	

Setting details



**Menu, Subtitle, Audio**  
You can select the language of "Menu", "Subtitle" and "Audio" if more than one language is recorded onto the disc.

**English, Deutsch, РУССКИЙ, Italiano, Espanol:**  
The selected language will be heard or seen.

**Other:**  
Other languages can be selected (see "Language code list" on page 41).

**Off (Subtitle):**  
Subtitles do not appear.

**Original (Audio):**  
The unit will select the first priority language of each disc.

- Note:**
- If the selected language is not recorded on the disc, the first-priority language is selected.
  - If you want to change the OSD language, you can perform it by TV MENU (see page 12).



**TV Screen**  
You have the following screen sizes to choose from:

**4:3 (Letter box):**  
When playing back a wide screen-DVD disc, it displays the wide picture with black bands at the top and bottom of screen.

**4:3 (Pan scan):**  
It displays the wide picture on the whole screen with left and right edges automatically cut off.

**16:9 (Wide):**  
Select this mode when connecting to a wide-screen TV. A wide screen picture is displayed full size.

- Note:**
- If the DVD disc is not formatted in the pan & scan style, it displays 4:3 style.

**Display**

On screen display can be switched on or off when you press any buttons.

**Off:** On screen displays do not appear when you press any buttons.

**On:** On screen displays appear when you press the buttons (factory setting).

**Picture Mode**

There are two types of source content in pictures recorded in DVD video discs: film content (pictures recorded from films at 24 frames per second) and video content (video signals recorded at 30 frames per second). Make this selection according to the type of content being viewed.

**Auto:** Select this position normally. The DVD player automatically detects source content, film or video of playback source, and converts that signal in an appropriate method.

**Film:** The DVD player converts film content pictures appropriately. Suitable for playback of film content pictures.

**Video:** The DVD player filters video signal, and converts appropriately. Suitable for playback of video content pictures.

- Note:**
- Depending on the disc, pictures may be cut off or doubled. In this case, select "Video".

**JPEG Interval**


You can continuously playback all JPEG files automatically. After the selection below, the disc will start playback on JPEG files which have been recorded.

**Off:**  
Plays back one file at a time.

**5 Seconds:**  
Plays back images in the form of a slide show at 5 second intervals.

**10 Seconds:**  
Plays back images in the form of a slide show at 10 second intervals.

**15 Seconds:**  
Plays back images in the form of a slide show at 15 second intervals.



**Night Mode**  
Night Mode enables you to control the dynamic range so as to achieve a suitable sound for your equipment.

**Off:** It plays back at the recording level on the disc.

**On:** Loud sound such as explosion is toned down slightly when played back. This is suitable when it is connected to a stereo.

- Note:**
- This function works only when the disc recorded with Dolby Digital is played back.
  - The level of Night Mode may differ depending on DVD video disc.

**Digital Out**


You can select the digital output sound format corresponding to your system connection.

**Off:**  
There is no sound output from COAXIAL DIGITAL AUDIO OUT jack.

**PCM:**  
Change Dolby Digital to PCM for the output. Select when connected to a 2 channel digital stereo amplifier.

**Bitstream:**  
Disc audio bitstream data will be output.

- Note:**
- Even if you select "Bitstream", MPEG Audio will be output in PCM format.



**Parental control setting**

Some discs are specified as not suitable for children. Such discs can be limited not to playback with the unit.

- Press **▲** or **▼** to select "Parental", then press **ENTER**. "Enter Password" screen will appear.
- Press "0000" using **Number buttons (0-9)**. (Please note, this is pre-setting password of this unit). Then press **ENTER**. The parental level list will appear.
  - Level Off:** The parental control setting does not function.
  - Level 8:** Virtually all DVD software can be played back.
  - Level 1:** DVD software for adults cannot be played back.
- Press **▲** or **▼** to select from the level 1 to level 8. The limitation will be more severe as the level number is lower. Then press **ENTER**.

- Note:**
- Depending on the discs, the unit cannot limit playback.
  - Some discs may not be encoded with specific rating level information though its disc jacket says "adult." For those discs, the age restriction will not work.
  - The password is required every time when you change the parental level.
  - If you input a wrong number, press **CANCEL**.

**Set the new password**

- Press **▲** or **▼** to select "Password", then press **ENTER**. "Enter Current Password" screen will appear.
- Press **Number buttons (0-9)** to input the current password (If the password has not been set yet after you purchase this unit, it is "0000").
- Then press **ENTER**. "Enter New Password" screen will appear. Press **Number buttons (0-9)** to input the new password.
- Press **ENTER**. Now your new password has been set. Be sure to remember this number!

**If you forget the password.**

- Press **EJECT** to remove the disc.
- While holding **7** down on the remote control and at the same time press **STOP** on the side panel. "Password Clear" appears on the screen. Now the password has been returned to the initial value ("0000").

Setting details

**DivX(R) VOD**

In order to play DivX® VOD (Video On Demand) content on this unit, you first need to register the unit with your DivX® VOD content provider. You do this by generating a DivX® VOD registration code, which you submit to your provider.

Press **▲** or **▼** to select "DivX(R) VOD". Then press **ENTER**. Your 8-character registration code is displayed. Make a note of the code as you will need it when you register with a DivX® VOD provider. Then press **ENTER**.

- Note:**
- If each setup (pages 38-40) has been completed, the unit can always work under the same condition (especially with DVD discs).
  - Each setup will be retained in the memory even if you turn the power off.

Temporary cancel the rating level by DVD disc

Depending on the DVD disc, the disc may try to temporarily cancel the rating level that you have set. It is up to you to decide whether to cancel the rating level or not.

- Load a DVD disc.**
- If the DVD disc has been designed to temporarily cancel the Rating level, the screen which follows the "Reading" screen will change, depending on which disc is played. If you select "YES" with the ENTER key, password input screen will then appear.**
  - If "NO" is selected, press **EJECT** to remove the disc.
- Enter the password with Number buttons (0-9). Then press ENTER.**  
To exit from the entry, press **RETURN**.
- Playback will commence if the entered password is correct.**

- Note:**
- This temporary cancellation of rating level will be kept until the disc is ejected.
  - When the disc is ejected, the original rating level will be set again automatically.

Enter the appropriate code number for the initial settings "Menu", "Subtitle" and/or "Audio" (see page 38).

Language Name	Code	Language Name	Code	Language Name	Code	Language Name	Code
Abkhazian	1112	Fiji	1620	Lingala	2224	Sinhalese	2919
Afar	1111	Finnish	1619	Lithuanian	2230	Slovak	2921
Afrikaans	1116	French	1628	Macedonian	2321	Slovenian	2922
Albanian	2927	Frisian	1635	Malagasy	2317	Somali	2925
Amharic	1123	Galician	1722	Malay	2329	Spanish	1529
Arabic	1128	Georgian	2111	Malayalam	2322	Sundanese	2931
Armenian	1835	German	1415	Maltese	2330	Swahili	2933
Assamese	1129	Greek	1522	Maori	2319	Swedish	2932
Aymara	1135	Greenlandic	2122	Marathi	2328	Tagalog	3022
Azerbaijani	1136	Guarani	1724	Moldavian	2325	Tajik	3017
Bashkir	1211	Gujarati	1731	Mongolian	2324	Tamil	3011
Basque	1531	Hausa	1811	Nauru	2411	Tatar	3030
Bengali; Bangla	1224	Hebrew	1933	Nepali	2415	Telugu	3015
Bhutani	1436	Hindi	1819	Norwegian	2425	Thai	3018
Bihari	1218	Hungarian	1831	Oriya	2528	Tibetan	1225
Breton	1228	Icelandic	1929	Panjabi	2611	Tigrinya	3019
Bulgarian	1217	Indonesian	1924	Pashto, Pushto	2629	Tonga	3025
Burmese	2335	Interlingua	1911	Persian	1611	Turkish	3028
Byelorussian	1215	Irish	1711	Polish	2622	Turkmen	3021
Cambodian	2123	Italian	1930	Portuguese	2630	Twi	3033
Catalan	1311	Japanese	2011	Quechua	2731	Ukrainian	3121
Chinese	3618	Javanese	2033	Rhaeto-Romance	2823	Urdu	3128
Corsican	1325	Kannada	2124	Romanian	2825	Uzbek	3136
Croatian	1828	Kashmiri	2129	Russian	2831	Vietnamese	3219
Czech	1329	Kazakh	2121	Samoan	2923	Volapük	3225
Danish	1411	Kirghiz	2135	Sanskrit	2911	Welsh	1335
Dutch	2422	Korean	2125	Scots Gaelic	1714	Wolof	3325
English	1524	Kurdish	2131	Serbian	2928	Xhosa	3418
Esperanto	1525	Laothian	2225	Serbo-Croatian	2918	Yiddish	2019
Estonian	1530	Latin	2211	Shona	2924	Yoruba	3525
Faroese	1625	Latvian, Lettish	2232	Sindhi	2914	Zulu	3631



## SERVICING NOTICES ON CHECKING

### 1. KEEP THE NOTICES

As for the places which need special attentions, they are indicated with the labels or seals on the cabinet, chassis and parts. Make sure to keep the indications and notices in the operation manual.

### 2. AVOID AN ELECTRIC SHOCK

There is a high voltage part inside. Avoid an electric shock while the electric current is flowing.

### 3. USE THE DESIGNATED PARTS

The parts in this equipment have the specific characters of incombustibility and withstand voltage for safety. Therefore, the part which is replaced should be used the part which has the same character.

Especially as to the important parts for safety which is indicated in the circuit diagram or the table of parts as a  $\triangle$  mark, the designated parts must be used.

### 4. BE CAREFUL WITH THE LCD PANEL

Avoid a shock to the panel while servicing. Take enough care to deal with it.

### 5. PUT PARTS AND WIRES IN THE ORIGINAL POSITION AFTER ASSEMBLING OR WIRING

There are parts which use the insulation material such as a tube or tape for safety, or which are assembled in the condition that these do not contact with the printed board. The inside wiring is designed not to get closer to the pyrogenic parts and high voltage parts. Therefore, put these parts in the original positions.

### 6. PERFORM A SAFETY CHECK AFTER SERVICING

Confirm that the screws, parts and wiring which were removed in order to service are put in the original positions, or whether there are the portions which are deteriorated around the serviced places serviced or not. Check the insulation between the antenna terminal or external metal and the AC cord plug blades. And be sure the safety of that.

#### (INSULATION CHECK PROCEDURE)

1. Unplug the plug from the AC outlet.
2. Remove the antenna terminal on TV and turn on the TV.
3. Insulation resistance between the cord plug terminals and the external exposure metal **[Note 2]** should be more than 1M ohm by using the 500V insulation resistance meter **[Note 1]**.
4. If the insulation resistance is less than 1M ohm, the inspection repair should be required.

#### **[Note 1]**

If you have not the 500V insulation resistance meter, use a Tester.

#### **[Note 2]**

External exposure metal: Antenna terminal  
Headphone jack

## HOW TO ORDER PARTS

Please include the following informations when you order parts. (Particularly the VERSION LETTER.)

#### 1. MODEL NUMBER and VERSION LETTER

The MODEL NUMBER can be found on the back of each product and the VERSION LETTER can be found at the end of the SERIAL NUMBER.

#### 2. PART NO. and DESCRIPTION

You can find it in your SERVICE MANUAL.

## IMPORTANT

When you exchange IC and Transistor with a heat sink, apply silicon grease on the contact section of the heat sink. Before applying new silicon grease, remove all the old silicon grease. (Old grease may cause damage to the IC and Transistor).

## WHEN REPLACING DVD DECK

### [ When removing the DVD Deck ]

Before removing Pick Up PCB and DVD MT PCB connector, the short circuit the position shown in **Fig. 1** using a soldering iron. If you remove the DVD Deck with no soldering, the Laser may be damaged.

### [ When installing the DVD Deck ]

Remove all the soldering on the short circuit position after the connection of Pick Up PCB and DVD MT PCB connector.

### NOTE

- Before your operation, please read "PREPARATION OF SERVICING".
- Use the Lead Free solder.
- Manual soldering conditions
  - Soldering temperature:  $320 \pm 20^{\circ}\text{C}$
  - Soldering time: Within 3 seconds
  - Soldering combination: Sn-3.0Ag-0.5Cu
- When Soldering/Removing of solder, use the draw in equipment over the Pick Up Unit to keep the Flux smoke away from it.




Fig. 1



## DISC REMOVAL METHOD AT NO POWER SUPPLY

1. Remove the Back Cabinet and Angle Deck. (Refer to item 1 of the DISASSEMBLY INSTRUCTIONS.)
2. Slide the Belt Loading toward the arrow direction by hand to release the lock. (Refer to Fig. 1)
3. Take out the Disc from the DVD Deck. Be careful not to scratch on the Disc.




Fig. 1

## PARENTAL CONTROL - RATING LEVEL 4 DIGIT PASSWORD CANCELLATION

If the stored 4 digit password in the Rating Level menu needs to be cancelled, please follow the steps below.

1. Turn Unit ON.
2. Set the DVD to the Stop Mode.
3. Check that "No disc" is displayed on the screen.
4. Press and hold the "STOP" button on the side panel.
5. Simultaneously press and hold the "7" key on the remote control unit.
6. Hold both keys for more than 2 seconds.
7. The On Screen Display message "PASSWORD CLEAR" will appear.
8. The 4 digit password has now been cleared.

## TRAY LOCK

The disk cannot be taken out by setting the Tray Lock, please follow the steps below.

1. Turn Unit ON.
2. Set the DVD to the Stop Mode.
3. Press it in order of "SETUP", "SUBTITLE", "3", "AUDIO SELECT" and "0" key of a remote control unit.
4. The On Screen Display message "🔒" will appear.
5. The Tray Lock has now been set up.


To unlock the Tray Lock, please follow the steps below.

1. Turn Unit ON.
2. Set the DVD to the Stop Mode.
3. Press it in order of "SETUP", "SUBTITLE", "3", "AUDIO SELECT" and "0" key of a remote control unit.
4. The On Screen Display message "🔒" will appear.
5. The Tray Lock has now been cleared.

# REMOTE CONTROL KEY CODE

## NEC Format

Custom Code : 40-BF H, 44-BB H, 45-BA H, 45-BC H



No.	Key Name	Custom Code	Key Code
1	EJECT	45 BA	F5
2	TV/DVD	45 BC	B3
3	SLEEP	40 BF	15
4	POWER	40 BF	12
5	1	40 BF	01
6	2	40 BF	02
7	3	40 BF	03
8	4	40 BF	04
9	5	40 BF	05
10	6	40 BF	06
11	7	40 BF	07
12	8	40 BF	08
13	9	40 BF	09
14	DISPLAY	40 BF	1C
15	0	40 BF	00
16	MUTE	40 BF	10
17	SUBTITLE	44 BB	87
18	DVD MENU	40 BF	19
19	VOLUME +	40 BF	1A
20	AUDIO SELECT	44 BB	53
21	INPUT	40 BF	0F
22	TOP MENU	44 BB	DF
23	VOLUME -	40 BF	1E
24	CH RTN/ZOOM	45 BA	40
25	HOLD	40 BF	53
26	TEXT/TV	45 BA	79
27	CH/PAGE↑/↑	40 BF	3E
28	LEFT	44 BB	51
29	ENTER/CHANNEL LIST	40 BF	3D
30	RIGHT	44 BB	4D
31	CH/PAGE↓/↓	40 BF	3F
32	MENU/SETUP	40 BF	0E
33	EXIT/CANCEL	44 BB	EF
34	RETURN	44 BB	5D
35	PLAY	44 BB	15
36	STOP	44 BB	14
37	SKIP-	45 BA	23
38	REVEAL / SEARCH-	45 BA	19
39	SUB PAGE / SEARCH+	45 BA	13
40	F/T/B / SKIP+	45 BA	24
41	RED / SLOW-	45 BA	0E
42	GREEN / PAUSE	45 BA	15
43	YELLOW / PLAY MODE	45 BA	E0
44	BLUE / SLOW+	45 BA	0D
45	MARKER	45 BA	EC
46	ANGLE	44 BB	96
47	REPEAT A-B	44 BB	5C
48	JUMP	44 BB	9B
49	PICTURE SIZE	40 BF	59

# TABLE OF CONTENTS

- GREEN PRODUCT PROCUREMENT
- LEAD-FREE SOLDER
- OWNER'S MANUAL

SERVICING NOTICES ON CHECKING .....	A1-1
HOW TO ORDER PARTS .....	A1-1
IMPORTANT .....	A1-1
WHEN REPLACING DVD DECK .....	A1-2
DISC REMOVAL METHOD AT NO POWER SUPPLY .....	A1-3
PARENTAL CONTROL - RATING LEVEL .....	A1-3
TRAY LOCK .....	A1-3
REMOTE CONTROL KEY CODE .....	A1-4
TABLE OF CONTENTS .....	A2-1
GENERAL SPECIFICATIONS .....	A3-1~A3-5
<b>DISASSEMBLY INSTRUCTIONS</b>	
1.REMOVAL OF MECHANICAL PARTS AND P.C. BOARDS .....	B1-1, B1-2
2.REMOVAL OF DVD DECK PARTS .....	B2-1, B2-2
3.REMOVAL AND INSTALLATION OF FLAT PACKAGE IC .....	B3-1, B3-2
<b>SERVICE MODE LIST</b> .....	C-1
<b>SERVICING FIXTURES AND TOOLS</b> .....	C-2
<b>RE-WRITE FOR DVD FIRMWARE</b> .....	C-2
<b>WHEN REPLACING EEPROM (MEMORY) IC</b> .....	C-3
<b>ELECTRICAL ADJUSTMENTS</b> .....	D-1~D-6
<b>TROUBLESHOOTING GUIDE</b> .....	E-1~E-9
<b>BLOCK DIAGRAMS</b>	
DVD .....	F-1, F-2
POWER .....	F-3, F-4
21PIN/TUNER/SOUND AMP .....	F-5, F-6
REGULATOR .....	F-7, F-8
SCALER/SUB MICON/DVD_INTERFACE/AV_SWITCH .....	F-9, F-10
<b>PRINTED CIRCUIT BOARDS</b>	
DVD MT .....	G-1, G-2
MAIN/TUNER .....	G-3~G-6
POWER/OPERATION/REMOCON/SW .....	G-7, G-8
POWER/OPERATION/REMOCON .....	G-9, G-10
<b>SCHEMATIC DIAGRAMS</b>	
MPEG/MICON/DSP/RF_AMP .....	H-1, H-2
MEMORY .....	H-3, H-4
MOTOR DRIVE .....	H-5, H-6
AUDIO/VIDEO .....	H-7, H-8
21PIN .....	H-9, H-10
REGULATOR .....	H-11, H-12
REGULATOR2 .....	H-13, H-14
AV SWITCH .....	H-15, H-16
SOUND AMP MUTE .....	H-17, H-18
TUNER .....	H-19, H-20
SCALER .....	H-21, H-22
SUB MICON .....	H-23, H-24
JACK .....	H-25, H-26
DVD_INTERFACE/AV_SWITCH .....	H-27, H-28
PANEL_INTERFACE .....	H-29, H-30
POWER .....	H-31, H-32
BACKLIGHT INVERTER .....	H-33, H-34
SOUND AMP .....	H-35, H-36
JACK OUT .....	H-37, H-38
SW .....	H-39, H-40
<b>INTERCONNECTION DIAGRAM</b> .....	H-41, H-42
<b>WAVEFORMS</b> .....	I-1, I-2
<b>MECHANICAL EXPLODED VIEWS</b> .....	J1-1~J1-3
<b>DVD DECK EXPLODED VIEW</b> .....	J2-1
<b>MECHANICAL REPLACEMENT PARTS LIST</b> .....	K1-1
<b>DVD DECK REPLACEMENT PARTS LIST</b> .....	K2-1
<b>ELECTRICAL REPLACEMENT PARTS LIST</b> .....	K3-1~K3-4

## GENERAL SPECIFICATIONS

G-1	TV System	LCD	LCD Size / Visual Size	15.0 inch / 380.1 mmV		
			LCD Type	Color TFT LCD		
			Number of Pixels	1024(H) x 768(V)		
			View Range	70/70 degree		
				Left/Right Up/Down	65/60 degree	
				Bright Dot Zero Bright Dot Ratio	$n \leq 0$ (Sorted Products) ---	
	Color System			PAL / SECAM		
	Speaker			2 Speaker		
			Position	Front		
			Size	1.5 x 2.7 inch		
			Impedance	8 ohm		
	Sound Output		MAX	1.0W + 1.0W		
			10%(Typical)	---		
		NTSC3.58+4.43 /PAL60Hz		Yes		
G-2	DVD System	Color System		NTSC, PAL		
		Disc		DVD,		
		Disc Diameter		120 mm , 80 mm		
		Drive		DSM-2		
		Search speed	Fwd		4 step	
				Actual	2-45 times (DVD/Video CD) 4-40 times (CD)	
			Rev		4 step	
				Actual	2-45 times (DVD/Video CD) 4-40 times (CD)	
			Slow speed	Fwd		1/7 -1/2 times
					Actual	--
			Rev	1/7 -1/2 times		
				Actual	--	
G-3	Tuning System	Broadcasting System	Analog	U.K., I.R., CCIR, FRENCH System B/G, D/K, I/I, L		
			Digital	--		
		Tuner and Receive CH	System	1Tuner (Analog)		
		CH Coverage	Destination	UK, I.R., CCIR Hyper+France CATV		
			Analog	IreE2~E4, X~Z+2, S1~S10, E5~E12, S11~S41, E21~E69		
			Digital	--		
		Intermediate Frequency	Analog	BG / II / DK, L / L' (SECAM VL)		
				38.9 / 38.9 / 38.9 / 33.9MHz		
				33.4 / 32.9 / 32.4 / 40.4MHz		
				5.5 / 6.0 / 6.5 / 6.5MHz		
			Digital	--		
		Auto Tuning Method		ALL Band (Not C.C.I.R. CH Plan)		
		Preset CH	Analog	99		
	Digital	--				
Stereo/Dual TV Sound		Nicam/A2 Dual				
Tuner Sound Muting		Yes				
G-4	Signal	Video Signal	Input Level	1 V p-p/75 ohm		
			Output Level	1 V p-p/75 ohm		
			S/N Ratio (Weighted)	65dB		
			Horizontal Resolution at DVD Mode	400 Lines		
		RGB Signal	Output Level	--		
		Audio Signal	Input Level	-8.0dBm/50k ohm		
			Output Level	-12.0dBm/1k ohm (-20dBFS 0dBFS=2.0Vrms)		
				at DVD	-8 dBm/1k ohm (0dBm=0.775Vrms)	
				at TV		
			Digital Output Level	0.5 V p-p/75 ohm		
			S/N Ratio at DVD (Weighted)	85dB		
			Harmonic Distortion	0.02% (1KHz)		
			Frequency Response :	at DVD	4Hz - 22kHz	
		at Video CD	4Hz - 20kHz			
		at SVCD	--			
		at CD	4Hz - 20kHz			
G-5	Power	Power Source	AC	220-240V AC 50Hz		
			DC	---		
		Power Consumption		at AC	45 W at AC 230 V 50 Hz	
				at DC	--	
		Stand by (at AC)	w/ EPG Timer		--	
	w/o EPG Timer		1 W at 230V 50Hz			
	Per Year		-- kWh/Year			
	Protector	Power Fuse	Yes			
G-6	Regulation	Safety		CE(EN60065:02), GOST		
		Radiation		CE, GOST		
		X-Radiation		---		
G-7	Temperature	Operation		+5°C ~ +40°C		
		Storage		-20°C ~ +60°C		
		Space Around Unit		100 mm(4inch)		
G-8	Operating Humidity			Less than 80% RH		

## GENERAL SPECIFICATIONS

G-9	OSD Language	(TV)	English, Spanish, German, Russian, Italian	
		(DVD)	English, Spanish, German, Russian, Italian	
G-10	Clock and Timer	Sleep Timer	Max Time 120 Min	
		On/Off Timer	Step 10 Min	
		Wake Up Timer	Program(On Timer / Off Timer) -- Program	
		Timer Back-up (at Power Off Mode)	more than -- Min Sec	
G-11	Remote Control	Unit	RC-PT	
		Glow in Dark Remocon	No	
		Remocon Format	TOSHIBA	
		Format	TOSHIBA	
		Custom Code	40-BF h ,44-BB h ,45-BA h ,45-BC h	
		Power Source	Voltage(D.C) UM size x pcs	3V UM-4 x 2 pcs
		Total Keys		49 Keys
		Keys	Power (Stand By)	Yes
			Display / (Status)	Yes
			Menu / Setup	Yes
			Digital Menu	No
			Input Select	Yes
			TV/DVB-T	No
			Guide/EPG	No
			Picture Size	Yes
			1	Yes
			2	Yes
			3	Yes
			4	Yes
			5	Yes
			6	Yes
			7	Yes
			8	Yes
			9	Yes
			0	Yes
			Sleep	Yes
			Mute	Yes
			Volume Up $f \rightarrow$	No
			Volume Down $k \leftarrow$	No
			Volume Up	Yes
			Volume Down	Yes
			CH Down	No
			CH Up	No
			Menu	No
			$\uparrow$	No
			$\downarrow$	No
			$\leftarrow$	Yes
			$\rightarrow$	Yes
			Enter / CH List	Yes
			Exit / Cancel	Yes
			Freeze frame	No
			TV/Radio	No
			Subtitle	Yes
			Play	Yes
			Stop	Yes
			Eject	Yes
			TV / DVD	Yes
	Return	Yes		
	DVD Menu	Yes		
	Top Menu	Yes		
	Repeat A-B	Yes		
	Jump	Yes		
	CH RTN/Zoom	Yes		

## GENERAL SPECIFICATIONS

	T' TEXT Keys	TEXT / TV	Yes			
		Reveal / Skip	No			
		Sub Page / Search+	Yes			
		Reveal / Search-	Yes			
		Reveal	No			
		Display Cancel	No			
		HOLD	Yes			
		Angle	Yes			
		Marker	Yes			
		F.T.B / Skip+	Yes			
		Skip-	Yes			
		Slow+ / Blue	Yes			
		Slow- / Red	Yes			
		Play Mode/Yellow	Yes			
		Green/Pause	Yes			
		Normal	No			
		F/T/B(Expand)	No			
		F/T/B(Expand) / Normal	No			
		Quick View	No			
		Sub Page / Quick View	No			
		Up/CH Up	No			
		↑ / CH Up / Page Up	Yes			
		CH Up / Page Up	No			
		Down / CH Down	No			
		↓ / CH Down / Page Down	Yes			
		CH Down / Page Down	No			
		Reset	No			
		Audio	Yes			
		Reset / Audio 1/2	No			
		G-12	Features	Power On Memory	Yes	
				Auto Shut Off	Yes	
				Just Clock Function	No	
				Game Position	No	
				DNR	No	
					--	
				Comb Filter	Yes	
					3D	
				Auto Set Up (Fast installation)	Auto tuning (Analog tuner)	Yes
					CH sort	Yes
					ATS	Yes
	Auto clock (Analog tuner)			No		
	Plug in start			Yes		
Picture Setting(TV)	Picture Preference			Yes		
	Brightness , Contrast , Color			Yes		
	Tint			Yes		
	Sharpness			Yes		
	DNR			No		
	Color Temperature			Yes		
	Blue Back			Yes		
	Backlight Control			Yes		
	Film Mode			No		
Audio	Nicam			Yes		
	Tone Control (Bass/Treble/Balance)			Yes		
	Surround			No		
	BBE			No		
	SRS WOW (SRS 3D/Focus/Tru Bass)			No		
	Variable Audio Out			No		
Tuning	Auto Tuning			Yes		
	Manual Tuning			Yes		
	CH Allocation			Yes		
Lock (Analog)	Panel Lock			No		
	Channel Lock			No		
	Hotel Lock			No		
Screen Saver	Inversion			No		
	Full White			No		
	Screen Saver			No		
	Static Image			No		
Black Side Panel				No		
CH Label				Yes		
T' Text		Yes				
	Text type	Fasttext / Toptext				
	Text Language	English , French, Swedish, Hungarian Turkish, German, Portuguese, Spanish, Italian, Greek, Slovakian, Russian, Polish, Czech, Rumanian, Estonian, Lettish, Lithuanian, Ukrainian, Croatian, Slovenian, Latvian				

## GENERAL SPECIFICATIONS

	Wide Mode (AUTO/4:3/16:9)		Yes	
	Reset TV Setting		Yes	
	HD Zoom		No	
	Picture Scroll (Vertical Position)		No	
	PFC(Power Factor circuit)		No	
	Freeze frame		No	
	HD-Ready		No	
	Plug and Play		No	
	Scart Spec	Scart1	AV in	
			AV out	
			S-Video in	
			RGB in	
		Scart2	AV in	
			AV out	
			S-Video in	
			RGB in	
	PC Monitor Input		No	
	HDMI Input		No	
	Component Input		No	
	Wall Mount	Size W x H(mm)	No	
		Screw Size	No	
<b>Features (DVD)</b>	Tray Lock		Yes	
	WMA		No	
	JPEG		Yes	
	Video CD Playback		Yes	
	SVCD Playback		No	
	MP3 Playback		Yes	
	Divx Playback		Yes	
		DMF Support		No
	Digital Out	(Dolby Digital)		Yes
		(MPEG)		Yes
		(PCM)		Yes
		(DTS)		Yes
	Down Mix Out	(Dolby Digital)		Yes
		(DTS)		No
	3D Surround			No
Closed Caption			No	
Screen Saver			No	
Audio DAC			192kHz / 24bit	
<b>G-13 Accessories</b>	Owner's Manual	Language	English / Russian	
		w/Guarantee Card	No	
	Remote Control Unit		Yes	
	Rod Antenna		No	
		Poles	-	
		Terminal	-	
	Loop Antenna (W/ Antenna Change Plug)		No	
		Terminal	-	
	U/V Mixer		No	
	DC Car Cord (Center+)		No	
	Guarantee Card		Yes	
	Warning Sheet		No	
	Circuit Diagram		No	
	Antenna Change Plug		No	
	Service Facility List		No	
	Important Safeguard		No	
	Dew/AHC Caution Sheet		No	
	Quick Set-up Sheet		Yes	
	My Movie stream (Free DVD redemption voucher)		No	
	Carbon Neutral Certificate		No	
	Battery		Yes	
		UM size x pcs	UM-4 x 2 pcs	
		OEM Brand	No	
	AC Adapter		No	
	AC Cord (for AC Adapter)		No	
	AC Cord		Yes	
	AV Cord (2Pin-1Pin)		No	
RF Cable		Yes		
HDMI-DVI Cable		No		
Helpline Sheet		No		
300 ohm to 75 ohm Antenna Adapter		No		
Sheet Information (GOST)		Yes(ONLY MAY ORDER)		

## GENERAL SPECIFICATIONS

<b>G-14</b>	<b>Interface</b>	Switch	Top	Power (Tact)	Yes		
				System Select	No		
				Main Power SW	No		
				Channel Up/Menu Up/Play	Yes		
				Channel Down/Menu Down/Stop	Yes		
				Volume Up/Menu >	Yes		
				Volume Down/Menu <	Yes		
				Play	No (CH+ Alternative)		
				Eject	Yes		
				Skip+, Search+	No		
				Skip-, Search-	No		
				Stop	No (CH- Alternative)		
				Input Select / Enter	Yes		
				Menu	Yes		
				Indicator	Power/Stand-by/EPG Timer	Yes(GREEN / RED / --)	
					On Timer	No	
				Terminals	Side	CI Card Slot	No
					Rear	Video Input 1	RCA x 1
						Audio Input 1	RCA x 2(L/MONO, R)
						S- Input 1	Yes
				Video Input 2	No		
				Audio Input 2	No		
				S- Input 2	No		
				Video Output	No		
				Audio Output	No		
				Digital Audio Out (Coaxial)	Yes		
				Component In	No		
				Audio Input (Component In use)	No		
				Sub Woofer Output	No		
				Diversity	No		
				Ext Speaker	No		
				DC Jack 12V(Center +)	No		
				Other Terminal	Headphone		
				VHF/UHF Antenna Input	DIN Type		
				AC Inlet	Yes		
		Euro Scart (21Pin)	1Scart				
		PC Monitor Input (D-Sub)	No				
		Audio Input	No				
		HDMI Input 1	No				
		Audio Input (HDMI/DVI In use)	No				
		HDMI Input 2	No				
		Audio Input (HDMI/DVI In use)	No				
<b>G-15</b>	<b>Set Size</b>	Approx. W x D x H (mm)		394 x 207 x 392			
		w/o Stand,Handle Approx. W x D x H (mm)		394 x 64 x 355			
<b>G-16</b>	<b>Weight</b>	Net Approx.		4.0kg (8.8 lbs)			
		Net w/o Stand,Handle Approx.		3.3kg (7.3 lbs)			
		Gross Approx.		5.6kg (12.3 lbs)			
<b>G-17</b>	<b>Carton</b>	Master Carton	Content	No			
			Material	---- Sets			
			Dimensions W x D x H(mm)	-- x -- x --			
			Description of Origin	No			
			Gift Box	Yes			
			Material	Single/White			
			Dimensions W x D x H(mm)	485 x 275 x 470			
			W/Color Photo Label	No			
			Description of Origin	Yes			
		Drop Test	Natural Dropping At 1 Corner / 3 Edges / 6 Surfaces				
			Height (cm)	80			
			Container Stuffing	1006 Sets/40' container			
	w/Pallet	No					
	w/Wrapping	No					
<b>G-18</b>	<b>Material</b>	Cabinet	Cabinet Front	PC+ABS 94V0 NON-HALOGEN			
			Cabinet Rear	PS 94V0 NON-DECABROM			
		PCB	Non-Halogen	No			
			Eyelet	Yes			
<b>G-19</b>	<b>Environment</b>	Environmental standard requirement		Green procurement of TOSHIBA			
		Pb- Free		Phase3(PHASE3A)			
		Measures for Whisker		Yes			
		WEEE		Yes			



# DISASSEMBLY INSTRUCTIONS


## 1. REMOVAL OF MECHANICAL PARTS AND P.C. BOARDS

### CAUTION

Be careful not to remove the FFC cable forcibly, because the FFC cable may be damaged.


### 1-1: FRONT CABINET ASS'Y, STAND ASS'Y AND COVER BACK (Refer to Fig. 1-1)

1. Unlock the support (1).
2. Remove the Cover Back in the direction of arrow (A).
3. Remove the 2 screws (2).
4. Remove the Stand Ass'y in the direction of arrow (B).
5. Remove the 7 screws (3).
6. Remove the Front Cabinet Ass'y in the direction of arrow (C).




### 1-2: LCD PANEL AND REMOCON PCB (Refer to Fig. 1-2)

1. Disconnect the following connector: **(CD7005, CD7006 and CP7200)**.
2. Remove the 2 screws (1).
3. Remove the 3 screws (2).
4. Remove the Angle LCD-R and Angle LCD-L in the direction of arrow (A).
5. Remove the LCD PANEL in the direction of arrow (B).
6. Disconnect the following connector: **(CP7601)**.
7. Remove the screw (3).
8. Remove the Remocon PCB in the direction of arrow (C).




### 1-3: POWER PCB AND TUNER PCB (Refer to Fig. 1-3)

1. Disconnect the following connector: **(CP501 and CP8101)**.
2. Remove the 6 screws (1).
3. Remove the Power PCB in the direction of arrow (A).
4. Remove the screw (2).
5. Remove the Tuner PCB in the direction of arrow (B).



### 1-4: MAIN PCB AND OPERATION PCB (Refer to Fig. 1-4)


1. Disconnect the following connector: **(CP6501 and CP2201)**.
2. Remove the 5 screws (1).
3. Remove the Main PCB in the direction of arrow (A).
4. Remove the 3 screws (2).
5. Remove the Operation PCB in the direction of arrow (B).



## DISASSEMBLY INSTRUCTIONS

### 1-5: DVD DECK (Refer to Fig. 1-5)

1. Short circuit the position shown in **Fig. 1-5** using a soldering iron. If you remove the DVD Deck with no soldering, the Laser may be damaged.
2. Remove the 4 screws (1).
3. Remove the DVD Deck in the direction of arrow (A).
4. Disconnect the following connectors:  
**(CP2301, CP2302 and CP2303).**
5. Remove the 2 screws (2).
6. Remove the Angle Mpeg in the direction of arrow (B).
7. Remove the 4 screws (3).
8. Remove the DVD MT PCB in the direction of arrow (C).



### NOTE

1. Before your operation, please read "PREPARATION OF SERVICING"
2. Use the Lead Free solder.
3. Manual soldering conditions
  - Soldering temperature:  $320 \pm 20^{\circ}\text{C}$
  - Soldering time: Within 3 seconds
  - Soldering combination: Sn-3.0Ag-0.5Cu
4. When Soldering/Removing of solder, use the drawing equipment over the Pick Up Unit to keep the Flux smoke away from it.
5. When installing the DVD Deck, remove all the soldering on the short circuit position after the connection of Pick Up PCB and DVD MT PCB connector.

# DISASSEMBLY INSTRUCTIONS


## 2. REMOVAL OF DVD DECK PARTS

### NOTE

1. Disassemble only the DVD DECK PARTS parts listed here. Minute adjustments are needed if the disassembly is done. If the repair is needed except listed parts, replace the DVD MECHA ASS'Y.




### 2-1: TRAVERSE ASS'Y (Refer to Fig. 2-1-A)

1. Remove the 3 screws (1).
2. Unlock the 2 supports (2).
3. Remove the Insulator (R) from the Loader Sub Ass'y.
4. Remove the Traverse Ass'y.




### NOTE

1. In case of the Traverse Ass'y installation, hook the wire on the Loader Ass'y as shown Fig. 2-1-B to Fig. 2-1-C.



### 2-2: SWITCH PCB ASS'Y/GEAR MIDDLE/GEAR FEED/RACK FEED ASS'Y/FEED MOTOR (Refer to Fig. 2-2-A)

1. Remove the Insulator (F).
2. Remove the Insulator (R).
3. Unlock the support (1).
4. Remove the Gear Middle.
5. Remove the screw (2).
6. Remove the Rack Feed Ass'y.
7. Remove the screw (3).
8. Remove the Switch PCB Ass'y.
9. Remove the screw (4).
10. Remove the Gear Feed.
11. Remove the 2 screws (5).
12. Remove the Feed Motor.
13. Remove the Gear Motor.



# DISASSEMBLY INSTRUCTIONS

## NOTE

1. When installing the Rack Feed Ass'y, push both ends to align the teeth as shown Fig. 2-2-B. Then install it.
2. In case of the Gear Motor installation, check if the value of the Fig. 2-2-C is correct.
3. When installing the wire of the Switch PCB Ass'y, install it correctly as Fig. 2-2-D.  
Manual soldering conditions
  - Soldering temperature:  $320 \pm 20^{\circ}\text{C}$
  - Soldering time: Within 3 seconds
  - Soldering combination: Sn-3.0Ag-0.5Cu
4. After the assembly of the Traverse Ass'y, hook the wire on the Traverse Ass'y as shown Fig. 2-2-E.




Fig. 2-2-E

## 2-3: FFC WIRE HANDLING

1. When installing the FFC, fold it correctly and install it as shown from Fig. 2-3-A to Fig. 2-3-B.

## NOTE

1. Do not make the folding lines except the specified positions for the FFC.




Fig. 2-2-B




Fig. 2-2-C




Fig. 2-2-D




Fig. 2-3-A




Fig. 2-3-B

# DISASSEMBLY INSTRUCTIONS


## 3. REMOVAL AND INSTALLATION OF FLAT PACKAGE IC

### REMOVAL

1. Put Masking Tape (cotton tape) around the Flat Package IC to protect other parts from any damage. (Refer to Fig. 3-1.)

#### NOTE


Masking is carried out on all the parts located within 10 mm distance from IC leads.



2. Heat the IC leads using a blower type IC desoldering machine. (Refer to Fig. 3-2.)

#### NOTE


Do not rotate or move the IC back and forth, until IC can move back and forth easily after desoldering the leads completely.



3. When IC starts moving back and forth easily after desoldering completely, pickup the corner of the IC using tweezers and remove the IC by moving with the IC desoldering machine. (Refer to Fig. 3-3.)

#### NOTE


Some ICs on the PCB are affixed with glue, so be careful not to break or damage the foil of each IC leads or solder lands under the IC when removing it.



4. Peel off the Masking Tape.
5. Absorb the solder left on the pattern using the Braided Shield Wire. (Refer to Fig. 3-4.)

#### NOTE


Do not move the Braided Shield Wire in the vertical direction towards the IC pattern.




# DISASSEMBLY INSTRUCTIONS

## INSTALLATION

1. Take care of the polarity of new IC and then install the new IC fitting on the printed circuit pattern. Then solder each lead on the diagonal positions of IC temporarily. **(Refer to Fig. 3-5.)**




2. Supply the solder from the upper position of IC leads sliding to the lower position of the IC leads. **(Refer to Fig. 3-6.)**




3. Absorb the solder left on the lead using the Braided Shield Wire. **(Refer to Fig. 3-7.)**

### NOTE

Do not absorb the solder to excess.



4. When bridge-soldering between terminals and/or the soldering amount are not enough, resolder using a Thin-tip Soldering Iron. **(Refer to Fig. 3-8.)**



5. Finally, confirm the soldering status on four sides of the IC using a magnifying glass. Confirm that no abnormality is found on the soldering position and installation position of the parts around the IC. If some abnormality is found, correct by resoldering.

### NOTE

When the IC leads are bent during soldering and/or repairing, do not repair the bending of leads. If the bending of leads are repaired, the pattern may be damaged. So, always be sure to replace the IC in this case.

## SERVICE MODE LIST


This unit provided with the following SERVICE MODES so you can repair, examine and adjust easily.

To enter to the SERVICE MODE function, press and hold both buttons simultaneously on the main unit and on the remote control for more than a the standard time in the appropriate condition. (See below chart.)

Set Condition	Set Key	Remocon Key	Standard Time	Operations
TV mode	VOL. DOWN (Minimum)	1	2 sec.	Initialization of factory TV data. NOTE: If you set factory initialization, the memories are reset such as the channel setting, and the POWER ON total hours.
TV mode	VOL. DOWN (Minimum)	2	2 sec.	Check of the SUM DATA and MICON VERSION on the screen. Refer to the "WHEN REPLACING EEPROM (MEMORY) IC".
DVD mode (No disc)	VOL. DOWN (Minimum)	4	2 sec.	Initialization of factory DVD data.
DVD mode (No disc)	VOL. DOWN (Minimum)	5	2 sec.	DVD Write mode. Refer to the "RE-WRITE FOR DVD FIRMWARE".
TV mode	VOL. DOWN (Minimum)	6	2 sec.	POWER ON total hours are displayed on the screen. Can be checked of the INITIAL DATA of MEMORY IC. Refer to the "WHEN REPLACING EEPROM (MEMORY) IC".
ALL mode	VOL. DOWN (Minimum)	9	2 sec.	Display of the Adjustment MENU on the screen. Refer to the "ELECTRICAL ADJUSTMENT" (On-Screen Display Adjustment).
DVD mode (No disc)	STOP	1	2 sec.	Region setting. Refer to the "RE-WRITE FOR DVD FIRMWARE".
DVD mode (No disc)	STOP	7	2 sec.	Releasing of PARENTAL LOCK. Refer to the "PARENTAL CONTROL - RATING LEVEL".

Method	
Press the following remocon keys continuously. SETUP → SUBTITLE → 3 → AUDIO SELECT → 0	The disk cannot be taken out. Refer to the "TRAY LOCK".

## SERVICING FIXTURES AND TOOLS



Ref. No.	Part No.	Parts Name	Remarks
JG176	APJG176142	Up-Date Disc	Up-Date of the Firmware

## RE-WRITE FOR DVD FIRMWARE

1. Turn on the power, and set the DVD mode.
2. Confirm that the "No Disc" will be appeared on the screen.
3. Press both VOL. DOWN button on the set and Channel button (5) on the remote control for more than 2 seconds.
4. Press VOL. UP/DOWN button on the unit to check if all the keys on the unit do not function.  
**NOTE: To check if DVD Write mode is set.**  
**When inserting Up-Date Disc at Non DVD Write mode, the read error will happen.**

5. Insert the Up-Date Disc. (Refer to **SERVICING FIXTURE AND TOOLS**)
6. Automatic read will start and "Firmware upgrade Please Wait" will be displayed on the screen. At this time, the horizontal noise lines may appear. But no problem.  
**NOTE: Do not turn off the unit on the way or operate the keys on the unit and remocon.**  
**Up-Date error will happen and can not be done with the Up-Date of Up-Date Disc.**


7. After the Up-Date, Logo screen will appear.
8. Unplug the AC cord, then plug it in.

### After the write, set to the initializing of shipping.

9. Turn on the power, and set the DVD mode.
10. Press both VOL. DOWN button on the set and Channel button (4) on the remote control for more than 2 seconds. The "INITIALIZE 5 ---> COMPLETE" will appear on the screen.
11. Then unplug the AC cord, and plug it in.

### CHECK FOR THE FIRMWARE VERSION

12. Turn on the power, and set the DVD mode.
13. Press both Channel button (1) on the remote control and the STOP button on the set for more than 2 seconds. Firmware version will be displayed on the top left of the screen.



When the changed version displays, the Re-write will be completed.

A D L S X 8 3 2 7 A  
 Fixed Released times on the same date  
 Release date (Example: 2008.3.27)

A = October  
 B = November  
 C = December

14. Turn off the power



## WHEN REPLACING EEPROM (MEMORY) IC

### CONFIRMATION OF CHECK SUM, POWER ON TOTAL HOURS AND MICON VERSION

Initial total of MEMORY IC, POWER ON total hours and MICON VERSION can be checked on the screen. Total hours are displayed in 16 system of notation.

**NOTE: If you set a factory initialization, the total hours is reset to "0".**

**Please refer to "CONFIRMATION OF INITIAL DATA" when SUM DATA is not corresponding.**

1. Turn on the POWER, and set to the TV mode.
2. Set the VOLUME to minimum.
3. Press both VOL. DOWN button on the set and Channel button **(2)** on the remote control for more than 2 seconds.
4. After the confirmation of each check sum, turn off the power.

NOTE: The each item value might be different according to each set.




FIG. 1

### CONFIRMATION OF INITIAL DATA

If a service repair is undertaken where it has been required to change the MEMORY IC, the following steps should be taken to ensure correct data settings while making reference to INITIAL SETTING TABLE (Attached "INITIAL DATA").

1. Turn on the POWER, and set to the TV mode.
2. Set the VOLUME to minimum.
3. Press both VOL. DOWN button on the set and Channel button **(6)** on the remote control for more than 2 seconds. ADDRESS and DATA should appear as FIG 2.

NOTE: No need to set data other position than 0D00~0E3F and 1900~7FFF

	ADDRESS	DATA
INIT	0000	00
LCD ON		0000
ANALOG M :	DB180_	80424A
ANALOG S :	DB0F0_	70821B

FIG. 2

4. ADDRESS is now selected and should "blink". Using the UP/DOWN button on the remote, step through the ADDRESS until required ADDRESS to be changed is reached.
5. Press RIGHT/LEFT button to select DATA. When DATA is selected, it will "blink".
6. Again, step through the DATA using UP/DOWN button until required DATA value has been selected.
7. Pressing RIGHT/LEFT button will take you back to ADDRESS for further selection if necessary.
8. Repeat steps 4 to 6 until all data has been checked.
9. When satisfied correct DATA has been entered, turn POWER off (return to STANDBY MODE) to finish DATA input.

**After the data input, set to the initializing of shipping.**

10. Turn on the POWER.
  11. Set the VOLUME to minimum.
  12. Press both VOL. DOWN button on the set and Channel button **(1)** on the remote control for more than 2 seconds.
  13. After the finishing of the initializing of shipping, the unit will turn off automatically.
- The unit will now have the correct DATA for the new MEMORY IC.

# ELECTRICAL ADJUSTMENTS

## 1. ADJUSTMENT PROCEDURE

Read and perform these adjustments when repairing the circuits or replacing electrical parts or PCB assemblies.

### CAUTION


- Use an isolation transformer when performing any service on this chassis.
- When removing a PCB or related component, after unfastening or changing a wire, be sure to put the wire back in its original position.
- When you exchange IC and Transistor with a heat sink, apply silicon grease on the contact section of the heat sink. Before applying new silicon grease, remove all the old silicon grease. (Old grease may cause damage to the IC and Transistor).

Prepare the following measurement tools for electrical adjustments.

1. Pattern Generator

### On-Screen Display Adjustment

1. Set the VOLUME to minimum.
2. Press the VOL. DOWN button on the set and the channel button (9) on the remote control for more than 2 seconds to display adjustment mode on the screen as shown in Fig. 1-1.



3. Use the PAGE UP/DOWN button or Channel button (0-9) on the remote control to select the options shown in Fig. 1-2.
4. Press the MENU button on the remote control to end the adjustments.
5. To display the adjustment screen for TUNER, AV and DVD mode, press the INPUT button on the remote control to set to the TUNER, AV and DVD mode.
6. Press the VOL.DOWN button on the set and the channel (9) on the remote control for more than 2 seconds.

NO.	FUNCTION	NO.	FUNCTION
01	OSD H POSI	24	V POSI
02	OSD V POSI	25	V POSI MAX
03	R DRIVE(N)	26	V POSI MIN
04	R CUTOFF(N)	27	BACKLIGHT CENTER
05	G DRIVE(N)	28	BACKLIGHT MAX
06	G CUTOFF(N)	29	BACKLIGHT MIN
07	B DRIVE(N)	30	BRIGHT CENTER
08	B CUTOFF(N)	31	BRIGHT MAX
09	R DRIVE(C)	32	BRIGHT MIN
10	R CUTOFF(C)	33	TINT CENTER
11	G DRIVE(C)	34	CONTRAST CENTER
12	G CUTOFF(C)	35	CONTRAST MAX
13	B DRIVE(C)	36	CONTRAST MIN
14	B CUTOFF(C)	37	CONTRAST 40
15	R DRIVE(W)	38	COLOR CENTER
16	R CUTOFF(W)	39	COLOR MAX
17	G DRIVE(W)	40	COLOR MIN
18	G CUTOFF(W)	41	TEXT H POSI
19	B DRIVE(W)	42	TEXT V POSI
20	B CUTOFF(W)	43	FLICKER ADJ
21	H POSI		
22	H POSI MAX		
23	H POSI MIN		

Fig. 1-2

## 2. BASIC ADJUSTMENTS

### 2-1: WHITE BALANCE

1. Place the set in Aging Test for more than 15 minutes.
2. Receive the gray scale pattern from the Pattern Generator.
3. Press the INPUT button on the remote control to set to the AV mode.
4. Using the remote control, set the brightness and contrast to normal position.
5. Activate the adjustment mode display of Fig. 1-1 and press the channel button (03) on the remote control to select "R DRIVE(N)".
6. Press the PAGE UP/DOWN button on the remote control to select the "R DRIVE(N)", "R CUTOFF(N)", "B DRIVE(N)", "B CUTOFF(N)", "R DRIVE(C)", "R CUTOFF(C)", "B DRIVE(C)", "B CUTOFF(C)", "R DRIVE(W)", "R CUTOFF(W)", "B DRIVE(W)" or "B CUTOFF(W)".
7. Adjust the LEFT/RIGHT button on the remote control to whiten the R DRIVE(N), R CUTOFF(N), B DRIVE(N), B CUTOFF(N), R DRIVE(C), R CUTOFF(C), B DRIVE(C), B CUTOFF(C), R DRIVE(W), R CUTOFF(W), B DRIVE(W) and B CUTOFF(W) at each step tone sections equally.
8. Perform the above adjustments 6 and 7 until the white achieved.

# ELECTRICAL ADJUSTMENTS

## 2-2: CONTRAST MAX

1. Receive the monoscope pattern. (RF Input)
2. Using the remote control, set the brightness and contrast to normal position.
3. Activate the adjustment mode display of **Fig. 1-1** and press the channel button **(35)** on the remote control to select "CONTRAST MAX".
4. Press the LEFT/RIGHT button on the remote control until the contrast step No. becomes "48"
5. Check if the picture is normal.
6. Receive the monoscope pattern. (VIDEO Input)
7. Press the INPUT button on the remote control to set to the AV mode.
8. Using the remote control, set the brightness and contrast to normal position.
9. Activate the adjustment mode display of **Fig. 1-1** and press the channel button **(35)** on the remote control to select "CONTRAST MAX".
10. Press the LEFT/RIGHT button on the remote control until the contrast step No. becomes "42".
11. Check if the picture is normal.
12. Playback the DVD(480i) disc.
13. Press the INPUT button on the remote control to set to the DVD mode.
14. Using the remote control, set the brightness and contrast to normal position.
15. Activate the adjustment mode display of **Fig. 1-1** and press the channel button **(35)** on the remote control to select "CONTRAST MAX".
16. Press the LEFT/RIGHT button on the remote control until the contrast step No. becomes "41".
17. Check if the picture is normal.

# ELECTRICAL ADJUSTMENTS

## 2-3: Confirmation of Fixed Value (Step No.)

Please check if the fixed values of each of the adjustment item is set correctly referring below. (TUNER/AV/DVD)

NO.	FUNCTION	TUNER	AV			DVD
			CVBS	S(Y/C)	RGB	
		STEP NO.				
1	OSD H POSI	140	140	140	140	75
2	OSD V POSI	7	7	7	7	31
3	R DRIVE(N)	*	*	*	*	*
4	R CUT OFF(N)	*	*	*	*	*
5	G DRIVE(N)	890	890	890	890	890
6	G CUT OFF(N)	0	0	0	0	0
7	B DRIVE(N)	*	*	*	*	*
8	B CUTOFF(N)	*	*	*	*	*
9	R DRIVE(C)	*	*	*	*	*
10	R CUT OFF(C)	*	*	*	*	*
11	G DRIVE(C)	890	890	890	890	890
12	G CUT OFF(C)	0	0	0	0	0
13	B DRIVE(C)	*	*	*	*	*
14	B CUTOFF(C)	*	*	*	*	*
15	R DRIVE(W)	*	*	*	*	*
16	R CUT OFF(W)	*	*	*	*	*
17	G DRIVE(W)	890	890	890	890	890
18	G CUT OFF(W)	0	0	0	0	0
19	B DRIVE(W)	*	*	*	*	*
20	B CUTOFF(W)	*	*	*	*	*
21	H POSI 50Hz 4:3/14:9/Full_S	634	634	634	642	646
	H POSI 50Hz 4:3/14:9/Full_S SECAM	638	638	638	642	-
	H POSI 50Hz 16:9	704	704	704	712	710
	H POSI 50Hz 16:9 SECAM	708	708	708	710	-
	H POSI 50Hz CINEMA	766	766	766	772	772
	H POSI 50Hz CINEMA SECAM	768	768	768	770	-
	H POSI 60Hz 4:3/14:9/Full_S	580	580	580	572	570
	H POSI 60Hz 16:9	650	650	650	642	642
	H POSI 60Hz CINEMA	706	706	706	700	692
	H POSI PC 4:3	-	-	-	-	-
H POSI PC 16:9	-	-	-	-	-	
22	H POSI MAX (PC)	-	-	-	-	-
23	H POSI MIN (PC)	-	-	-	-	-
24	V POSI 50Hz 4:3/16:9	27	27	27	25	27
	V POSI 50Hz FULL SCREEN	27	27	27	25	26
	V POSI 50Hz Cinema	61	61	61	59	60
	V POSI 50Hz 14:9	45	45	45	43	44
	V POSI 60Hz 4:3/16:9	20	20	20	16	18
	V POSI 60Hz FULL SCREEN	20	20	20	16	18
	V POSI 60Hz Cinema	50	50	50	31	48
	V POSI 60Hz 14:9	36	36	36	31	35
	V POSI PC	-	-	-	-	-
25	V POSI MAX 50Hz CINEMA	-	-	-	-	-
	V POSI MAX 60Hz CINEMA	-	-	-	-	-
	V POSI MAX PC	-	-	-	-	-
26	V POSI MIN 50Hz CINEMA	-	-	-	-	-
	V POSI MIN 60Hz CINEMA	-	-	-	-	-
	V POSI MIN PC	-	-	-	-	-
27	BACKLIGHT CENTER	100	100	100	100	100
28	BACKLIGHT MAX	155	155	155	155	155
29	BACKLIGHT MIN	40	40	40	40	40
30	BRIGHT CENTER	+	+	+	+	-5
31	BRIGHT MAX	+	+	+	+	70
32	BRIGHT MIN	+	+	+	+	-64
33	TINT CENTER	+	+	+	+	-9
34	CONTRAST CENTER	+	+	+	+	*
35	CONTRAST MAX	+	+	+	+	*
36	CONTRAST MIN	+	+	+	+	18
37	CONTRAST 40	+	+	+	+	*
38	COLOR CENTER	+	+	+	+	38
39	COLOR MAX	+	+	+	+	63
40	COLOR MIN	+	+	+	+	0
41	TEXT H POSI	0	0	0	0	190
42	TEXT V POSI	0	0	0	0	7

**NOTE:** For the step no. with \* mark, please adjust it according to the situation of the set.

**NOTE:** For the step no. with + mark, please adjust it according to the 2-4.

## ELECTRICAL ADJUSTMENTS

**2-4: Confirmation of Fixed Value (Step No.)**


Please check if the fixed values of each of the adjustment item is set correctly referring below. (TUNER/AV)

NO.	FUNCTION	TUNER			AV1(SCART1)					AV2(RCA)					AV2(RCA)					AV1(SCART1)									
		576i			576i			480i		576i			480i		S(Y/C)			576i			480i		RGB						
		PAL50	PAL60	SECAM	PAL50	PAL60	SECAM	NTSC3.58	NTSC4.43	PAL50	PAL60	SECAM	NTSC3.58	NTSC4.43	PAL50	PAL60	SECAM	NTSC3.58	NTSC4.43	PAL50	PAL60	SECAM	NTSC3.58	NTSC4.43	PAL50	PAL60	SECAM	NTSC3.58	NTSC4.43
		STEP No.																											
30	BRIGHT CENTER	6	6	6	6	6	6	6	6	6	6	6	6	6	6	6	6	6	6	6	6	6	6	6	6	6	6		
31	BRIGHT MAX	50	50	50	50	50	50	50	50	50	50	50	50	50	50	50	50	50	50	50	50	50	50	50	50	50	50		
32	BRIGHT MIN	-80	-80	-80	-80	-80	-80	-80	-80	-80	-80	-80	-80	-80	-80	-80	-80	-80	-80	-80	-80	-80	-80	-80	-80	-80	-80		
33	TINT CENTER	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0		
34	CONTRAST CENTER	*	*	*	*	*	*	*	*	*	*	*	*	*	*	*	*	*	*	*	*	*	*	*	*	*	*		
35	CONTRAST MAX	*	*	*	*	*	*	*	*	*	*	*	*	*	*	*	*	*	*	*	*	*	*	*	*	*	*		
36	CONTRAST MIN	18	18	18	18	18	18	18	18	18	18	18	18	18	18	18	18	18	18	18	18	18	18	18	18	18	18		
37	CONTRAST 50	*	*	*	*	*	*	*	*	*	*	*	*	*	*	*	*	*	*	*	*	*	*	*	*	*	*		
38	COLOR CENTER	40	40	40	40	40	40	40	40	40	40	40	40	40	40	40	40	40	40	40	40	40	40	40	40	40	40		
39	COLOR MAX	63	63	63	63	63	63	63	63	63	63	63	63	63	63	63	63	63	63	63	63	63	63	63	63	63	63		
40	COLOR MIN	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0		

NOTE: For the step no. with \* mark, please adjust it according to the situation of the set.


# ELECTRICAL ADJUSTMENTS

## 3. ELECTRICAL ADJUSTMENT PARTS LOCATION GUIDE (WIRING CONNECTION)




# TROUBLESHOOTING GUIDE

## (LCD SECTION)




# TROUBLESHOOTING GUIDE






# TROUBLESHOOTING GUIDE




# TROUBLESHOOTING GUIDE




# TROUBLESHOOTING GUIDE


## (DVD SECTION)




# TROUBLESHOOTING GUIDE




# TROUBLESHOOTING GUIDE




# TROUBLESHOOTING GUIDE



# TROUBLESHOOTING GUIDE




# DVD BLOCK DIAGRAM







## POWER BLOCK DIAGRAM




## 21PIN/TUNER /SOUND AMP BLOCK DIAGRAM



# REGULATOR BLOCK DIAGRAM




# SCALER/SUB MICON/DVD\_INTERFACE/AV\_SWITCH BLOCK DIAGRAM






# PRINTED CIRCUIT BOARDS MAIN/TUNER (TOP SIDE)




# PRINTED CIRCUIT BOARDS MAIN/TUNER (BOTTOM SIDE)








**PRINTED CIRCUIT BOARDS  
POWER/OPERATION/REMOCON (CHIP MOUNTED PARTS)  
SOLDER SIDE**



# MPEG/MICON/DSP/RF\_AMP SCHEMATIC DIAGRAM (DVD MT PCB)




NOTE: THIS SCHEMATIC DIAGRAM IS THE LATEST AT THE TIME OF PRINTING AND SUBJECT TO CHANGE WITHOUT NOTICE.

NOTE: THE DC VOLTAGE EACH PART WAS MEASURED WITH THE DIGITAL TESTER DURING PLAYBACK.

PCB130  
DMG297

# MEMORY SCHEMATIC DIAGRAM (DVD MT PCB)




NOTE: THIS SCHEMATIC DIAGRAM IS THE LATEST AT THE TIME OF PRINTING AND SUBJECT TO CHANGE WITHOUT NOTICE.

NOTE: THE DC VOLTAGE EACH PART WAS MEASURED WITH THE DIGITAL TESTER DURING PLAYBACK.

PCB130  
DMG097

# MOTOR DRIVE SCHEMATIC DIAGRAM (DVD MT PCB)



**CAUTION** SINCE THESE PARTS MARKED BY ARE CRITICAL FOR SAFETY, USE ONES DESCRIBED IN PARTS LIST ONLY.

**ATTENTION** LES PIÈCES REPARÉES PAR UN ÉTANT DANGEREUSES AN POINT DE VUE SÉCURITÉ, UTILISER QUE CELLES DÉCRITES DANS LA NOMENCLATURE DES PIÈCES.


NOTE: THIS SCHEMATIC DIAGRAM IS THE LATEST AT THE TIME OF PRINTING AND SUBJECT TO CHANGE WITHOUT NOTICE.

NOTE: THE DC VOLTAGE EACH PART WAS MEASURED WITH THE DIGITAL TESTER DURING PLAYBACK.

PCB130  
DMG097

# AUDIO/VIDEO SCHEMATIC DIAGRAM

## (DVD MT PCB)



NOTE: THIS SCHEMATIC DIAGRAM IS THE LATEST AT THE TIME OF PRINTING AND SUBJECT TO CHANGE WITHOUT NOTICE.


NOTE: THE DC VOLTAGE EACH PART WAS MEASURED WITH THE DIGITAL TESTER DURING PLAYBACK.

**CAUTION** SINCE THESE PARTS MARKED BY ARE CRITICAL FOR SAFETY, USE ONES DESCRIBED IN PARTS LIST ONLY.

**ATTENTION** LES PIÈCES RÉPARÉES PAR UN ÉTANT DANGEREUSES AN POINT DE VUE SÉCURITÉ N'UTILISER QUE CELLES DÉCRITES DANS LA NOMENCLATURE DES PIÈCES.

PCB130  
DMG097

# 21PIN SCHEMATIC DIAGRAM (MAIN PCB)





NOTE: THIS SCHEMATIC DIAGRAM IS THE LATEST AT THE TIME OF PRINTING AND SUBJECT TO CHANGE WITHOUT NOTICE.


NOTE: THE DC VOLTAGE AT EACH PART WAS MEASURED WITH THE DIGITAL TESTER WHEN THE COLOR BROADCAST WAS RECEIVED IN GOOD CONDITION AND PICTURE IS NORMAL.

CAUTION: DIGITAL TRANSISTOR

CAUTION: DIGITAL TRANSISTOR



# REGULATOR SCHEMATIC DIAGRAM (MAIN PCB)




NOTE: THIS SCHEMATIC DIAGRAM IS THE LATEST AT THE TIME OF PRINTING AND SUBJECT TO CHANGE WITHOUT NOTICE.

NOTE: THE DC VOLTAGE AT EACH PART WAS MEASURED WITH THE DIGITAL TESTER WHEN THE COLOR BROADCAST WAS RECEIVED IN GOOD CONDITION AND PICTURE IS NORMAL.

**CAUTION** SINCE THESE PARTS MARKED BY ARE CRITICAL FOR SAFETY, USE ONES DESCRIBED IN PARTS LIST ONLY.

**ATTENTION** LES PIÈCES RÉPARÉES PAR UN ÉTANT DANGEREUSES AN POINT DE VUE SÉCURITÉ, N'UTILISER QUE CELLES DÉCRITES DANS LA NOMENCLATURE DES PIÈCES.

CAUTION: DIGITAL TRANSISTOR




PCBF 40  
CMG130

# REGULATOR2 SCHEMATIC DIAGRAM (MAIN PCB)

FROM/TO REGULATOR

AT+3.3V  
AT+5.8V  
GND



FROM/TO SCALER

GND  
AT+1.8V\_1  
AT+1.8V\_2  
AT+3.3V  
SYS\_POWER\_H

FROM/TO JACK

GND

TO SOUND AMP MUTE

P.CON+3.3V  
AT+3.3V

TO TUNER

P.CON+3.3V

TO SUB MICON

P.CON+3.3V  
GND

PCBF 40  
CMG130

**CAUTION** SINCE THESE PARTS MARKED BY ARE CRITICAL FOR SAFETY USE ONES DESCRIBED IN PARTS LIST ONLY.

**ATTENTION** LES PIÈCES RÉPARÉES PAR UN ÉTANT DANGEREUSES AN POINT DE VUE SECURITE N'UTILISER QUE CELLES DÉCRITES DANS LA NOMENCLATURE DES PIÈCES.



NOTE: THE DC VOLTAGE AT EACH PART WAS MEASURED WITH THE DIGITAL TESTER WHEN THE COLOR BROADCAST WAS RECEIVED IN GOOD CONDITION AND PICTURE IS NORMAL.

NOTE: THIS SCHEMATIC DIAGRAM IS THE LATEST AT THE TIME OF PRINTING AND SUBJECT TO CHANGE WITHOUT NOTICE.



# AV SWITCH SCHEMATIC DIAGRAM

(MAIN PCB)




NOTE: THE DC VOLTAGE AT EACH PART WAS MEASURED WITH THE DIGITAL TESTER WHEN THE COLOR BROADCAST WAS RECEIVED IN GOOD CONDITION AND PICTURE IS NORMAL.

NOTE: THIS SCHEMATIC DIAGRAM IS THE LATEST AT THE TIME OF PRINTING AND SUBJECT TO CHANGE WITHOUT NOTICE.

PCBF 40  
CMG130

# SOUND AMP MUTE SCHEMATIC DIAGRAM

(MAIN PCB)




PCBF 40  
CMG130


NOTE: THIS SCHEMATIC DIAGRAM IS THE LATEST AT THE TIME OF PRINTING AND SUBJECT TO CHANGE WITHOUT NOTICE.

NOTE: THE DC VOLTAGE AT EACH PART WAS MEASURED WITH THE DIGITAL TESTER WHEN THE COLOR BROADCAST WAS RECEIVED IN GOOD CONDITION AND PICTURE IS NORMAL.


CAUTION: DIGITAL TRANSISTOR



CAUTION: DIGITAL TRANSISTOR



# TUNER SCHEMATIC DIAGRAM (MAIN PCB)



**CAUTION** SINCE THESE PARTS MARKED BY ARE CRITICAL FOR SAFETY USE ONES DESCRIBED IN PARTS LIST ONLY.


**ATTENTION** LES PIÈCES RÉPARÉES PAR UN ÉTANT DANGEREUSES AN POINT DE VUE SECURITE N'UTILISER QUE CELLES DÉCRITES DANS LA NOMENCLATURE DES PIÈCES.

NOTE: THIS SCHEMATIC DIAGRAM IS THE LATEST AT THE TIME OF PRINTING AND SUBJECT TO CHANGE WITHOUT NOTICE.

NOTE: THE DC VOLTAGE AT EACH PART WAS MEASURED WITH THE DIGITAL TESTER WHEN THE COLOR BROADCAST WAS RECEIVED IN GOOD CONDITION AND PICTURE IS NORMAL.



# SUB MICON SCHEMATIC DIAGRAM (MAIN PCB)



FROM TO SCALER

FROM TO DVD\_INTERFACE/AV\_SWITC

TO 21PIN

FROM TO TUNER

TO SOUND\_AMP MUTE

FROM REGULATOR2

TO PANEL\_INTERFACE


CP101	A2001WW-7A
GND	1
SUB_TX	2
MODE	3
P.CON-3.3V	4
SUB_RX	5
RESET	6
NC	7

NOTE: THE DC VOLTAGE AT EACH PART WAS MEASURED WITH THE DIGITAL TESTER WHEN THE COLOR BROADCAST WAS RECEIVED IN GOOD CONDITION AND PICTURE IS NORMAL.

NOTE: THIS SCHEMATIC DIAGRAM IS THE LATEST AT THE TIME OF PRINTING AND SUBJECT TO CHANGE WITHOUT NOTICE.

PCBF 40  
CMG130

# JACK SCHEMATIC DIAGRAM (MAIN PCB)




NOTE: THE DC VOLTAGE AT EACH PART WAS MEASURED WITH THE DIGITAL TESTER WHEN THE COLOR BROADCAST WAS RECEIVED IN GOOD CONDITION AND PICTURE IS NORMAL.

NOTE: THIS SCHEMATIC DIAGRAM IS THE LATEST AT THE TIME OF PRINTING AND SUBJECT TO CHANGE WITHOUT NOTICE.

CAUTION: DIGITAL TRANSISTOR



CAUTION: DIGITAL TRANSISTOR



PCBF 40  
CMG130

# DVD\_INTERFACE/AV\_SWITCH SCHEMATIC DIAGRAM (MAIN PCB)

### FROM TO REGULATOR

- GND
- P.CON+9V
- MOTOR\_CNB
- P.CON+12V
- P.CON+5V\_DVB
- MOTOR+6V
- P.CON+3.3V\_DVD

### FROM TO AUDIO/VIDEO

- CP6501 (CP8501, CP8502)  
A2009WV0-2X11P
- |    |             |
|----|-------------|
| 1  | SPOIF-134   |
| 2  | ZERO        |
| 3  | GND         |
| 4  | DVD_RESET   |
| 5  | GND         |
| 6  | START_SW    |
| 7  | TX          |
| 8  | GND         |
| 9  | P.CON+3.3V  |
| 10 | GND         |
| 11 | P.CON+6V    |
| 12 | GND         |
| 13 | DVD_A_OUT_R |
| 14 | DVD_A_OUT_L |
| 15 | I/Y_VIDEO   |
| 16 | I/U/C_VIDEO |
| 17 | GND         |
| 18 | RX          |
| 19 | P.CON+3.3V  |
| 20 | P.CON+12V   |
| 21 | P.CON+6V    |
| 22 | GND(M)      |


← CD4501\_1  
E82M1601

### FROM AV SWITCH

- VIDEO\_A\_L
- VIDEO\_A\_R
- S\_JACK\_G
- S\_JACK\_Y

### FROM SUB MICON

- DVD/AUDIO
- DVD\_RESET
- DVD\_RX
- DVD\_TX




PCBF40  
CMG130

NOTE: THIS SCHEMATIC DIAGRAM IS THE LATEST AT THE TIME OF PRINTING AND SUBJECT TO CHANGE WITHOUT NOTICE.

NOTE: THE DC VOLTAGE AT EACH PART WAS MEASURED WITH THE DIGITAL TESTER WHEN THE COLOR BROADCAST WAS RECEIVED IN GOOD CONDITION AND PICTURE IS NORMAL.

# PANEL\_INTERFACE SCHEMATIC DIAGRAM (MAIN PCB)



NOTE: THIS SCHEMATIC DIAGRAM IS THE LATEST AT THE TIME OF PRINTING AND SUBJECT TO CHANGE WITHOUT NOTICE.


NOTE: THE DC VOLTAGE AT EACH PART WAS MEASURED WITH THE DIGITAL TESTER WHEN THE COLOR BROADCAST WAS RECEIVED IN GOOD CONDITION AND PICTURE IS NORMAL.

**CAUTION** THESE PARTS MARKED BY ARE CRITICAL FOR SAFETY. USE ONES DESCRIBED IN PARTS LIST ONLY.

**ATTENTION** LES PIECES REPARÉES PAR UN ETANT DANGEREUSES AN POINT DE VUE SECURITE N'UTILISER QUE CELLS DECRITES DANS LA NOMENCLATURE DES PIECES.



# POWER SCHEMATIC DIAGRAM (POWER PCB)



NOTE: THE RESISTOR MARKED F IS FUSE RESISTOR.  
THE ALUMI ELECTROLYTIC CAPACITOR MARKED NP  
IS NON POLAR ONE.

NOTE: THIS SCHEMATIC DIAGRAM IS THE LATEST AT THE TIME  
OF PRINTING AND SUBJECT TO CHANGE WITHOUT NOTICE.

NOTE: THE DC VOLTAGE AT EACH PART WAS MEASURED  
WITH THE DIGITAL TESTER WHEN THE COLOR BROADCAST  
WAS RECEIVED IN GOOD CONDITION AND PICTURE IS NORMAL.

**CAUTION** SINCE THESE PARTS MARKED BY ⚡ ARE  
CRITICAL FOR SAFETY USE ONES  
DESCRIBED IN PARTS LIST ONLY.


**ATTENTION** LES PIÈCES RÉPARÉES PAR UN ⚡ ÉTANT  
DANGEREUSES AN POINT DE VUE SECURITE  
N'UTILISER QUE CELLS DECRITES  
DANS LA NOMENCLATURE DES PIÈCES.

FROM TO REGULATOR

S_DET	CP501 (CP3801)	1
FILTER_MUTE	127301123K2	2
POP_MUTE		3
NC		4
AT+12V	P.CON-3.3V	5
AT+12V		6
AT+5.8V		7
AT+5.8V		8
AT+5.8V		9
	P.CON-3.8V	10
	P.CON-3.8V	11
	GND	12
	GND	13
	GND	14
	GND	15
	GND	16
POWER_ON_H	DIV POWER_ON_H7	17
LIGHT_CTL	POWER_ON_H	18
INVERTER_H	LIGHT_CTL	19
POWER_FAIL	INVERTER_H	20
	POWER_FAIL	21
	NC	22
	NC	23

PCB240  
CEG373

# BACKLIGHT INVERTER SCHEMATIC DIAGRAM (POWER PCB)



NOTE: THE DC VOLTAGE AT EACH PART WAS MEASURED WITH THE DIGITAL TESTER WHEN THE COLOR BROADCAST WAS RECEIVED IN GOOD CONDITION AND PICTURE IS NORMAL.

NOTE: THIS SCHEMATIC DIAGRAM IS THE LATEST AT THE TIME OF PRINTING AND SUBJECT TO CHANGE WITHOUT NOTICE.


NOTE: THE RESISTOR MARKED F IS FUSE RESISTOR. THE ALUMI ELECTROLYTIC CAPACITOR MARKED NP IS NON POLAR ONE.

**CAUTION** SINCE THESE PARTS MARKED BY ARE CRITICAL FOR SAFETY, USE ONES DESCRIBED IN PARTS LIST ONLY.

**ATTENTION** LES PIÈCES RÉPARÉES PAR UN ÉTAIENT DANGEREUSES AU POINT DE VUE SÉCURITÉ. N'UTILISER QUE CELLES DÉCRITES DANS LA NOMENCLATURE DES PIÈCES.

PCB240  
CEG373

# SOUND AMP SCHEMATIC DIAGRAM (POWER PCB)




NOTE: THIS SCHEMATIC DIAGRAM IS THE LATEST AT THE TIME OF PRINTING AND SUBJECT TO CHANGE WITHOUT NOTICE.

NOTE: THE DC VOLTAGE AT EACH PART WAS MEASURED WITH THE DIGITAL TESTER WHEN THE COLOR BROADCAST WAS RECEIVED IN GOOD CONDITION AND PICTURE IS NORMAL.

**CAUTION** SINCE THESE PARTS MARKED BY ARE CRITICAL FOR SAFETY, USE ONES DESCRIBED IN PARTS LIST ONLY.

**ATTENTION** LES PIÈCES RÉPARÉES PAR UN ÉTANT DANGEREUSES AN POINT DE VUE SÉCURITÉ N'UTILISER QUE CELLES DÉCRITES DANS LA NOMENCLATURE DES PIÈCES

CAUTION: DIGITAL TRANSISTOR




PCB240  
CEG373

# JACK\_OUT SCHEMATIC DIAGRAM (POWER PCB)

FROM TO AV SWITCH


CP8101 (CP4300)  
127501123K2




B1004  
FCW000000F131106

JACK\_GND


FROM POWER





FROM TO SOUND AMP



(OPERATION PCB)



(REMOCON PCB)




NOTE: THIS SCHEMATIC DIAGRAM IS THE LATEST AT THE TIME OF PRINTING AND SUBJECT TO CHANGE WITHOUT NOTICE.

NOTE: THE DC VOLTAGE AT EACH PART WAS MEASURED WITH THE DIGITAL TESTER WHEN THE COLOR BROADCAST WAS RECEIVED IN GOOD CONDITION AND PICTURE IS NORMAL.

PCB240  
CEG375

# SW SCHEMATIC DIAGRAM

(SW PCB)




**CAUTION** SINCE THESE PARTS MARKED BY ARE CRITICAL FOR SAFETY USE ONES DESCRIBED IN PARTS LIST ONLY

**ATTENTION** LES PIÈCES RÉPARÉES PAR UN ÉTANT DANGEREUSES AN POINT DE VUE SECURITE. N'UTILISER QUE CELLES DECRITES DANS LA NOMENCLATURE DES PIÈCES

NOTE: THIS SCHEMATIC DIAGRAM IS THE LATEST AT THE TIME OF PRINTING AND SUBJECT TO CHANGE WITHOUT NOTICE.

# INTERCONNECTION DIAGRAM




NOTE: THE DC VOLTAGE AT EACH PART WAS MEASURED WITH THE DIGITAL TESTER WHEN THE COLOR BROADCAST WAS RECEIVED IN GOOD CONDITION AND PICTURE IS NORMAL.

**CAUTION** SINCE THESE PARTS MARKED BY ARE CRITICAL FOR SAFETY USE ONES DESCRIBED IN PARTS LIST ONLY.


**ATTENTION** LES PIECES REPARÉES PAR UN ETANT DANGEREUSES AN POINT DE VUE SECURITE N'UTILISER QUE CELLS DECRITES DANS LA NOMENCLATURE DES PIECES.

# WAVEFORMS


**21PIN**




**AV SWITCH**




**SCALER**




**2**




**SOUND AMP MUTE**




**26**




**3**




**21**




**MPEG/MICON/DSP/RF\_AMP**




**4**




**SOUND AMP**




**53**




**5**




**23**




**54**




**6**



**SCALER**







**MEMORY**



**NOTE:** The following waveforms were measured at the point of the corresponding balloon number in the schematic diagram.

# WAVEFORMS


## AUDIO/VIDEO




**NOTE:** The following waveforms were measured at the point of the corresponding balloon number in the schematic diagram.




# MECHANICAL EXPLODED VIEW



# MECHANICAL EXPLODED VIEW (PACKING DIAGRAM)



# DVD DECK EXPLODED VIEW



Do not replace the parts. Because, minute adjustments are needed if this condition is disassembled further more. If the repair is needed, replace the DVD MECHA ASS'Y.

CLASS	MARK
GREASE	AA

**NOTE:** Applying positions AA for the grease are displayed for this section. Check if the correct grease is applied for each position.

# MECHANICAL REPLACEMENT PARTS LIST

Location No.	TSB P/N	Reference No.	Description
101	AE009750	7A708A009A	FRONT CABI ASS'Y
101A	AE009751	702WNAA007	SHEET SPEAKER
101B	AE009752	708WPDA008	CABINET FRONT
101C	AE009571	713WPAA280	GLASS LED
101D	AE007694	7235490068	BADGE BRAND
101E	AE009572	761WPAA177	COVER STAND
101F	AE009671	800WQ0A073	FELT SHEET
102	AE009753	7A702A545A	BACK CABI ASS'Y
102A	AE009754	702WPAB214	CABINET BACK
102B	AE009577	761WSAA102	ANGLE HINGE
102C	75003893	800WQ0A080	FELT SHEET
102D	AE007708	800WQ00095	FELT SHEET
103	AE009755	7A704A087A	STAND ASS'Y
103A	AE009585	704WPAA066	STAND
103B	AE009586	761WPAA181	COVER HINGE
103C	AE009756	761WSAA116	FRAME STAND
103D	AE009587	761WSBA014	ANGLE STAND
103E	AE009624	800SRA0002	CUSHION LEG VEB1349-A
103F	AE008947	899NAGCL14	CABLE CLAMP
103G	AE007710	89900FB118	BAND
104	AE009757	7A711A071A	PANEL SIDE ASS'Y
104A	AE009758	711WPDA781	PANEL SIDE
104B	AE009581	711WPEA001	SLOT DVD
104C	AE009582	735WPAB101	BUTTON FRAME
104D	AE008459	800WQ00105	FELT SHEET
105	AE009589	761WSA0628	ANGLE MPEG
106	AE009759	702WPAB215	COVER BACK
107	75006982	706WPAA007	COVER CONNECTOR
108	AE009760	722549A727	SHEET RATING
109	AE009761	723000D845	SHEET JACK-1
110	AE009762	723000D846	SHEET JACK-2
111	AE009814	723549A092	POP LABEL
112	AE009745	724WNAA034	SHEET PC
113	AE009815	724WNAA036	SHEET PC
114	AE008287	726000A139	SHEET CAUTION
115	AE009597	744WUA0029	SPRING EARTH-2
116	AE009763	744WUA0035	SPRING EARTH TUNER
117	AE009816	753WUAA017	SPRING EARTH
118	AE009764	761WSAA120	ANGLE LCD-L
119	AE009765	761WSAA121	ANGLE LCD-R
120	AE009817	800WFAA042	CUSHION 30*15*T4
121	AE009625	8900P3545B	RIVET
122	AE009627	899RFPC25V	HOLDER CORD
123	AE009766	723000D923	SHEET BARCODE
124	AE009767	791WHAA223	LAMIFILM BAG
125	AE009768	792WHAA254	PACKAGE TOP
126	AE009769	792WHAA255	PACKAGE BOTTOM
127	AE009770	793WCDD680	GIFT BOX
128	AE009818	JB5KD000	POLYBAG,INSTRUCTION(RED CAUTION)
129	AE009315	J2K20402A	WARRANTY CARD(TOSHIBA)
130	AE009712	J51C0107A	QUICK SET-UP SHEET
131	AE009771	J51C0121A	INSTRUCTION BOOK(R/E)
201	AE005475	8110K30A0U	SCREW TAP TITE(P) LAMI HEAD 3*10 CH
202	AE004849	8109230A0U	SCREW TAP TITE(B) BIND 3*10 CH
203	AE005140	810A14080U	SCREW WASHER(A) M4*8 CH
204	AE005675	810923060U	SCREW TAP TITE(B) BIND 3*6 CH
205	AE009612	8110K3080U	SCREW TAP TITE(P) LAMI HEAD 3*8 CH
206	AE007747	814623080U	SCREW TAP TITE(B) BIND 3*5.7+4*2.3 CH
207	AE003526	810923080U	SCREW TAP TITE(B) BIND 3*8 CH
208	AE003524	8109I30A0U	SCREW TAP TITE(B) WH7 3*10 CH
209	AE007896	810A13060U	SCREW WASHER(A) M3*6 CH
210	AE009613	8109230A0S	SCREW TAP TITE(B) BIND 3*10 BK
211	72784031	8117540A6S	SCREW TAPPING(B0) TRUSS 4*16 BK

# DVD DECK REPLACEMENT PARTS LIST

Location No.	TSB P/N	Reference No.	Description	
△ 600	AE009615	A50N01P650	DVD MECHA ASS'Y	A50N01P650
601	AE008499	92SBB0033A	LOADER SUB ASS'Y	DLM1D29-31
602	AE005815	92AAA0017A	FEED RACK ASS'Y	
603	AE003551	92P100088A	GEAR,MOTOR	
604	AE005805	92P100117A	GEAR,MIDDLE	
605	AE008500	92P200017A	INSULATOR, F	
606	AE008501	92P200018A	INSULATOR, R	
607	AE005816	92P100116A	GEAR,FEED	
608	BZ710149	800WFAA008	CUSHION C	
701	AE005817	92P700007A	SCREW,GEAR FEED	
702	AE003554	814011723U	SCREW,PAN M1.7*2.3 P3 CH	
703	AE003555	816112080U	SEMS.TAP TITE(P) PAN W10 2*8 CH	
704	AE005006	813381750U	SCREW,T-TITE(B)CAMERA PAN M1.7*5.0 P3 CH	
705	AE003557	811022080U	SCREW,TAP TITE(P) BIND 2*8 CH	
CD2001	AE009434	12C14O1602	CORD JUMPER	FFC05241600408T1-A04
CD2301	AE003558	122H062102	CORD JUMPER	2H062102
M2602	AE009616	1515T98006	MOTOR	WRF-300CA-10460A
PCB640	AE008503	A5X002C640	SW PCB ASS'Y	DED020A
SW2	AE001158	0500101036	PUSH SWITCH	ESE22MH22

# ELECTRICAL REPLACEMENT PARTS LIST

Location No.	TSB P/N	Reference No.	Description	
<b>RESISTORS</b>				
△ R503	75006901	RC31X1126J	RC	12M OHM 1W
△ R505	AE003984	R002T4330J	RC	33 OHM 1/4W
△ R509	AE009486	RC31X1125J	RC	1.2M OHM 1W
△ R510	AE005735	R63881R22J	R,FUSE	0.22 OHM 1W
△ R512	AE009709	R002T2394J	RC	390K OHM 1/2W
△ R522	AE009710	R3K78AR82J	R,METAL OXIDE	0.82 OHM 2W
△ R7038	AE009711	R63882220J	R,FUSE	22 OHM 1/2W
△ R7039	AE009711	R63882220J	R,FUSE	22 OHM 1/2W
<b>CAPACITORS</b>				
C502	AE009713	E718HH151D	CE	150 UF 400V
△ C504	AE009067	E7EPF1222M	CE	2200 UF 10V
△ C506	BZ110025	P2122B224M	CMP	0.22 UF 275V ECQUL
△ C507	BZ110222	CD39E0MH3M	CC	0.0022UF 250V
△ C508	BZ110035	P2122B104M	CMP	0.1 UF 275V ECQUL
△ C510	AD301026	CD39E0M13M	CC	0.001 UF 250V
C512	AE009714	E8E175221M	CE	220 UF 50V
△ C513	BZ110176	C03L0R7Q2K	CC	470 PF 2KV R
△ C514	AE009491	CD39E0MQ2K	CC	470 PF 250V
△ C518	AE009492	P332E4223J	CPP	0.022 UF 400V
△ C522	AE008913	E7EYF2102M	CE	1000 UF 16V
△ C525	AE008913	E7EYF2102M	CE	1000 UF 16V
C5825	AE003825	C0JTB05E2K	CC	150 PF 500V B
C7026	AE009700	C234SLB11J	CC	10 PF 6KV SL
C7029	AE009700	C234SLB11J	CC	10 PF 6KV SL
C7030	AE009700	C234SLB11J	CC	10 PF 6KV SL
C7033	AE009700	C234SLB11J	CC	10 PF 6KV SL
<b>DIODES</b>				
D107	AE009498	DGJRT54WS0	DIODE SCHOTTKY BARRIER	BAT54WS
△ D504	AE009461	D6C047110A	DIODE VARISTA	ENE471D-10A
△ D505	AE008372	D2LT001F50	DIODE SILICON	1F5-E
D506	AE008319	D4AT01H3E0	DIODE RECTIFIER	1H3-E
△ D507	BZ410062	D2WTRM11C0	DIODE SILICON	RM11C-EIC
△ D508	BZ410062	D2WTRM11C0	DIODE SILICON	RM11C-EIC
D509	AE009494	DE7RB3302B	DIODE ZENER	UDZSNP33B TE-17
△ D510	BZ410062	D2WTRM11C0	DIODE SILICON	RM11C-EIC
△ D511	AE008319	D4AT01H3E0	DIODE RECTIFIER	1H3-E
△ D512	AE002133	D2BXARS010	DIODE SILICON	SARS01-V1
△ D514	BZ410126	D2WXRU3AM0	DIODE SILICON	RU3AM-EIC
△ D515	AE009715	D4LA0100S0	DIODE SCHOTTKY BARRIER	VF20100S
△ D516	AE008319	D4AT01H3E0	DIODE RECTIFIER	1H3-E
D517	BZ410065	D97U01601B	DIODE ZENER	MTZJ16B T-77
△ D518	BZ410062	D2WTRM11C0	DIODE SILICON	RM11C-EIC
△ D523	AE009495	D27A95T900	DIODE SCHOTTKY BARRIER	RB095T-90
D804	AE009498	DGJRT54WS0	DIODE SCHOTTKY BARRIER	BAT54WS
D805	AE009498	DGJRT54WS0	DIODE SCHOTTKY BARRIER	BAT54WS
D1001	AE009498	DGJRT54WS0	DIODE SCHOTTKY BARRIER	BAT54WS
D1002	AE009498	DGJRT54WS0	DIODE SCHOTTKY BARRIER	BAT54WS
D2303	AE009006	DGERMA1110	DIODE SILICON	MA111-(TX)
D2304	AE009006	DGERMA1110	DIODE SILICON	MA111-(TX)
D3201	AE004643	D28R1QS040	DIODE	EC31QS04-TE12L
△ D3801	AE004643	D28R1QS040	DIODE	EC31QS04-TE12L
△ D3802	AE004643	D28R1QS040	DIODE	EC31QS04-TE12L
D3804	AE008906	D28R11FS20	DIODE	EC11FS2-TE12L
△ D3805	AE004643	D28R1QS040	DIODE	EC31QS04-TE12L
△ D3806	AE008906	D28R11FS20	DIODE	EC11FS2-TE12L
D3807	AE009716	DE7RB1302B	DIODE ZENER	UDZSNP13B TE-17
D3809	AE009006	DGERMA1110	DIODE SILICON	MA111-(TX)
D4002	AE009006	DGERMA1110	DIODE SILICON	MA111-(TX)
D4003	AE009006	DGERMA1110	DIODE SILICON	MA111-(TX)
D4005	AE009006	DGERMA1110	DIODE SILICON	MA111-(TX)
D4008	AE009006	DGERMA1110	DIODE SILICON	MA111-(TX)
D4211	AE008091	DE7RB4R72B	DIODE ZENER	UDZSNP4.7B TE-17
D4305	AE009006	DGERMA1110	DIODE SILICON	MA111-(TX)
D7001	AE009006	DGERMA1110	DIODE SILICON	MA111-(TX)
D7002	BZ410006	D1VT001330	DIODE,SILICON	1SS133T-77
D7003	BZ410006	D1VT001330	DIODE,SILICON	1SS133T-77
D7004	BZ410006	D1VT001330	DIODE,SILICON	1SS133T-77
D7005	AE009006	DGERMA1110	DIODE SILICON	MA111-(TX)
D7006	BZ410006	D1VT001330	DIODE,SILICON	1SS133T-77
D7007	BZ410006	D1VT001330	DIODE,SILICON	1SS133T-77
D7008	BZ410006	D1VT001330	DIODE,SILICON	1SS133T-77
D7009	BZ410006	D1VT001330	DIODE,SILICON	1SS133T-77
D7010	BZ410006	D1VT001330	DIODE,SILICON	1SS133T-77
D7011	AE009006	DGERMA1110	DIODE SILICON	MA111-(TX)
D7012	AE009006	DGERMA1110	DIODE SILICON	MA111-(TX)
D7013	AE009006	DGERMA1110	DIODE SILICON	MA111-(TX)
D7014	AE009006	DGERMA1110	DIODE SILICON	MA111-(TX)
D7015	BZ410006	D1VT001330	DIODE,SILICON	1SS133T-77
D7016	AE009006	DGERMA1110	DIODE SILICON	MA111-(TX)
D7017	AE009006	DGERMA1110	DIODE SILICON	MA111-(TX)
D7018	BZ410006	D1VT001330	DIODE,SILICON	1SS133T-77

# ELECTRICAL REPLACEMENT PARTS LIST

Location No.	TSB P/N	Reference No.	Description	
<b>DIODES</b>				
D7019	AE009006	DGERMA1110	DIODE SILICON	MA111-(TX)
D7020	AE009006	DGERMA1110	DIODE SILICON	MA111-(TX)
D7021	AE009006	DGERMA1110	DIODE SILICON	MA111-(TX)
D7022	AE009006	DGERMA1110	DIODE SILICON	MA111-(TX)
D7023	AE009006	DGERMA1110	DIODE SILICON	MA111-(TX)
D7024	AE009006	DGERMA1110	DIODE SILICON	MA111-(TX)
D7025	AE009006	DGERMA1110	DIODE SILICON	MA111-(TX)
D7026	AE009006	DGERMA1110	DIODE SILICON	MA111-(TX)
D7601	AE000288	0021E9Q010	LED	LTL-1BEFJ-002A
D8510	AE009006	DGERMA1110	DIODE SILICON	MA111-(TX)
<b>ICS</b>				
IC101	AE009717	S50Y01TM01	MEMORY DATA 52PIN FLASH MICOM ROM 16K	R5F21244SNFP
IC105	79097849	I9UF032290	RESET IC 2.9V TYPE	PST3229NR
△ IC301	AE008430	I03SP20520	SOUND AMP 5W 2CH	LA42052-E
△ IC501	AE009499	ICAD055310	LOW STANDBY POWER IC CONTROL	FA5531P-A2
△ IC502	AD302211	I1KJ9A431A	VARIABLE SHUNT REGULATOR TAPE	KIA431A-AT
△ IC505	AE002809	000220002W	PHOTO COUPLER	PS2561AL1-1-V(W)
IC801	AE009739	S51C01BE01	MEMORY DATA EEPROM 256K 12C	AT24C256BN-10SU-1.8
IC802	79097849	I9UF032290	RESET IC 2.9V TYPE	PST3229NR
IC803	AE009718	S51C01BM01	MEMORY DATA SCALER	VCT6973G-FA-B3-000
△ IC2301	AE008194	I03FV65650	5CH MOTOR DRIVER IC	LA6565VR-TLM-E
△ IC3202	AE008435	I1LF010150	DC-DC CONVERTER CONTROLLER	AL1015
△ IC3203	AE008431	I07F078200	VARIABLE REG LOW INPUT IO=1A	BD7820FP-E2
△ IC3204	AE008431	I07F078200	VARIABLE REG LOW INPUT IO=1A	BD7820FP-E2
△ IC3205	AE004653	I1KF98D050	REGULATOR 5V	KIA78D05F
△ IC3801	AE007825	I07F0C0WF0	1A REGULATOR	BA00BC0WFP-E2
IC3803	AE008431	I07F078200	VARIABLE REG LOW INPUT IO=1A	BD7820FP-E2
△ IC3806	AE009719	I5HJ950UC0	REGULATOR VO=5.0V IO=800MA	S-1170B50UC-OUJTFG
IC4001	AE009720	ICQK06966A	VADDIS9 MPEG/MICON/DSP/RF-AMP	ZR36966ELCG-D-G
IC4005	AE008324	IF9J0164AG	1M*16*4BANK(64M) 143MHZ SDRAM	M12L64164A-7TG
IC4007	AE009721	S51C01BF01	MEMORY DATA NOR FLASH 16M B00T	SST39VF1601-70-4C-EKE
IC6501	AD301988	I0UF015010	A/V SW 2INPUT 1OUTPUT	MM1501XNRE
IC6502	AD301988	I0UF015010	A/V SW 2INPUT 1OUTPUT	MM1501XNRE
IC6503	AD301988	I0UF015010	A/V SW 2INPUT 1OUTPUT	MM1501XNRE
IC6504	AD301988	I0UF015010	A/V SW 2INPUT 1OUTPUT	MM1501XNRE
IC7001	AE009512	I07F098820	19WLCD INVERTER IC	BD9882FV-E2
IC7002	AE009513	I0CF0902D0	QUAND OPERATIONAL AMPLIFILE	LM2902DR
IC8501	AE009365	I0QF045650	DUAL OPEAMP	NJM4565M(TE1)
△ IC8502	AE008223	I1TF911170	VO=ADJ IO=1A TAPING	LM1117S-ADJ
<b>TRANSISTORS</b>				
Q101	AE009515	T27T030190	FET	2SK3019_TL
Q102	AE009515	T27T030190	FET	2SK3019_TL
Q301	BZ510108	TAAA1504SY	TRANSISTOR SILICON	KTA1504S_Y_RTK
Q302	BZ510071	TNAAB05003	COMPOUND TRANSISTOR	KRC102SRTK
△ Q501	AE009722	T41GK35320	FET	2SK3532-01MR
Q505	BZ510108	TAAA1504SY	TRANSISTOR SILICON	KTA1504S_Y_RTK
Q1000	BZ510109	TCAA3875SY	TRANSISTOR SILICON	KTC3875S_Y_RTK
Q1001	BZ510090	TPAAB05001	COMPOUND TRANSISTOR	KRA102SRTK
Q1002	BZ510109	TCAA3875SY	TRANSISTOR SILICON	KTC3875S_Y_RTK
Q1003	BZ510109	TCAA3875SY	TRANSISTOR SILICON	KTC3875S_Y_RTK
Q1004	BZ510108	TAAA1504SY	TRANSISTOR SILICON	KTA1504S_Y_RTK
Q1005	BZ510107	TPAAA05001	COMPOUND TRANSISTOR	KRA101SRTK
Q1006	BZ510109	TCAA3875SY	TRANSISTOR SILICON	KTC3875S_Y_RTK
Q2301	AE008330	TAAA1505SY	TRANSISTOR SILICON	KTA1505S-Y-RTK/P
Q2302	AE008331	TAAA1544T0	TRANSISTOR SILICON	KTA1544T-RTK/P
△ Q3200	AE009621	TL4A01664Y	TRANSISTOR SILICON	KTA1664-Y(GP)
△ Q3201	BZ510109	TCAA3875SY	TRANSISTOR SILICON	KTC3875S_Y_RTK
△ Q3202	AE004665	TS3M000044	COMPOUND TRANSISTOR	CPH6312-TL-E
△ Q3801	AE009514	TJ7T35P020	FET	RTQ035P02-TR
Q3802	BZ510071	TNAAB05003	COMPOUND TRANSISTOR	KRC102SRTK
Q3803	BZ510071	TNAAB05003	COMPOUND TRANSISTOR	KRC102SRTK
Q3804	BZ510109	TCAA3875SY	TRANSISTOR SILICON	KTC3875S_Y_RTK
△ Q3805	AE009621	TL4A01664Y	TRANSISTOR SILICON	KTA1664-Y(GP)
△ Q3809	AE009514	TJ7T35P020	FET	RTQ035P02-TR
Q4200	BZ510109	TCAA3875SY	TRANSISTOR SILICON	KTC3875S_Y_RTK
Q4201	BZ510108	TAAA1504SY	TRANSISTOR SILICON	KTA1504S_Y_RTK
Q4205	BZ510109	TCAA3875SY	TRANSISTOR SILICON	KTC3875S_Y_RTK
Q4210	BZ510109	TCAA3875SY	TRANSISTOR SILICON	KTC3875S_Y_RTK
Q4214	BZ510108	TAAA1504SY	TRANSISTOR SILICON	KTA1504S_Y_RTK
Q4217	BZ510072	TPAAC05002	COMPOUND TRANSISTOR	KRA103SRTK
Q4218	BZ510071	TNAAB05003	COMPOUND TRANSISTOR	KRC102SRTK
Q4224	BZ510109	TCAA3875SY	TRANSISTOR SILICON	KTC3875S_Y_RTK
Q4305	BZ510090	TPAAB05001	COMPOUND TRANSISTOR	KRA102SRTK
Q4308	BZ510090	TPAAB05001	COMPOUND TRANSISTOR	KRA102SRTK
Q4309	BZ510071	TNAAB05003	COMPOUND TRANSISTOR	KRC102SRTK
Q4310	BZ510067	TNAAC05002	COMPOUND TRANSISTOR	KRC103SRTK
Q5801	AE009515	T27T030190	FET	2SK3019_TL
Q5802	AE009515	T27T030190	FET	2SK3019_TL
△ Q7003	AE009515	T27T030190	FET	2SK3019_TL
Q7004	AE009516	T250A06J30	FET	TK30A06J3(ORION.Q)
Q7005	AE009516	T250A06J30	FET	TK30A06J3(ORION.Q)

# ELECTRICAL REPLACEMENT PARTS LIST

Location No.	TSB P/N	Reference No.	Description	
<b>COILS &amp; TRANSFORMERS</b>				
△ L501	AE009366	029X000121	COIL,LINE FILTER	SS24H-K08240-CH
L503	BZ310150	02167E220K	COIL	22 UH
L504	AD301785	02167E100K	COIL	10 UH
L3201	AD301785	02167E100K	COIL	10 UH
L3202	AE009723	0216MG220M	COIL	22 UH
L4204	72784092	0216SD220J	COIL	22 UH
L4205	72784092	0216SD220J	COIL	22 UH
L4206	72784092	0216SD220J	COIL	22 UH
L4207	72784092	0216SD220J	COIL	22 UH
L7001	AD301785	02167E100K	COIL	10 UH
L8501	AE008874	0216SD2R2J	COIL	2.2 UH
L8502	AE006570	0216SD1R0J	COIL	1 UH
L8504	AE006570	0216SD1R0J	COIL	1 UH
△ T501	AE009724	0481240038	TRANSFORMER,SWITCHING	81240038
△ T7001	AE009521	048135109G	TRANSFORMER,SWITCHING	8135109G
△ T7002	AE009521	048135109G	TRANSFORMER,SWITCHING	8135109G
<b>JACKS</b>				
△ J301	AE009522	060R131024	HEADPHONE JACK	PJ-364H
△ J501	AE009725	064Q1A0011	JACK,AC	CCT2302-0701C
J4206	AE009726	063D100067	SOCKET,21PIN	MRC-021H-02PC(O87)
J4301	AE009524	060R401140	RCA JACK	RCA-101HT(OR)
J8101	AE009526	062R750007	PLUG	DIN-417HA-01
J8104	AE009529	060R431040	RCA JACK	RCA-341H(2)NI-06
<b>SWITCHES</b>				
SW2201	BZ612010	0504101T34	SWITCH,TACT	EVQ21505R
SW2202	BZ612010	0504101T34	SWITCH,TACT	EVQ21505R
SW2203	BZ612010	0504101T34	SWITCH,TACT	EVQ21505R
SW2204	BZ612010	0504101T34	SWITCH,TACT	EVQ21505R
SW2205	BZ612010	0504101T34	SWITCH,TACT	EVQ21505R
SW2206	BZ612010	0504101T34	SWITCH,TACT	EVQ21505R
SW2207	BZ612010	0504101T34	SWITCH,TACT	EVQ21505R
SW2208	BZ612010	0504101T34	SWITCH,TACT	EVQ21505R
<b>P.C.BOARD ASSEMBLIES</b>				
PCB130	AE009727	A51C01B130	DVD MT PCB ASS'Y	DMG097A
PCB240	AE009728	A51C01B240	POWER PCB ASS'Y	CEG373A
PCB270	AE009729	A51C01B270	OPERATION PCB ASS'Y	CEG374A
PCB290	AE009730	A51C01B290	TUNER PCB ASS'Y	CEG367A
PCBDA0	AE009731	A51C01BDA0	REMOCON PCB ASS'Y	CEG375A
PCBF40	AE009732	A51C01BF40	MAIN PCB ASS'Y	CMG130A
<b>MISCELLANEOUS</b>				
B101	AE007761	024AC5181J	CORE,BEADS	BLM18PG181SN1D
B501	BZ310122	024HT03563	CORE,BEADS	W4BRH3.5X6X1.0X2
B801	72783734	024AC5330J	CORE,BEADS	BLM18PG330SN1D
B802	AE007761	024AC5181J	CORE,BEADS	BLM18PG181SN1D
B803	AE007761	024AC5181J	CORE,BEADS	BLM18PG181SN1D
B804	AE007761	024AC5181J	CORE,BEADS	BLM18PG181SN1D
B805	AE007761	024AC5181J	CORE,BEADS	BLM18PG181SN1D
B806	AE007761	024AC5181J	CORE,BEADS	BLM18PG181SN1D
B807	AE007761	024AC5181J	CORE,BEADS	BLM18PG181SN1D
B808	AE007761	024AC5181J	CORE,BEADS	BLM18PG181SN1D
B809	AE007761	024AC5181J	CORE,BEADS	BLM18PG181SN1D
B810	AE007761	024AC5181J	CORE,BEADS	BLM18PG181SN1D
B811	AE007761	024AC5181J	CORE,BEADS	BLM18PG181SN1D
B812	AE007761	024AC5181J	CORE,BEADS	BLM18PG181SN1D
B813	AE007761	024AC5181J	CORE,BEADS	BLM18PG181SN1D
B818	AE007761	024AC5181J	CORE,BEADS	BLM18PG181SN1D
B819	AE007761	024AC5181J	CORE,BEADS	BLM18PG181SN1D
B820	AE009773	024AC8102T	CORE,BEADS	BLM15AG102SN1D
B821	AE009773	024AC8102T	CORE,BEADS	BLM15AG102SN1D
B2304	AE008552	024NC51021	CORE,BEADS	EBMS160808A102_RDC45
B2305	AE008552	024NC51021	CORE,BEADS	EBMS160808A102_RDC45
B3201	AE007761	024AC5181J	CORE,BEADS	BLM18PG181SN1D
B3802	AE007761	024AC5181J	CORE,BEADS	BLM18PG181SN1D
B3803	AE007761	024AC5181J	CORE,BEADS	BLM18PG181SN1D
B3804	AE007761	024AC5181J	CORE,BEADS	BLM18PG181SN1D
B3807	AE007761	024AC5181J	CORE,BEADS	BLM18PG181SN1D
B3808	AE007761	024AC5181J	CORE,BEADS	BLM18PG181SN1D
B3809	AE007761	024AC5181J	CORE,BEADS	BLM18PG181SN1D
B3810	AE007761	024AC5181J	CORE,BEADS	BLM18PG181SN1D
B4001	AE008552	024NC51021	CORE,BEADS	EBMS160808A102_RDC45
B4002	AE008552	024NC51021	CORE,BEADS	EBMS160808A102_RDC45
B4003	AE008552	024NC51021	CORE,BEADS	EBMS160808A102_RDC45
B4005	AE008552	024NC51021	CORE,BEADS	EBMS160808A102_RDC45
B4006	AE008552	024NC51021	CORE,BEADS	EBMS160808A102_RDC45
B4008	AE008552	024NC51021	CORE,BEADS	EBMS160808A102_RDC45
B4010	AE008552	024NC51021	CORE,BEADS	EBMS160808A102_RDC45
B4015	AE008552	024NC51021	CORE,BEADS	EBMS160808A102_RDC45
B4016	AE008552	024NC51021	CORE,BEADS	EBMS160808A102_RDC45
B4202	AE008395	024HC56005	CORE,BEADS	FCM1608CF-600T06
B4203	AE008879	024HC56013	CORE,BEADS	FCM1608KF-601T02



# ELECTRICAL REPLACEMENT PARTS LIST

Location No.	TSB P/N	Reference No.	Description	
<b>MISCELLANEOUS</b>				
B4204	AE007761	024AC5181J	CORE,BEADS	BLM18PG181SN1D
B4228	AE008395	024HC56005	CORE,BEADS	FCM1608CF-600T06
B4312	AE008609	024HC51023	CORE,BEADS	FCM1608KF-102T02
B4322	AE008609	024HC51023	CORE,BEADS	FCM1608KF-102T02
B5801	AE008879	024HC56013	CORE,BEADS	FCM1608KF-601T02
B5803	72783734	024AC5330J	CORE,BEADS	BLM18PG330SN1D
B6501	AE008609	024HC51023	CORE,BEADS	FCM1608KF-102T02
B6502	AE007761	024AC5181J	CORE,BEADS	BLM18PG181SN1D
B6504	AE007761	024AC5181J	CORE,BEADS	BLM18PG181SN1D
B7200	AE007761	024AC5181J	CORE,BEADS	BLM18PG181SN1D
B7201	AE007761	024AC5181J	CORE,BEADS	BLM18PG181SN1D
B8104	AE008610	024HC51513	CORE,BEADS	FCM1608KF-151T06
B8501	AE008394	024BC5121J	CORE,BEADS	BLM18PG121SN1D
B8502	AE008552	024NC51021	CORE,BEADS	EBMS160808A102_RDC45
B8503	AE008394	024BC5121J	CORE,BEADS	BLM18PG121SN1D
B8504	AE008552	024NC51021	CORE,BEADS	EBMS160808A102_RDC45
BT001	AE008217	141U004016	BATTERY,MANGAN	MNAAA(R03)
BT002	AE008217	141U004016	BATTERY,MANGAN	MNAAA(R03)
CD301	AE009733	06E8141801	CORD CONNECTOR	E8141801
△ CD501	AE009734	120Q155804	CORD AC	P205-1324-4
CP101	AE009735	06GG270029	CONNECTOR PCB SIDE	A2001WV-7A
CP501	AE008882	06977NM020	CONNECTOR PCB SIDE	127301123K2
CP802	AE009736	06GG260029	CONNECTOR PCB SIDE	A2001WV-6A
CD3805	AE006481	06CPLQ2011	CABLE,PAL	TD-OR0157F
CD4301	AE009541	06CH231204	CORD CONNECTOR	CH231204
CD4302	AE009542	06CU251301	CORD CONNECTOR	CU251301
CD6501	AE009737	06E82M1601	CORD CONNECTOR	E82M1601
CD7005	AE009738	06E82E6001	CORD CONNECTOR	E82E6001
CD7006	AE009738	06E82E6001	CORD CONNECTOR	E82E6001
CD7204	AE009740	06CHRU2401	CORD CONNECTOR	CHRU2401
CP2201	AD301795	069S230639	CONNECTOR PCB SIDE	A2001WR2-3P
CP2301	AE008156	069KYOT159	CONNECTOR PCB SIDE	LD07T2-24ND-03
CP2302	AE009544	069EV5T060	CONNECTOR PCB SIDE	04_6232_105_015_800+
CP2303	AE009545	069EV6T060	CONNECTOR PCB SIDE	04_6232_106_015_800+
CP3801	AE008886	06CK7N0301	CORD CONNECTOR	TWG-P23P-A1
CP4300	AE008886	06CK7N0301	CORD CONNECTOR	TWG-P23P-A1
CP5802	AE009741	06GF2G0020	CONNECTOR PCB SIDE	WD-00028-R
CP5803	AE009742	06GF2G0010	CONNECTOR PCB SIDE	WD-00027-R
CP6501	AE009549	069S2M0079	CONNECTOR PCB SIDE	A2006WV0-2X11P
CP7200	AE009548	069S2U0739	CONNECTOR PCB SIDE	A2006WV0-2X15P
CP7601	AE009743	06GG250029	CONNECTOR PCB SIDE	A2001WV-5A
CP8101	AE008882	06977NM020	CONNECTOR PCB SIDE	127301123K2
CP8501	AE009553	06GG2E0019	CONNECTOR PCB SIDE	A2001WR-14A
CP8502	AD301796	069S280629	CONNECTOR PCB SIDE	A2001WV2-8P
CUS151	BZ710279	800WFAA006	CUSHION A	
CUSF41	BZ710279	800WFAA006	CUSHION A	
EL2401	BZ614043	124116281A	EYE LET	XRY16X28BD
EL2402	BZ614044	124120301A	EYE LET	XRY20X30BD
△ F501	AE002112	080NT2R504	FUSE	50T025H
△ F7001	AE004626	083LA05007	FUSE	1206FA5A-T
FH501	AE002634	06710T0009	HOLDER,FUSE	EYF-52BCY
FH502	AE002634	06710T0009	HOLDER,FUSE	EYF-52BCY
NR7200	AE009744	11074000M7	R,NETWORK	CRA108000JV
NR7201	AE009744	11074000M7	R,NETWORK	CRA108000JV
NR7204	AE009557	11074470M7	R,NETWORK	CRA108470JV
NR7205	AE009557	11074470M7	R,NETWORK	CRA108470JV
NR7211	AE009557	11074470M7	R,NETWORK	CRA108470JV
OS7601	AE009746	077A038005	REMOTE RECEIVER	ROM-S038TAO
△ SP301	AE009558	070Y433004	SPEAKER	S0308F01
△ SP302	AE009558	070Y433004	SPEAKER	S0308F01
△ TH501	AE009559	DSQDNE5R0L	THERMISTOR	5D2-08LCS
TM101	AE009747	076D0PT010	TRANSMITTER	000-103000550
△ TU5801	AE009748	0163Y03011	RF UNIT	TDTG-S486D
△ V7201	AE009749	09EK115007	LCD	CLAA150XP07FQ
X101	AE009387	100GT01616	CRYSTAL	B16000E011
X801	AE009388	100DT02007	CRYSTAL	DSX840GA
X4001	AE009566	100GT02727	CRYSTAL	SMD-49 C27000J029

## RESISTOR

RC..... CARBON RESISTOR

## CAPACITORS

CC..... CERAMIC CAPACITOR  
 CE..... ALUMI ELECTROLYTIC CAPACITOR  
 CP..... POLYESTER CAPACITOR  
 CPP..... POLYPROPYLENE CAPACITOR  
 CPL..... PLASTIC CAPACITOR  
 CMP..... METAL POLYESTER CAPACITOR  
 CMPL..... METAL PLASTIC CAPACITOR  
 CMPP..... METAL POLYPROPYLENE CAPACITOR

# **TOSHIBA CORPORATION**

1-1, SHIBAURA 1-CHOME, MINATO-KU, TOKYO 105-8001, JAPAN