7.1.3 CONNECTOR FUNCTION DESCRIPTION

ANTENNA JACK

RR+
SECURITY
NC
ACC
ANT+B
NC
NC
NC
TEL IN
RR-

RL+
FR+
FL+
ILLUMI
+B
GND
NC
FL-
FR-
RL-

GND
SYSTEM ACC
+B
+B
ILLUMI
BUS+
BUS-

SHIELD
Rch+
Lch+
Lch-
Rch-
NC
GND