No.	Assembly image	Assembly description
10		Assemble the 3rd Sub Barrel Assy and gear as shown in the figure.
11		This is the assembled state of the spring.
12		Assemble the PI Sensor as shown in the figure.