

Kodak EasyShare CX7430

-

9

web-

www.kodak.com/go/cx7430support.

Kodak EasyShare CX7430


-

		24-	,
			, -
		USB 2.0- USB	, - - EasyShare.
		102.5	
		38	
		65	
		178	.
			: +/- 2 EV 0,5 EV
		TTL-AE -	, -
		JPEG/EXIF v2.21	

		QuickTime (CODEC: MPEG-4)
		G.711
		Auto (), Fill (), Red-eye ("), Off (.)
		Wide: 0.6-3.6 ISO 140 Tele: 0.6-2.1 ISO 140
		7 .
	1/2.5 ,	4:3, RGB Bayer CFA, 4.23
ISO		80-160
		80, 100, 200, 400
		, 6 /7 (2)
		Wide: f/2.7-f/5.2; Tele: f/4.6-f/8.7
		34 - 102 (35 -)
		Wide: 0.6 ; 10 (Landscape) : 13-70

		(Multi-zone) (Center-Zone)
)	(4 , , 312000 : 29.8
		0 to 40° C
		16 MB SD MMC (SD -  - SD Card Association.)
	Best () ★★★	2304 x 1728 (4)
	Best () (3:2) ★★★	2304 x 1536 (3.5)
	Better () ★★	1656 x 1242 (2.1)
	Good (, e-mail)	1200 x 900 (1.1)
	★	

		2 AA- Kodak, 2 Ni-MH AA- , 2 , CRV3, AA- Ni-MH KODAK KAA2HR
	(AC adapter)	3- ()
		10
(Shutter Speed)		1/2 1/1400 : . 0.7 4 :
		, 1/4
		NTSC PAL ()
	Best () ★★★ Good (, e-mail) ★★	Best: 640 x 480 (VGA), 13 . Good: 320 x 240 (QVGA), 20 .
		, ,



	Auto (), Daylight (), Tungsten (), Fluorescent ()
() ()	3X , 4X

_____ | _____