

- To use the CHECK PROGRAM (QC TEST MODE), press PROCESS key, and PROGRAM key at the same time and then the POWER switch on without depositing any laundry.

NO	CHECK METHOD	LED INDICATOR	CHECK ITEM
1	Initial state	<ul style="list-style-type: none"> • All LED on. • After 2~3 seconds water level frequency is displayed on LED. 	
2	Press once	<ul style="list-style-type: none"> • After laundry amount detecting, LED indicates laundry amount. • Pump model: water level LED is set to medium. 	<ul style="list-style-type: none"> • Laundry amount test. • After checking laundry amount, motor is on. (Left & Right)
3	Press twice		• Cold water
4	Press 3 times		• Hot water.
5	Press 4 times		<ul style="list-style-type: none"> • Drain motor is 1st state is play. • If lid is opened door error display. (wash and spin LED blinks)
6	Press 5 times		• Drain motor is 2nd state.
7	Press 6 times		• Drain pump is on.
8	Press 7 times		• AUTO off switch.

- WATER LEVEL FREQUENCY & LAUNDRY AMOUNT ARE DISPLAY BY THE LED (WATER LEVEL, PROCESS, PROGRAM)

Ex) Water level check ; Frequency : 26.7 KHz

8 ○ EX-LARGE	8 ○ SOAK	8 ○ FUZZY
4 ○ LARGE	4 ● WASH	4 ● ECONOMY
2 ● MEDIUM	2 ● RINSE	2 ● JEAN
1 ○ SMALL	1 ○ SPIN	1 ● WOOL

Ex) Laundry amount ; Pulse : 25

8 ○ SOAK	8 ○ FUZZY
4 ○ WASH	4 ● ECONOMY
2 ● RINSE	2 ○ JEAN
1 ○ SPIN	1 ● WOOL