

## ATTENTION

Thanks for choosing Healthcare OT 150 GE scale. To ensure a proper operation procedure, please carefully read through the instruction manual.

This appliance is marked according to the European directive 2002/96/EC on Waste Electrical and Electronic Equipment (WEEE). This guideline is the frame of a European-wide validity of return and recycling on Waste Electrical and Electronic Equipment.

## HELPFUL TIPS

Your scale is a precision electronic instrument. One of the hardest things to weigh is the human body because it is always in motion. To ensure reliable readings, always try to place your feet on the scale in the same place and stand still.

Treat your scale with care. Do not drop it or jump on it. The scale is durable, but misuse or abuse may render the electronic sensors inoperable.

Never submerge the scale under water. To clean the scale surface, use either a damp cloth or glass cleaner. Do not open or take apart the scale or its components.

## HOW TO OPERATE


1. Open the battery cover at the backside of the scale.
2. If there are batteries in the case, take the insulator out. Otherwise insert 4\*AAA batteries to the battery case. Then close the battery cover.




3. Select the weight unit you want among kg/lb/st.




4. Place the scale on a hard and even floor.
5. If there is a number other than 0.0kg displayed, please wait for about 30 seconds until it automatically turns off; if there is nothing on the screen, please overlook next step .
6. With your foot, firmly tap the center of the scale until "8888" displayed .



7. Important! Wait for "0.0kg" to be displayed before stepping on the scale .



8. Step on the scale(the display will flicker) and your weight measurement will be shown on the screen. The scale will automatically shut off after a few seconds.



## TROUBLESHOOTING GUIDE


If you experience any difficulty in use of the scale:

1. Check the battery is correctly fitted.
2. Check that you have selected your preference of kg/lb/st.
3. Check whether the scale is on a flat, level floor and not touching against a wall.
4. Ensure whether you do not step on the scale until the display shows "0.0kg".
5. If, when you tap the scale to activate it, there is no display at all or "Lo" is displayed- try two new batteries.



Replace battery

6. If "O\_Ld" is displayed, the scale has been overloaded.




Weight overload

## SPECIFICATION

Weight range	Min 2kg
	Max 150kg
Graduation	0.1kg

## CAUTION



Keep the scale off water



Don't put it on uneven floor while weighing



Keep the scale with care



Don't step on the edge of the scale

**GORENJE WISHES YOU A LOT OF PLEASURE  
WHILE USING YOUR APPLIANCE**

## УВАГА


Ми вдячні вам за купівлю наших ваг OT 150 GE. Для належного використання приладу уважно прочитайте інструкцію з експлуатації.

## КОРИСНІ ПОРАДИ

Ваші ваги - є точним електронним інструментом. Найважче зважувати людське тіло, оскільки воно завжди знаходитьться у русі. Щоб забезпечити фактичні значення, завжди намагайтесь поставити ноги на одному місці та стояти нерухомо. Обережно обходьтесь з вагами. Не кидайте ваги і не стрибайте на них. Ваги призначенні для тривалого використання, але при неправильному застосування можуть зіпсуватися електронні сенсори. Ніколи не занурюйте ваги під воду. Для чищення поверхні ваг скористайтесь вологовою ганчіркою, або миючим засобом для чищення скла. Не розкривайте та не розбирайте на частини ваги та її компоненти.

## КОРИСТУВАННЯ


1. На задній стінці ваг відкрийте кришку, що захищає батарейки.
2. Якщо батарейки присутні, витягніть ізоляцію. В іншому випадку вставте батарейки 4\*AAA. Закройте кришкою.




3. Виберіть одиницю маси, якою ви бажаєте скористатися кг/lb/st.\*




4. Покладіть ваги на тверду рівну підлогу.
5. Якщо на дисплеї висвічується будь-яке число, але не 0.0 кг, зачекайте 30 секунд і на дисплеї воно автоматично вимкнеться. Якщо ж на дисплеї нічого не висвітиться, пропустіть наступний пункт.
6. Злегка стукніть ногою посередині ваг, поки на дисплеї не висвітиться "8888".



7. Важливо! Перед тим, як встати на ваги, дочекайтесь висвітлення на дисплеї "0.0 кг".



8. Встаньте на прилад (поки дисплей мерехтить) і на дисплеї висвітиться значення вашої ваги. Ваги автоматично вимкнуться через кілька секунд.



## УСУНЕННЯ ПОШКОДЖЕНЬ

Якщо виникли труднощі при експлуатації приладу:

1. Перевірте, чи правильно розміщено батарейки.
2. Перевірте, чи вивибрали міру ваги кг/lb/st.\*
3. Перевірте, чи знаходяться ваги на рівній твердій підлозі і не торкаються стіни.
4. Перевірте, чи ви не стаєте на ваги, поки на дисплей не висвітиться "0.0 кг".
5. Якщо після легкого удару приладу для активізації, на дисплеї нічого не висвітиться, або висвітиться "Lo", замініть батарейки на нові.



Заміна батарейки

6. Якщо на дисплеї висвітиться "O\_Ld", ваги були перевантажені.




Перевантаження приладу

## СПЕЦИФІКАЦІЯ

Діапазон ваги	Мін. 2 кг
	Макс. 150 кг
Градуювання	0.1кг


## ЗАСТЕРЕЖЕННЯ




Утримуйте ваги подалі від води



Бережно обходьтеся з приладом



При зважуванні не ставте прилад на нерівну поверхню



Не наступайте на краї ваг

### Примітка:

lb – англ. фунт – 0,45 кг  
st.\* - англ. стоун – 6,35 кг

**GORENJE БАЖАЄ ВАМ ОТРИМАТИ ЗАДОВОЛЕННЯ  
ПІД ЧАС КОРИСТУВАННЯ ПРИЛАДОМ**