

Service Service Service

14PV182/05/39/58

21PV288/01/05/08/13

14PV183/01/08/13

21PV288/39/58/58C

14PV184/05

37TR127/03/39

14PV284/01/05/05W/08

51TR427/03/39

14PV284/13/39/39W

37TVB11/39

20PV184/01/05/08/13

51TVB30/39

Evolution: AA

Service Manual

Contents

Chapter

- 1 Table of contents per page
Technical data
Description of controls and connections
Service and caution notes
- 2 Adjustment procedures
Mechanical adjustment procedures
Circuit description
Electrical adjustment procedures
- 3 Interconnection wiring diagram
Block diagrams
Schematic diagrams
- 4 PCB layout
- 5 Tape deck exploded view
Mechanical parts list
Cabinet exploded view
Electrical parts list

Survey of remote controls:

14PV182/05/58	RT770/101	4822 219 10191
14PV183/01/08/13		
14PV182/39	RT770/104	4822 219 10192
14PV184/05	RT787/101	4822 219 10476
14PV284/01/05/05W/08/13		
20PV184/01/05/08/13		
21PV288/01/05/08/13/58/58C		
14PV284/39/39W	RT787/104	4822 219 10479
21PV288/39		
37TR127/03	RT780/201	4822 219 10478
51TR427/03		
37TR127/39	RT780/204	4822 219 10477
51TR427/39		
37TVB11/39		
51TVB30/39		

Tape Deck:

14PV182/05	WDB-P2/0LP
14PV182/39/58, 14PV183/01/08/13	WDBT-P2/0
14PV284/39/39W, 21PV288/39	
37TR127/39, 51TR427/39	
37TVB11/39, 51TVB30/39	
14PV184/05	BT-P2/0LP
14PV284/01/05/05W/08/13	
20PV184/01/05/08/13	
21PV288/01/05/08/13	
37TR127/03, 51TR427/03	
21PV288/58/58C	WDBT-S4/2

Survey of versions:

/01	PAL B/G
/02	PAL B/G (with VPS)
/05	PAL I UK
/07	PAL I Ireland
/08	PAL B/G Italy
/13	PAL B/G Nordic
/39	SECAM L, PAL B/G, PAL I
/58	PAL/SECAM B/G, D/K

Safety regulations require that the set is restored to its original condition and that parts which are identical to those specified are used.

