

















№	Фото ПДУ	Part № для заказа	Модель ТВ	Тип Шасси
1		RCU3S10	ERC 21NI60, 21TI70 ERISSON 1465, 2120, S14	3S10
2		RCU3Y01	ERC 21NI60, 21TI70 ERISSON 1465, 2120, S14, 2150	3Y01, 3Y11

3		RSU5N10	<p>ERC 25TI60, 29SI60, 29TB65, 29TJ70, 34TJ70, 34TP75</p> <p>ERISSON 2520, 2910, 2920</p>	5N10
4		RCU5N11	<p>ERC 25TI60, 29SI60, 29TB65, 29TJ70, 34TJ70, 34TP75</p> <p>ERISSON 2520, 2910, 2920</p>	5N11
5		D790-002901-30	<p>ERISSON 1401, 2102, 2103, 21F1, 21F2, 21F3, 2515, 2915</p>	

6		TBS--0000000062	ERISSON 14GX37	
7		TBS--0000000056	ERISSON 2107, 2108, 2109	
8		TBS--0000000063	ERISSON 2105, 2107	

9		TBS--0000000125	ERISSON 2107, 2108, 2109 (NEW!)	
10		RSU21SP50	ERC 21SP50	
11		D790-002901-31	ERISSON 25F2, 29F2, 29F3, 2503, 2903, 3410, 34F2	

12		TBS-0000000115	ERISSON 1455	
13		D790-003502-03	ERISSON 1401, 21F2, 21F3 ONE CHIP TOSHIBA	
14		0608-F5N010-00M	ERISSON 1406, 1465, S14, 2105, 2120	3Y11

15		HS08-S03704-00	HYUNDAI H-TV 1400, H-TV 1401 H-TV 2100, H-TV 2101	3Y01 4Y01
16		HS08-S03721-00	HYUNDAI H-TV 2502, H-TV 2902	5P60
17		0806-RC1325-14	HYUNDAI H-TV 2502, H-TV 2902	5P60