



	S1	S2	S3	S4	S5
31*32.9KHZ	L	H	H	H	H
33*36.9KHZ	H	L	H	H	L
37*39.9KHZ	L	H	L	L	L
40*45.9KHZ	L	L	L	H	H
46*48.9KHZ	L	H	L	H	L
49*53.9KHZ	H	H	L	L	H
54*57.9KHZ	L	H	L	L	H
58*64.9KHZ	H	L	L	L	H
65*67.9KHZ	L	H	L	L	L
68*75.9KHZ	H	H	L	L	L
76*77.9KHZ	H	L	L	L	L
78*79.9KHZ	L	H	L	L	L
80*84.9KHZ	H	L	L	L	L
85KHZ	L	L	L	L	L



13-4 Video Part Schematic Diagram



13-5 CRT Socket & Control Part Schematic Diagram

