


6 Exploded View and Parts List

※ You can search for updated part codes through ITSELF web site.
URL : <http://itself.sec.samsung.co.kr/>



No.	DESCRIPTION	CODE No.	SPECIFICATION	Q'ty	REMARKS
1	ASSY, COVER-FRONT	BN96-01295A	ABS HB GR70 + SILVER & BLACK SPRAY	1	SA
2	PANEL	BN07-00112A	PANEL-LTM170W1-L01	1	SA
3	SHIELD-PANEL	BN63-01420A	SECC T0.8	1	SNA
4	SCREW-TAPTITE	6003-000276	BH,+,B,M3,L10,ZPC(YEL)	9	SA , COVER-FRONT + SHIELD-PANEL
5	MAIN-PCB	--	MAIN-PCB	1	SA
6	I/P BOARD	--	I/P BOARD	1	SA
7	SCREW-TAPTITE	6003-000117	BH,+,B,M3,L6,ZPC(YEL)	4	SA , SHIELD-PANEL + MAIN-PCB
8	SCREW-TAPTITE	6003-000117	BH,+,B,M3,L6,ZPC(YEL)	5	SA , SHIELD-PANEL + I/P BOARD
9	HOLDER-INVERTER	BN61-01234A	ABS V0 BK07	2	SNA
10	ASSY SHIELD-PCB	BN96-01436A	SECC T0.5	1	SNA
11	SCREW-TAPTITE	6003-000117	BH,+,B,M3,L6,ZPC(YEL)	11	SA , SHIELD-PANEL + SHIELD-PCB
12	ASSY REAR-STAND	BN96-01435A	ABS + D/E CAST	1	SA
13	SCREW-TAPTITE	6003-001003	BH,+,B,M4,L12,ZPC(BLK)	1	SA , COVER-FRONT + COVER-REAR

Memo