







5 Troubleshooting


5-1 No Power







WAVEFORMS




5-2 No Video (PC Signal)






WAVEFORMS




5-3 No Picture (TV)





WAVEFORMS




5-4 No Picture (VIDEO/S-VIDEO/SCART)






WAVEFORMS



5-5 No Sound(TV)



WAVEFORMS



5-6 No Sound(VIDEO,S-VIDEO,SCART)

