

For multimedia models : you have to enter 7,5,9 and 2 while the picture menu is displayed to enter service menu. Press “0” to exit from service menu.