


TS20X

(14-21" COLOR TV BASIC SCHEMATIC DIAGRAM)



ATTENTION:
 (1) 2SC 2636C-EF-G, 2SC 1815-DY-GR: ALL parts with symbol are important safety parts
 (2) 191855-N44-A4, 191873-1520104-2: please do not use without a written permit from
 (3) SA-28A04-6F-2, SA1515-OY-GR.
 (4) 011 CT-148B-2P-4-89V-0101-F-2
 (5) R4741CT1-08B-284-63V-470uF-K
 (6) R4740XCL11-83V-3000uF-K
 (7) 200A000-CB82-200V-300uF-J
 (8) 1500A00-CB81-1800V-300uF-J

SAFETY NOTE:
 ALL parts with symbol are important safety parts
 DESIGNS/PECIFICATIONS ARE SUBJECT TO CHANGE
 WITHOUT PRIOR NOTICE