


## 5 Exploded View and Parts List

-You can search for updated part codes through ITSELF web site.

URL : <http://itself.sec.samsung.co.kr>

### 5-1 Exploded View and Parts List



LIST	TITLE	P/N	AMOUNT	LIST	TITLE	P/N	AMOUNT	LIST	TITLE	P/N	AMOUNT	REMARK
1	front cover	500E161610R	1 pc	10	arm front cover	501E660900R	1 pc	11	screw	509E160620R	6 pc	SCREW 4.0X8.5X0.6MM FOR PCB
2	panel		1 pc	12	arm rear cover	501E660900R	1 pc	12	screw	509E1606070R	2 pc	BOLT 4-4X8.5X0.6MM FOR 3-SUB
3	key button	500E060820R	1 pc	13	screw	509E0610000R	1 pc	13	screw	509E1606060R	4 pc	SCREW 3X5 FOR PANEL
4	control board		1 pc	14	front rubber	503E2002600	6 pc	14	screw	509E1606000R	2 pc	SCREW 4X5 FOR REAR REAR COVER
5	power board		1 pc	15	base	501E4002110R	1 pc	15	screw	509E1606010R	4 pc	SCREW 4X10 FOR HINGE CHASSIS
6	interface board		1 pc	16	lens	501E2003000R	1 pc	16	screw	509E1606130R	3 pc	4.0X10.0X0.6MM REAR
7	bracket	500E900010R	1 pc	17	VEGA	503E0601410R	4 pc	17	acoustic tape	506E9001010R	1 pc	tape size 60x20mm
8	rear cover	500E060700R	1 pc	18	shielding_1	503E0601490R	1 pc	18	clip wire	509E060600R	2 pc	CLIP, INVERTER Only use on the OPT
9	Hinge assembly	500E160210R	1 pc	19	wire profile	501E060600R	1 pc					

Memo