


# ***IBK***

## **DV615SI(RU)**


### **service manual**












**Ver2.00**







## Chapter Eight Circuit Diagram


## 8.1 Decode Board(2DV611SI-2)








8.2 AV Board(7DV515-0)




SCART 8PIN 9.5V-12V AV 4:3  
SCART 8PIN 5.0V-8.0V AV 16:9  
SCART 8PIN 0.0V-2.0V TV MODE  
SCART 16PIN 0 CVBS MODE  
SCART 16PIN 1 RGB MODE


### 8.3 Power Board (@5DV985-4 UL)



## 8.4 Main Panel (4DV509-5)



## 8.5 OK Board (6DV709K-1)





8.6 USB Board (9DV509-2)

