



LCD TV SERVICE GUIDE (6M16)

■ Service guide


1) Black creen




2) White screen




3) Panel display abnormally




4) No sound




5) TV failure



6) HDMI no picture or picture abnormal



7) PC no picture or picture abnormal



8) YPBPR, AV, S-VIDEO, SCART no picture or picture abnormal

