


SHARP SERVICE MANUAL

SEMS70ES03S//

CA10- CHASSIS

PAL SYSTEM COLOUR TELEVISION

MODEL

70ES-03S

In order to service model 70ES-03S, refer to the previously issued Service Manual for model 70DS-03S. This manual only contains the differences between the above mentioned models.

In the interests of user-safety (required by safety regulations in some countries) the set should be restored to its original condition and only parts identical to those specified should be used.

CONTENTS


• PARTS LIST	2
--------------------	---

70ES-03S

The difference between the previous model 70DS-03S and the current model 70ES-03S, is only the cabinet.

PARTS LIST (Only contains the differences)

REF. NO.	PARTS	★	DESCRIPTION	CODE
MISCELLANEOUS PARTS				
	TINS-6590BMN0	S	Operation Manual	AS
CABINET PARTS				
1	CCABA1232BMV0	S	Front Cabinet	
1-1	GDORF1053BMSA	S	Door	AD
1-2	PKAI-1083BM00	S	Door Latch	AF
1-3	HBDGB3013MESB	S	Badge SHARP	AH
1-4	JBTN-1053BMSA	S	Button Up/Down	AC
1-5	JBTN-1052BMSA	S	Button Power	AC
1-6	HDECQ0042BMSA	S	Window Power	AC
1-7	HDECQ0041BMSA	S	Window	AC
2	CCABB1083BMV0	S	Rear Cabinet	BB



SHARP



RECYCLED PAPER

PRINTED IN SPAIN