

Справочная таблица по применению видеоголовок

производитель	кол-во головок	АППАРАТ модель	ВИДЕОГОЛОВКИ	
			название в каталоге	аналог или 2-е название
AIWA	2	HV-E101/102/505/900/909/910	2HD 8059-01-19 /FUNAI/	
AIWA	2	HV-E295	2HD 255055 /FUNAI/	1-759-034-11 /SONY/
AIWA	4	HV-FX1/11/33/55/330 HV-Z10/70	4HD 8059-01-64 /FUNAI/	
AKAI	2	AKAI VS-22/23/25/26/27/75/422/425/426/427 485, VS-F10/16/222, VS-G20/21/23/24/25/204 205/206/211/212/215/217/225, VS-P8MK3/P9/88 100/110/120/150, VS-R9/88/100/110, VS-X400	2HD BV-V1075A420G /AKAI/	BV-V1102A420A /AKAI/ BV-V1123A420A /AKAI/
AKAI	2	VS-105/112/115/116/120/125/126/201/202/205 220/240/244/245/247/248/250/301/303/304, P8	2HD BV-V1030A220D /AKAI/	
AKAI	3	VS-155/165	3HD BV-V1047A220A /AKAI/	
AKAI	3	VS-462/465/467, VS-F12/15/17/300/301/310/320, VS-G30/33/34/35	3HD BV-V1102A420G /AKAI/	BV-V1102A420C /AKAI/
AKAI	4	VS-30/33/35/37/38/53/55/66/765/766/767/786 865/867, VS-F4/30/33/400/410/420/430/440/441 450/455/480/490/497, VS-G51/54/55, VS-X450/470	4HD BV-V1075A420B /AKAI/	BV-V1075A420E /AKAI/ BV-V1123A420B /AKAI/
DAEWOO	2	VCR-12/30/32/50/52/500/AIM414	2HD 97SA20400 /DAEWOO/	97SA20400 /MONEX/
FISHER	2	FVH-P420/520/530/615/618/620/622/710/711 715/716/720/721/722/730/830/905/908/910/911,	2HD 4704-01000 /FISHER/	771T-05121 /SAN/ 771T-05221 /SAN/ 771T-05124 /SAN/
FISHER	2	FVH-P210/300/310/830	2HD 2N2P /SAN/	613-022-0264 /SAN/ 613-078-8750 /SAN/ 613-078-8762 /SAN/ 613-087-6850 /SAN/
FISHER	4	FVH-P725/840/980	4HD 4704-01500 /FISHER/	4704-03200/FISHER/
FUNAI	2	VIP-1000/2500/3000, VCR-4000/4500/4800/5200 VP-1400	2HD 8000-01-13 /FUNAI/	
FUNAI	2	VIP-2500A/3000A	2HD 8059-01-19 /FUNAI/	
FUNAI	2	VIP-3000A MK3, VIP-3000HC MK3	2HD 8055-30-01 /FUNAI/	S2P
FUNAI	2	3EE-MK6, VIP3000A MK6, VIP-5000A, M7	2HD 255055 /FUNAI/	1-759-034-11 /SONY/, 255156, 255018
FUNAI	2	MK5	2HD 8059-08-05 /FUNAI/	
FUNAI	4	VCR-8203/8207	4HD 8059-01-64 /FUNAI/	5458704 /HIT/
GOLDSTAR	2	GHV-51/121/1230/1231/1233/1240/1241/1242 1243/1244/1245/1246/1247/1248/1520, VCP-4000/4100/4200/4301/4305/4306/4310/4311 4315/4316/4320/4321/4325/4326, VCR-4130	2HD 413-014 /LG/	413-050 /LG/, 413-051 /LG/ 413-075 /LG/, 413-098 /LG/
GOLDSTAR	2	GHV-1290/1291/1293/1295/1296/1297/1392 1393/1891/1910/2005/2301/4133, VCP-100/110/510/1010	2HD 413-159 /LG/	413-137 /LG/, 413-888 /LG/

производитель	кол-во головок	АППАРАТ модель	ВИДЕОГОЛОВКИ	
			название в каталоге	аналог или 2-е название
GOLDSTAR	4	RQ-40, P4	4HD 413-111 /LG/	
HITACHI	2	VT-100/110/111/112/113/115/118/120/125/128 220/225/400/405/410/413/414/415/416/418/510 515/517/518/520/525/526/530/535/536/M210 211/215/626/720/725/726/727/728/820/821/825 827/920/921/P50/88	2HD 5457471 /HIT/	5436101 /HIT/
HITACHI	2	VT-10/11/14/30/33/330/340/503/640/930/5030 VT-P10/30	2HD 5458992 /HIT/	5458413 /HIT/, 5458415 /HIT/
HITACHI	2	VT-4000/4200/5000/5500/5600	2HD 5458104 /HIT/	5458102 /HIT/, 5458282 /HIT/
HITACHI	2	VT-6500/6700/6900/7000/8000/8030/8040/8100 8300/8500/8700/9000/9300/9500/9700/9900	2HD 5458161 /HIT/	5458105 /HIT/, 5458165 /HIT/
HITACHI	3	VT-130/135/138/145/150/250/255/258/262/275 420/425/426/428/430/431/435/438/530/535/536 L30/M630/635/636	3HD 5457478 /HIT/	5457472 /HIT/
HITACHI	4	VT-168/260/450/498	4HD 5457473 /HIT/	5457474 /HIT/
HITACHI	4	VT-540/545/546/548 /D660/665//M640/645/646 730/731/735/736/740/745/746/830/841/845/920/931/935	4HD 5436103 /HIT/	
HITACHI	4	VT-7/17/18/19/20/34/35/38/39/350	4HD 5458434 /HIT/	5459001/HIT/, 5459002/HIT/
JVC	2	HR-D170/171/210/211/217/310/320/321/350/520/521 522/525/527/540/550/560/567/590/700/720/770/1205 1215/1235/1245/1405/1520/1540 /DX20 /DX22,SR-3200	2HD PDM-2008C-5 /JVC/	
JVC	2	HR-D140/141/150/152/156/157/158/160/P50/S10	2HD PQ-20016B-2 /JVC/	
JVC	2	BR-6200, HR-D2650/3300/3330/4100/7200	2HD PU-31332G-10 /JVC/	
JVC	2	HR-2200/3660/7200/7300/7350/7600/7605/7610/7650 7700, HR-D110/111/120/121/220/225, BP-5000	2HD PU-31332L /JVC/	
JVC	2	HR-J200/201/207/217/219/220/227/311/321/507 1200, HR-P19/29/30/39/40/50/68/78	2HD PDM-3353L-14 /JVC/	
JVC	3	HR-D300/400/580/600/620/640/650/800	3HD PDM-2087A /JVC/	
JVC	4	HR-D330/337/440/441/610/637/641/660/670/720/730 740/820, HR-FC100, SR-330, SR-L900, BR-9060	4HD PDM-2002C /JVC/	
JVC	4	HR-D250/257/275	4HD PQ-20020B /JVC/	
JVC	4	HR-D180/190/227/230/500/610	4HD PDM-2004B /JVC/	
JVC	4	HR-D370/430/470	4HD PDM-2007A-8 /JVC/	
JVC	4	BR-7000/7020/7030/7040	4HD PDM-2104B /JVC/	
JVC	4	HR-7655	4HD PU-20850G /JVC/	
JVC	5	HR-D750/830/860	5HD PDM-2112B /JVC/	
JVC	6	HR-D92/530/840/870/910	6HD PDM-2001C-8 /JVC/	
JVC	7	HR-D950/960/980	7HD PDM-2137A-2 /JVC/	
MITSUBISHI	2	HS-230/303/304/320/700	928B09004 /MIT/	2HD 928B09003 /MIT/

производитель	кол-во головок	АППАРАТ	ВИДЕОГОЛОВКИ	
		модель	название в каталоге	аналог или 2-е название
MITSUBISHI	2	HS-300/301/302/310	2HD 928B00801 /MIT/	928B00803 /MIT/ 928B00804 /MIT/ 928B00805 /MIT/
MITSUBISHI	2	HS-306/316/318	2HD 928B17302 /MIT/	928B17305 /MIT/
MITSUBISHI	2	HS-337/347	2HD 928B33402 /MIT/	928B33401 /MIT/
MITSUBISHI	3	HS-319	3HD 928B29602 /MIT/	928B29608 /MIT/
MITSUBISHI	3	HS-338/480/B10/20/E10G/20G/21	3HD 928B32207 /MIT/	
MITSUBISHI	4	HS-307	4HD 928B20702 /MIT/	
MITSUBISHI	4	HS-330/650	4HD 928B14202 /MIT/	
MITSUBISHI	4	HS-B30/E30	4HD 928B641090 /MIT/	
MONEX	2	555 MK2	2HD 97SA20400 /DAEWOO/	97SA20400 /MONEX/
MONEX	2	777	2HD 8000-01-13 /FUNAI/	
NEC	2	DX-1000/1600, N-901/902/906/9011/9012/9013 9014/9015/9016/9033/9034/9053/9054/9055 9056/9063/9065/9066/9077/9096, PX-1200	2HD 82423AH1 /NEC/	82515AH1 /NEC/
ORION	2	VH-3/4/191/200/201/205/212/250/254/288/291/ 292/300/303/1000/1012/1030/1040/1050/1060 /1070/1100/11201177/1197/1204/1440/1500/1660 1800/2150/2189/25002600/2700/2800/2950/2960/2970/2975	2HD 1590D00001 /ORION/	1590D00020 /ORION/ 1590D00003 /ORION/ 1590D00005 /ORION/ 1590D00010 /ORION/
ORION	2	N388E-V	2HD 255055 /FUNAI/	1-759-034-11 /SONY/ 255156, 255018
PANASONIC	2	NV-300/330/332/333/340/390/2000/2010 NV-7000/7200/7500/7800/3000 NV-8200/8400/8600/8610/8620	2HD VEH-0103 /MAT/	VEH-0099 /MAT/ VEH-0115 /MAT/ VEH-0121 /MAT/
PANASONIC	2	NV-370/380/630PS	2HD VEH-0218 /MAT/	
PANASONIC	2	NV-230/430/431/433/G7/G9/G20/G19	2HD VEH-0286 /MAT/	VEH-0271 /MAT/ VEH-0295 /MAT/ VEH-0621 /MAT/ VEH-0296 /MAT/
PANASONIC	2	NV-SD1/2/3/22	2HD VEH-0653 /MAT/	VEH-0621 /MAT/ VEH-0826 /MAT/
PANASONIC	2	NV-P01MK2/P04REE/SD200/205	2HD VEH-0678 /MAT/	VEH-0712 /MAT/
PANASONIC	2	NV-P01/02/03/04	2HD VEH-S0518 /MAT/	
PANASONIC	3	NV-250/280/450/460/465/470/480/G10/11 12/14/15/16/120 AG1000/1050	3HD VEH-0270 /MAT/	VEH-0287 /MAT/
PANASONIC	3	NV-G30/40/130/220/J1/3/4/10/11/30/33/36/ NV-J40/41/101/L10/20/150/P1/P2/P5/P7/P10	3HD VEH-0386 /MAT/	VEH-0416 /MAT/ VEH-0519 /MAT/ VEH-0532 /MAT/
PANASONIC	3	NV-SD10/11/12	3HD VEH-0599 /MAT/	VEH-0657 /MAT/
PANASONIC	4	AG-6010/6015/6200	4HD VEH-0225 /MAT/	VEH-0278 /MAT/
PANASONIC	4	NV-180 /D48/G25	4HD VEH-0252 /MAT/	

производитель	кол-во головок	АППАРАТ модель	ВИДЕОГОЛОВКИ	
			название в каталоге	аналог или 2-е название
PANASONIC	4	NV-730/770	4HD VEH-0267 /MAT/	
PANASONIC	4	NV-G33/45/46/48/J20/21/22/23/35/43/45/47 NV-L15/18/23/25/28/45	4HD VEH-0385 /MAT/	VEH-0417 /MAT/ VEH-0518 /MAT/ VEH-0531 /MAT/
PANASONIC	4	NV-G20/21/22/25/28/50/200/300/J27	4HD VEH-0400 /MAT/	VEH-0343 /MAT/ VEH-0538 /MAT/
PANASONIC	4	NV-SD20/25/40	4HD VEH-0598 /MAT/	VEH-0656 /MAT/
PANASONIC	4	NV-SD300/320/350/400/420/450	4HD VEH-0679 /MAT/	VEH-0715 /MAT/ VEH-0841 /MAT/
PANASONIC	4	NV-SR70/80	4HD VEH-0714 /MAT/	
PANASONIC	5	NV-850	5HD VEH-0231 /MAT/	VEH-0265 /MAT/
PANASONIC	5	NV-M7	5HD VEH-0366 /MAT/	
PANASONIC	6	NV-870/890	6HD VEH-0288 /MAT/	VEH-0625 /MAT/
PANASONIC	6	NV-D80/F65/H75/H77/AG5150/AG5250	6HD VEH-0352 /MAT/	
PANASONIC	6	NV-F55	6HD VEH-0548 /MAT/	
PANASONIC	6	NV-HD90/100/101/F125	6HD VEH-0601 /MAT/	VEH-0600 /MAT/
PANASONIC	7	NV-FS88/90/100/200/NV-V8000	7HD VEH-0467 /MAT/	VEH-0454 /MAT/ VEH-0651 /MAT/
PANASONIC	7	NV or AG-7350	7HD VEH-0437 /MAT/	
PANASONIC	7	NV-F70, NV-F51	7HD VEH-0433 VEH-0730	VEH-0415
PANASONIC	8	NV-W1	8HD VEH-0499	
PANASONIC	8	NV or AG-7750	8HD VEH-0542 /MAT/	
PANASONIC	8	NV or AG-8700	8HD VEH-0687 /MAT/	
PANASONIC	9	M10	9HD VEH-0468 /MAT/	
PHILIPS	2	VR-3260/6442/6448/6542	2HD 0002HE17 /SHARP/	0002HE21 /SHARP/ 0002HE27 /SHARP/
PHILIPS	2	VR-6440/6540	2HD 0002HE04 /SHARP/	0002HE00 /SHARP/ 0002HE02 /SHARP/ 0002HE05 /SHARP/ 0002HE06 /SHARP/
PHILIPS	2	20DV1/2, 20IF7, 20RW7, 21DV1/2/3, 21PT351, 23DV1, 2SB01/02/11/31/37, 68SB4, 71SB4, 86SB1, 91SB2,92SB2 DV-186/190/291/292/464/468/471, SE-4101, TV/VCR1, VHS GP2/4/6, VR-201/202/203/211/212/213/223/231/232/237/ 2310/2319/2329/3750/6180/6182/6185/6290/6291 6293/6362/6367/6467/6468/6469/6470	2HD 691-20448 /PH/	
PHILIPS	2	VR-274	2HD 691-21029 /PH/	
SAMSUNG	2	VB-990/991/992, VK-30/31/300, VX-30/31/32/1230 1231/1260/1261, VXK-300/301/306/320/321/326/336, VQ-30/31	2HD 69000-390-271 /SAM/	69000-390-012 /SAM/
SAMSUNG	2	VB или VX-510/511/520/610/616/617/619/620 626/627/705/710/711/712/713/717/720/721/729	2HD 69000-342-400 /SAM/	69000-603-059 /SAM/ 69000-603-058 /SAM/

производитель	кол-во головок	АППАРАТ	ВИДЕОГОЛОВКИ	
		модель	название в каталоге	аналог или 2-е название
		732/750/900/910/911/920/930/950/970/971/972 981/988/8220/8221/8225		
SAMSUNG	2	VI-730	2HD 69000-370-097 /SAM/	
SAMSUNG	4	VB или VX-1530/1531/1560/1561/1580 VN 1560	4HD 69000-390-013 /SAM/	69000-400-040 /SAM/
SAMSUNG	6	VN 1850	6HD 69000-390-016 /SAM/	
SHARP	2	VC-402/500/571/573/581/582/583/584/600/681 682/683/684/693/699/700/772/781/782/783/7810 7822/5W20/6V3/A10/30/100/101/102/103/104/105 106/202/203/211/234/244 /D801/802/M73/T72/310 410/TI314/TS313/V7,	2HD 0002HE17 /SHARP/	0002HE21 /SHARP/ 0002HE27 /SHARP/
SHARP	2	VC-110/200/300/381/383/384/385/386/387/388 471/477/481/482/2000/3300/8481/9100/9300 9400/9500/9600/9700/9800,	2HD 0002HE04 /SHARP/	0002HE00 /SHARP/ 0002HE02 /SHARP/ 0002HE05 /SHARP/ 0002HE06 /SHARP/
SHARP	2	VC-MA30	2HD VC-MA30	
SHARP	3	VC-473/483/486	3HD 0004HE04 /SHARP/	0004HE02 /SHARP/ 0004HE06 /SHARP/
SHARP	4	VC-790/9750/A62/504/K88/89	4HD 0004HE20 /SHARP/	0004HE14 /SHARP/ 0004HE13 /SHARP/ 0004HE17 /SHARP/
SHARP	4	VC-793/800/H851/852/882	4HD 0005HE10 /SHARP/	
SHARP	4	VC-779/780/A501/602	4HD 0004HE14 /SHARP/	0004HE20 /SHARP/ 0004HE13 /SHARP/
SHARP	4	VC-793/800/H851/852/882	4HD 0005HE10 /SHARP/	0004HE17 /SHARP/
SHARP	4	VC-MA40/45/50	4HD NSH552 /SHARP/	
SHIVAKI	2	SV-P20/M25/14 MK3	2HD 413-159 /LG/	413-137 /LG/, 413-888 /LG/
SANYO	2	VHR-1100/1110/1150/1200/1300/2370	2HD 771T-05121 /SAN/	4704-01000 /FISHER/ 771T-05124 /SAN/ 771T-05221 /SAN/
SANYO	2	VHR-3100/3110/3150/3200/3300/3310 /D500	2HD 771T-09000 /SAN/	771T-09200 /SAN/ 771T-13400 /SAN/
SANYO	2	VTC-5000/5005/5100/5151/5300/5350/5370/ 5400/6000/6500/M10/11/20/21/50/NX10	2HD 242V-01700 /SAN/	242V-22300 /SAN/ 242V-22400 /SAN/
SANYO	2	VTC-5500/5550/9100/9300/9455/9500/9350	2HD 771T-02000 /SAN/	771T-02100 /SAN/ 771T-02500 /SAN/
SANYO	2	VHR-23/120/130/141/151/171/220/330/4080/4100/ 4105/4200/4300/4500/5080/5100/5200/6850/7100/7200 7250/7300/7700/8070/8100/8200/Z1/ D4400/4410/4500/ 4600/4610/6700	2HD 2N2P /SAN/	613-022-0264 /SAN/ 613-078-8750 /SAN/ 613-078-8762 /SAN/ 613-087-6850 /SAN/
SANYO	3	VHR-1500/2500	3HD 771T-06500 /SAN/	771T-06800 /SAN/
SANYO	3	VHR-3400/3500	3HD 771T-12500 /SAN/	

производитель	кол-во головок	АППАРАТ модель	ВИДЕОГОЛОВКИ	
			название в каталоге	аналог или 2-е название
SANYO	3	VHR-5300/6500/7400/7440	3HD 2N3P /SAN/	613-079-8039 /SAN/
SANYO	4	VHR-4770/7500/7770	4HD 2N4P /SAN/	613-096-2829 /SAN/ 3-749-152-01 /SONY/
SETRON	2	788	2HD 2N2P /SAN/	613-022-0264 /SAN/ 613-078-8750 /SAN/ 613-078-8762 /SAN/ 613-087-6850 /SAN/
SIEMENS	2	FM-350/352/355/361/362/363	2HD 4704-01000 /FISHER/	771T-05121 /SAN/
SIEMENS	2	FM-601/603/607/620/621/625/630/632	2HD 2N2P /SAN/	613-022-0264 /SAN/ 613-078-8750 /SAN/ 613-078-8762 /SAN/ 613-087-6850 /SAN/
SIEMENS	4	FM-364	4HD 4704-01500 /FISHER/	4704-03200 /FISHER/
SONY	2	SLV-X37/39/226	2HD 8059-01-19 /FUNAI/	
SONY	2	SLV-X10/20/25/75	2HD 2N2P /SAN/	613-022-0264 /SAN/ 613-078-8750 /SAN/ 613-078-8762 /SAN/ 613-087-6850 /SAN/
SONY	2	SLV-282/SLV-X30/35	2HD DZR-27R /SONY/	8-848-540-01 /SONY/
SONY	2	SLV-X312	2HD 255055 /FUNAI/	1-759-034-11 /SONY/
SONY	3	CCDF30/50/330/CCDV4/30/CCDM7U	3HD DGR-16R /SONY/	A-7049-095A /SONY/
SONY	3	CCDFAU 220/230/CCDF 335E/370E/150E/250A/350E/380E	3HD DGR-40R /SONY/ DGR-42R 8MM	A-7049-215A /SONY/
SONY	4	SLV-X90/95/626	4HD 2N4P /SAN/	3-749-152-01 /SONY/ 613-096-2829 /SAN/
SONY	4	SLV-X50/55/57/710/711/712 SLV-363/416	4HD DZR-21R /SONY/	X50PS /SONY/
SONY	6	SLV-X800/810/82	6HD DZR-43R /SONY/	1-550-649-11 /SONY/
SUPRA	2	SU-1800	2HD 97SA20400 /DAEWOO/	97SA20400 /MONEX/
SUPRA	2	SU-8800 MK 2	2HD 69000-370-097 /SAM/	
SUPRA	2	SU-8800 MK 3	2HD 69000-390-271 /SAM/	69000-390-012 /SAM/
SUPRA	2	SU-9200	2HD 1590D00001 /ORION/	1590D00020 /ORION/ 1590D00003 /ORION/ 1590D00005 /ORION/ 1590D00010 /ORION/
TOSHIBA	2	V-95/110/120/130/140/210/211/212/220/221/222	2HD 70030006 /TOS/	70321900 /TOS/
TOSHIBA	2	V-71/73/74/75/81/82/83/84/85/86/87/88/93/94/108/109/199/ V-200G/202G/205G/207G/209 DV-90/96G/97G NM-3	2HD 70321968 /TOS/	70325087 /TOS/
TOSHIBA	2	B2, C1	2HD 8059-01-19 /FUNAI/	
TOSHIBA	2	B1, K1	2HD 8000-01-13 /FUNAI/	
TOSHIBA	3	V-300/301/305/306/309/320/350	3HD 70325174 /TOS/	
TOSHIBA	4	V-500/509/800	4HD 70325185 /TOS/	