

5. Troubleshooting

Problem	Check	Remedy
<ul style="list-style-type: none"> • Motor does not run when turned on 	<ul style="list-style-type: none"> • Check that the plug is securely inserted into outlet • Check that the carbon-brush is not severely worn • Check that the hook in the carbon-brush is separated • Check that the power switch is turned on • Check that the contact at the cord-reel area is ok 	<ul style="list-style-type: none"> • Plug in firmly • Push it completely into the brush holder or replace it • Replace if motor does not run when turned on • Replace it if broken
<ul style="list-style-type: none"> • Slide control does not adjust 	<ul style="list-style-type: none"> • Check that the slide switch is not broken • Check that the triac is not shorted • Check that the base plate is not broken 	<ul style="list-style-type: none"> • Replace it • Replace it • Replace it
<ul style="list-style-type: none"> • Cord does not rewind fully 	<ul style="list-style-type: none"> • Check that the cord is not twisted or wound unevenly • Check that the spring is not weak or broken 	<ul style="list-style-type: none"> • Pull the cord out 2~3m and push down the rewinding button • Replace • Replace the power cord if it does not fully rewind
<ul style="list-style-type: none"> • Cord rewinds by itself 	<ul style="list-style-type: none"> • Check that the lever is not broken 	<ul style="list-style-type: none"> • Replace it
<ul style="list-style-type: none"> • Suction power is weak 	<ul style="list-style-type: none"> • Check that the floor nozzle or the hose is clogged with a large object • Check that the cover is attached firmly to the body • Check that the hose is firmly inserted 	<ul style="list-style-type: none"> • Remove the object • Attach the cover properly • Insert the hose firmly
<ul style="list-style-type: none"> • The needle of the dust indicator is in the red position. 	<ul style="list-style-type: none"> • Check that the floor nozzle or the hose is not clogged with a large object • Check that the spring of the dust indicator is ok • Check that the filter sponge is clean 	<ul style="list-style-type: none"> • Remove the object • Replace the spring • Clean the sponge