


CONTROL LOCATIONS



No.	Ref. No.	Control Function	No.	Ref. No.	Control Function
1	SW405	POWER ON/OFF BUTTON	10	SW501	RASTER CENTER
2	VR504	CONTRAST	11	VR801	HIGH VOLTAGE ADJUSTMENT
3	VR501	BRIGHTNESS	12	VR503	ABL ADJUSTMENT
4	SW404	ADJUSTMENT (+)	13	VR321	B-DRIVE
5	SW403	ADJUSTMENT (-)	14	VR311	G-DRIVE
6	SW402	SELECT (>)	15	VR301	R-DRIVE
7	SW401	SELECT (<)	16	VR322	B-BIAS
8	VR502	SUB-BRIGHT	17	VR312	R-BIAS
9	VR901	B ⁺ ADJUSTMENT	18	VR302	G-BIAS