



SCHEMATIC DIAGRAM - 4

**A** DVD MODULE (DV5) CIRCUIT



DV: DVD MODULE (DV5); SCHEMATIC DIAGRAM 1 - 4  
 HD: DVD MODULE (HDMI); SCHEMATIC DIAGRAM - 5

1/4 2/4  
 3/4 4/4  
 SA-PT860E/EB/EG  
 DVD MODULE (DV5) CIRCUIT