



# TROUBLESHOOTING GUIDE


## 1. NO POWER




## 2. NO CHARACTER




### 3. NO RASTER



#### 4. NO VERTICAL DEFLECTION




## 5. TROUBLE IN DPM




DPMS TABLE

Mode \ Item	H / V SYNC	VIDEO	LED
NORMAL	ON / ON	NORMAL	GREEN
STAND-BY	OFF / ON	OFF(0V)	ORANGE
SUSPEND	ON / OFF	OFF(0V)	ORANGE
OFF	OFF / OFF	OFF(0V)	ORANGE

## 6. NO DEGAUSSING



## 7. NO TILT (ROTATION)



## 8. TROUBLE IN OSD

