



For NIGAM/A2 models only.

POWER CIRCUIT

- Since this is basic circuit
- All DC voltage to be measured on a common point