

3 DISASSEMBLY PROCEDURES

Flow-Chart for Disassembly Procedure

NBR	ITEM/PART	Fig.	Removal (SCREW)
【1】	Side Case (L).	①	1-SCREW (A)
		②	4-SCREWS (B/C/D)
		③	4-SCREWS (E)
		④	Slightly open the side case (L) Disconnect (Connector A).
【2】	Cassette Cover	⑤	2-SCREWS (F)
【3】	Side Case (R).	⑥	1-SCREW (G)
		⑦	Disconnect (Connector B)
		⑧	1-SCREW (H)
		⑨	Unlock---3 Locking Tabs Remove the Side Case (R)
【4】	EVF-Unit	⑩	Unlock---2 Locking Tabs Disconnect (Connector C)
【5】	Front Case	⑪	1-SCREW (I) Unlock---2 Locking Tabs Disconnect (Connector D)
【6】	Main C.B.A	⑫	2-SCREWS (J/K) Unsolder the Shield Case Disconnect (Connector E/F/G/H/I Connector J)
		⑬	Disconnect (Connector K/L)
【7】	Lens-Unit	⑭	2-SCREWS (L)
【8】	Front C.B.A & Mic Unit	⑮	Remove the Focus Dial/Nut Remove the Spacer/Spacer Knob Remove the knob Spacer
		⑯	Disconnect (Connector M) Unlock ---Locking Tabs
		⑰	Remove the AV-Jack C.B.A 4-SCREWS (M)
			Remove the Front C.B.A Remove the Mic Unit
【9】	E.V.F.C.B.A (E.V.F.A/B/C)	⑱	1-Screw (N)
		⑲	1. Push the locking portion then Pull the Eye Cap Holder.
			2. Push the locking portion then Pull the Case Holder.
		⑳	2-SCREWS (O)
		㉑	Disconnect (Connector N/O/P)
		㉒	1-SCREWS (P)
		㉓	1-SCREW (Q) Disconnect (Connector Q/R)
		㉔	2-SCREW (Q)







