


■ REG SCHEMATIC DIAGRAM

NOTES : ● For the destination of each signal and further line connections that are cut off from this diagram, refer to "BOARD INTERCONNECTIONS".
 ● When ordering parts, be sure to order according to the Part Number indicated in the Parts List.



#: EXCHANGE PARTS LIST

	R6622	R6623	R6624	R6625	R6627	Q6621	Q6622	Q6623
MB WF ONLY MODEL	OPEN	OPEN	OPEN	OPEN	OPEN	OPEN	OPEN	OPEN
MB WF and 2.0LCD MODEL	OPEN	OPEN	OPEN	OPEN	OPEN	OPEN	OPEN	OPEN
OTHER MODEL	EXIST	EXIST	EXIST	EXIST	EXIST	EXIST	EXIST	EXIST

	R6306	R6307	R6314	Q6306	Q6307
L1911 YES	EXIST	EXIST	EXIST	EXIST	EXIST
L1911 NO	OPEN	OPEN	OPEN	OPEN	OPEN

NOTE: The parts with marked (*) is not used.