


S13



- 1. Z_SUS_DN
- 2. Z_SUS_UP
- 3. Z_ER_DN
- 4. Z_ER_UP
- 5. YZB_SEL
- 6. Z_BAIS
- 7. Z_ENABLE

- 1. Y-ENBLE
- 2. X-ER
- 3. SET_DN_2
- 4. SET_UP
- 5. SLOPE_RETE
- 6. DET_LEVEL
- 7. DELTA_Yy
- 8. PASS_TOP
- 9. SET_DN
- 10. SET_UP
- 11. ER_UP
- 12. ER_DN
- 13. SUS_UP
- 14. SUS_DN
- 15. DATA
- 16. OC2
- 17. OC1
- 18. ST8
- 19. CLK

LSIS HI.0
 LG Electronics
 LGDP4008
 0820
 PA1681-008X

MX10812
 29LV3200TC
 2X919100
 TAIWAN
 #2G1-3DA1E
 080715

ESMT
 M12L64322A-6T
 AZG1P803A 0808

EBR39594901
 CTRL
 KS42087A023402

LG PDP 071030
 BOARD-42G1_CTRL
 PARTNO: CAX41833301
 REV: C
 LOCNO: 1XXX

SOLDERING

F04

P161

P162