


(MONITOR C.B.A.)

➔:VIDEO MAIN SIGNAL PATH

TO MAIN CONNECTION
FP903

FP601-24,25,26	D GND	1
FP601-24,25,26	D GND	2
FP601-23	LCD CS	3
FP601-22	LCD SCK	4
FP601-21	LCD SD	5
FP601-20	VBLK	6
FP601-19	M 5V	7
FP601-18	LCD HD	8
FP601-17	LCD 3V	9
FP601-16	M G	10
FP601-15	LCD RVS	11
FP601-14	M B	12
FP601-13	MON M PLL	13
FP601-12	M R	14
FP601-11	M 12V	15
FP601-10	MON M RB OUT	16
FP601-9	MON M G OUT	17
FP601-8	LCD PLL	18
FP601-7	M 5V	19
FP601-6	M BL 5V	20
FP601-5	BL BRIGHT	21
FP601-3,4	M NOREG	22
FP601-3,4	M NOREG	23
FP601-1,2	NOREG GND	24
FP601-1,2	NOREG GND	25



NOTE:
THE MEASUREMENT MODE OF THE DC VOLTAGE ON THIS
DIAGRAM IS STOP MODE(MONITOR:ON)

NOTE:
DO NOT USE ANY PART NUMBER SHOWN ON THIS
SCHEMATIC DIAGRAM FOR ORDERING WHEN YOU ORDER
A PART,PLEASE REFER TO PARTS LIST.