

MODEL(S)	METHOD	CONFIRMED?
DVF 3530	<ol style="list-style-type: none"> 1. Power on the player and make sure there is no disc in the tray. 2. Select the Setup menu by pressing the Menu button. 3. Select Audio by pressing >. 4. Select Other using the arrow buttons and press Enter. 5. Using the remote control, key in the following: 7, 0, 7, followed by 0 for region free, 1 for region 1 etc. 6. Press Enter to confirm the region. 7. Turn the DVD player off. 8. Wait for a few seconds and and turn the player back on. 	Doesn't seem to work.

MODEL(S)	METHOD	CONFIRMED?
DVF 5010	<ol style="list-style-type: none"> 1. Ensure the player tray does not have a disc in it. 2. Press and hold the Play button on the player for about 5 seconds. 3. The display panel should show you what region you are in (if in Australia, it will say Oceania). 4. Use the remote control's up and down arrows to scroll through the region numbers. 5. Press Enter to select the required region. 6. The display should say "Initial OK!". 7. Play your disc. 	
MODEL(S)	METHOD	CONFIRMED?
DTH-5208AU	<ol style="list-style-type: none"> 1. Make sure that there is no disk in DVD player and the tray is closed. 2. Press MENU, 1, 6, 7 on remote. Player will ask you to enter region number. Press 1-6 for specific region selection or MUTE for multi-region. 3. Turn the player off. 	

MODEL(S)	METHOD	CONFIRMED?
DPL900VD DPL910VD	<ol style="list-style-type: none"> 1. Switch on the player in DVD/CD mode without disc. The player starts with "Reading disc" 2. Wait for the "no disk" on the screen. 3. With the remote control (still in DVD/CD mode), type the following code: 26862200 and then the region code (1, 2, ... or 6), or 0 for region free. 4. The reader now shows "Reading". 5. Insert your disc and start playing. 	

MODEL(S)	METHOD	CONFIRMED?
DTH-3300 DTH-3600 DTH-3700 DTH-4000 DTH-4200 DTH-4500 DTH-5000 DTH-5000U DTH-5200 DTH-5400	<ol style="list-style-type: none"> 1. Make sure that there is no disc in the tray and switch on the player. 2. Cold start the player, by holding down the PLAY and STOP buttons on the player. 3. You should see a set of language options. Release the PLAY and STOP buttons. 4. Select your language. 5. Press REPEAT then the following codes for the required region the player is already set to (region you bought the player in): <ul style="list-style-type: none"> Region 1 - 2, 9, 3, 3, 4 Region 2 - 3, 8, 7, 6, 7 Region 3 - 5, 6, 7, 3, 2 Region 4 - 7, 6, 8, 8, 4 Region 5 - 5, 3, 8, 1, 4 Region 6 - 2, 4, 4, 6, 2 6. A code will appear, indicating the region setting of your player. 7. Press 9 for region-free, or 1 for region 1, 2 for region 2, etc. 8. Press OPEN/CLOSE on the Player to open the disc tray. 9. Press STANDBY (POWER) on the remote control to close the tray. <p>Next time the player is turned on it will set to the region specified. If</p>	Yes, for 3300, 3700, 4000, 4200, 4500, 5000, 5200, 5400 (needs re-confirming for steps 8 & 9 not being needed)