



website:<http://biz.LGservice.com>

LCD TV


SERVICE MANUAL

CHASSIS : LP68A

MODEL : 17LS5R 17LS5R-ZA

CAUTION

BEFORE SERVICING THE CHASSIS,
READ THE SAFETY PRECAUTIONS IN THIS MANUAL.



CONTENTS

CONTENTS	2
PRODUCT SAFETY	3
SPECIFICATION	6
ADJUSTMENT INSTRUCTION	9
TROUBLE SHOOTING.....	13
BLOCK DIAGRAM.....	17
EXPLODED VIEW	20
REPLACEMENT PARTS LIST	22
SVC. SHEET	

SAFETY PRECAUTIONS

IMPORTANT SAFETY NOTICE

Many electrical and mechanical parts in this chassis have special safety-related characteristics. These parts are identified by \triangle in the Schematic Diagram and Replacement Parts List.

It is essential that these special safety parts should be replaced with the same components as recommended in this manual to prevent Shock, Fire, or other Hazards.

Do not modify the original design without permission of manufacturer.

General Guidance

An **isolation Transformer should always be used** during the servicing of a receiver whose chassis is not isolated from the AC power line. Use a transformer of adequate power rating as this protects the technician from accidents resulting in personal injury from electrical shocks.

It will also protect the receiver and its components from being damaged by accidental shorts of the circuitry that may be inadvertently introduced during the service operation.

If any fuse (or Fusible Resistor) in this TV receiver is blown, replace it with the specified.

When replacing a high wattage resistor (Oxide Metal Film Resistor, over 1W), keep the resistor 10mm away from PCB.

Keep wires away from high voltage or high temperature parts.

Before returning the receiver to the customer,

always perform an **AC leakage current check** on the exposed metallic parts of the cabinet, such as antennas, terminals, etc., to be sure the set is safe to operate without damage of electrical shock.

Leakage Current Cold Check(Antenna Cold Check)

With the instrument AC plug removed from AC source, connect an electrical jumper across the two AC plug prongs. Place the AC switch in the on position, connect one lead of ohm-meter to the AC plug prongs tied together and touch other ohm-meter lead in turn to each exposed metallic parts such as antenna terminals, phone jacks, etc.

If the exposed metallic part has a return path to the chassis, the measured resistance should be between $1M\Omega$ and $5.2M\Omega$.

When the exposed metal has no return path to the chassis the reading must be infinite.

An other abnormality exists that must be corrected before the receiver is returned to the customer.

Leakage Current Hot Check (See below Figure)

Plug the AC cord directly into the AC outlet.

Do not use a line Isolation Transformer during this check.


Connect 1.5K/10watt resistor in parallel with a 0.15uF capacitor between a known good earth ground (Water Pipe, Conduit, etc.) and the exposed metallic parts.

Measure the AC voltage across the resistor using AC voltmeter with 1000 ohms/volt or more sensitivity.

Reverse plug the AC cord into the AC outlet and repeat AC voltage measurements for each exposed metallic part. Any voltage measured must not exceed 0.75 volt RMS which is corresponds to 0.5mA.

In case any measurement is out of the limits specified, there is possibility of shock hazard and the set must be checked and repaired before it is returned to the customer.

Leakage Current Hot Check circuit



SERVICING PRECAUTIONS

CAUTION: Before servicing receivers covered by this service manual and its supplements and addenda, read and follow the **SAFETY PRECAUTIONS** on page 3 of this publication.

NOTE: If unforeseen circumstances create conflict between the following servicing precautions and any of the safety precautions on page 3 of this publication, always follow the safety precautions. Remember: Safety First.

General Servicing Precautions

1. Always unplug the receiver AC power cord from the AC power source before;
 - a. Removing or reinstalling any component, circuit board module or any other receiver assembly.
 - b. Disconnecting or reconnecting any receiver electrical plug or other electrical connection.
 - c. Connecting a test substitute in parallel with an electrolytic capacitor in the receiver.
CAUTION: A wrong part substitution or incorrect polarity installation of electrolytic capacitors may result in an explosion hazard.
2. Test high voltage only by measuring it with an appropriate high voltage meter or other voltage measuring device (DVM, FETVOM, etc) equipped with a suitable high voltage probe. Do not test high voltage by "drawing an arc".
3. Do not spray chemicals on or near this receiver or any of its assemblies.
4. Unless specified otherwise in this service manual, clean electrical contacts only by applying the following mixture to the contacts with a pipe cleaner, cotton-tipped stick or comparable non-abrasive applicator; 10% (by volume) Acetone and 90% (by volume) isopropyl alcohol (90%-99% strength)
CAUTION: This is a flammable mixture.
Unless specified otherwise in this service manual, lubrication of contacts is not required.
5. Do not defeat any plug/socket B+ voltage interlocks with which receivers covered by this service manual might be equipped.
6. Do not apply AC power to this instrument and/or any of its electrical assemblies unless all solid-state device heat sinks are correctly installed.
7. Always connect the test receiver ground lead to the receiver chassis ground before connecting the test receiver positive lead.
Always remove the test receiver ground lead last.
8. *Use with this receiver only the test fixtures specified in this service manual.*
CAUTION: Do not connect the test fixture ground strap to any heat sink in this receiver.

Electrostatically Sensitive (ES) Devices

Some semiconductor (solid-state) devices can be damaged easily by static electricity. Such components commonly are called *Electrostatically Sensitive (ES) Devices*. Examples of typical ES devices are integrated circuits and some field-effect transistors and semiconductor "chip" components. The following techniques should be used to help reduce the incidence of component damage caused by static by static electricity.

1. Immediately before handling any semiconductor component or semiconductor-equipped assembly, drain off any electrostatic charge on your body by touching a known earth ground. Alternatively, obtain and wear a commercially available discharging wrist strap device, which should be removed to

prevent potential shock reasons prior to applying power to the unit under test.

2. After removing an electrical assembly equipped with ES devices, place the assembly on a conductive surface such as aluminum foil, to prevent electrostatic charge buildup or exposure of the assembly.
3. Use only a grounded-tip soldering iron to solder or unsolder ES devices.
4. Use only an anti-static type solder removal device. Some solder removal devices not classified as "anti-static" can generate electrical charges sufficient to damage ES devices.
5. Do not use freon-propelled chemicals. These can generate electrical charges sufficient to damage ES devices.
6. Do not remove a replacement ES device from its protective package until immediately before you are ready to install it. (Most replacement ES devices are packaged with leads electrically shorted together by conductive foam, aluminum foil or comparable conductive material).
7. Immediately before removing the protective material from the leads of a replacement ES device, touch the protective material to the chassis or circuit assembly into which the device will be installed.
CAUTION: Be sure no power is applied to the chassis or circuit, and observe all other safety precautions.
8. Minimize bodily motions when handling unpackaged replacement ES devices. (Otherwise harmless motion such as the brushing together of your clothes fabric or the lifting of your foot from a carpeted floor can generate static electricity sufficient to damage an ES device.)

General Soldering Guidelines

1. Use a grounded-tip, low-wattage soldering iron and appropriate tip size and shape that will maintain tip temperature within the range or 500°F to 600°F.
2. Use an appropriate gauge of RMA resin-core solder composed of 60 parts tin/40 parts lead.
3. Keep the soldering iron tip clean and well tinned.
4. Thoroughly clean the surfaces to be soldered. Use a mall wire-bristle (0.5 inch, or 1.25cm) brush with a metal handle. Do not use freon-propelled spray-on cleaners.
5. Use the following unsoldering technique
 - a. Allow the soldering iron tip to reach normal temperature. (500°F to 600°F)
 - b. Heat the component lead until the solder melts.
 - c. Quickly draw the melted solder with an anti-static, suction-type solder removal device or with solder braid.
CAUTION: Work quickly to avoid overheating the circuit board printed foil.
6. Use the following soldering technique.
 - a. Allow the soldering iron tip to reach a normal temperature (500°F to 600°F)
 - b. First, hold the soldering iron tip and solder the strand against the component lead until the solder melts.
 - c. Quickly move the soldering iron tip to the junction of the component lead and the printed circuit foil, and hold it there only until the solder flows onto and around both the component lead and the foil.
CAUTION: Work quickly to avoid overheating the circuit board printed foil.
 - d. Closely inspect the solder area and remove any excess or splashed solder with a small wire-bristle brush.

IC Remove/Replacement

Some chassis circuit boards have slotted holes (oblong) through which the IC leads are inserted and then bent flat against the circuit foil. When holes are the slotted type, the following technique should be used to remove and replace the IC. When working with boards using the familiar round hole, use the standard technique as outlined in paragraphs 5 and 6 above.

Removal

1. Desolder and straighten each IC lead in one operation by gently prying up on the lead with the soldering iron tip as the solder melts.
2. Draw away the melted solder with an anti-static suction-type solder removal device (or with solder braid) before removing the IC.

Replacement

1. Carefully insert the replacement IC in the circuit board.
2. Carefully bend each IC lead against the circuit foil pad and solder it.
3. Clean the soldered areas with a small wire-bristle brush. (It is not necessary to reapply acrylic coating to the areas).

"Small-Signal" Discrete Transistor Removal/Replacement

1. Remove the defective transistor by clipping its leads as close as possible to the component body.
2. Bend into a "U" shape the end of each of three leads remaining on the circuit board.
3. Bend into a "U" shape the replacement transistor leads.
4. Connect the replacement transistor leads to the corresponding leads extending from the circuit board and crimp the "U" with long nose pliers to insure metal to metal contact then solder each connection.

Power Output, Transistor Device

Removal/Replacement

1. Heat and remove all solder from around the transistor leads.
2. Remove the heat sink mounting screw (if so equipped).
3. Carefully remove the transistor from the heat sink of the circuit board.
4. Insert new transistor in the circuit board.
5. Solder each transistor lead, and clip off excess lead.
6. Replace heat sink.

Diode Removal/Replacement

1. Remove defective diode by clipping its leads as close as possible to diode body.
2. Bend the two remaining leads perpendicular y to the circuit board.
3. Observing diode polarity, wrap each lead of the new diode around the corresponding lead on the circuit board.
4. Securely crimp each connection and solder it.
5. Inspect (on the circuit board copper side) the solder joints of the two "original" leads. If they are not shiny, reheat them and if necessary, apply additional solder.

Fuse and Conventional Resistor

Removal/Replacement

1. Clip each fuse or resistor lead at top of the circuit board hollow stake.
2. Securely crimp the leads of replacement component around notch at stake top.

3. Solder the connections.

CAUTION: Maintain original spacing between the replaced component and adjacent components and the circuit board to prevent excessive component temperatures.

Circuit Board Foil Repair

Excessive heat applied to the copper foil of any printed circuit board will weaken the adhesive that bonds the foil to the circuit board causing the foil to separate from or "lift-off" the board. The following guidelines and procedures should be followed whenever this condition is encountered.

At IC Connections

To repair a defective copper pattern at IC connections use the following procedure to install a jumper wire on the copper pattern side of the circuit board. (Use this technique only on IC connections).

1. Carefully remove the damaged copper pattern with a sharp knife. (Remove only as much copper as absolutely necessary).
2. carefully scratch away the solder resist and acrylic coating (if used) from the end of the remaining copper pattern.
3. Bend a small "U" in one end of a small gauge jumper wire and carefully crimp it around the IC pin. Solder the IC connection.
4. Route the jumper wire along the path of the out-away copper pattern and let it overlap the previously scraped end of the good copper pattern. Solder the overlapped area and clip off any excess jumper wire.

At Other Connections

Use the following technique to repair the defective copper pattern at connections other than IC Pins. This technique involves the installation of a jumper wire on the component side of the circuit board.

1. Remove the defective copper pattern with a sharp knife. Remove at least 1/4 inch of copper, to ensure that a hazardous condition will not exist if the jumper wire opens.
2. Trace along the copper pattern from both sides of the pattern break and locate the nearest component that is directly connected to the affected copper pattern.
3. Connect insulated 20-gauge jumper wire from the lead of the nearest component on one side of the pattern break to the lead of the nearest component on the other side. Carefully crimp and solder the connections.
CAUTION: Be sure the insulated jumper wire is dressed so the it does not touch components or sharp edges.

SPECIFICATION

NOTE : Specifications and others are subject to change without notice for improvement.

1. General Specification

NO	Item	Content	Remark
1	User Model Name	17LS5R-ZA : PAL/SECAM (EU)	
2	Feature	17" LCD TV	
3	Chassis Name	LP68A	
4	General Scope	External SW & Adj.	8Keys
5	Power Cord	Length : 1.87±0.04 M Shape : Wall-out, Color : BLACK	NATION
6	Power Adapter	No	
7	LCD Module Feature	Maker	AUO
		Type	TFT Color LCD Module
		Active Display Area	17.0 inches(432mm) diagonal(Aspect 4:3)
		Pixel Pitch [mm]	0.264mm(H) x 0.264mm(V)
		Electrical interface	LVDS
		Color Depth	6BIT WITH FRC, 16.2M colors
		Size [mm]	385.5(W) x 396.5(H) x 15.8(D) Max
		Surface Treatment	Hard Coating(3H) & Anti Glare (HAZE 3%)
		Operating Mode	Normally Black
		Back light Unit	4 CCFL (6 lamps)
	R/T	Typ	5ms(Typ), 9ms(Max)

2. Mechanical specification

No.	Item	Content	Remark			
1	Product Dimension	Width (W)	Length (D)	Height (H)		
		Before Packing	463.3	166.3	353.5	
		After Packing	527	175	470	
2	Product Weight	Only SET	3.94 kg(CPT)			
		With BOX	5.04 kg(CPT)			
3	Container Loading Quantity	Individual or Palletizing	20ft		40ft	
			Indi.	Wooden	Indi.	Wooden
			858	720	1716	1584
4	Stand Assy	Type	Base detachable			
		Size (W x D x H)	302.2 x 166.3 x 68			
		Tilt Degree	-3°(-0/+3°) ~ +10°(±2)			
		Tilt force	Target 1.5Kgf (0.8Kgf ~ 2.0Kgf)			
		Swivel Degree	- NON			
		Swivel Force	- NON			
5	Appearance	General	Refer to Standard of LG(55)G1-1020			

3. Engineering Specification

No.	ITEM	Specification				Remark
1	ENERGY	SYNC(V/H)		VIDEO	POWER	LED COLOR
	Normal	On/On		Active	≤ 40W	Green
	Sleep Mode	Off/On		Off	≤ 1W	Red
	Off Mode	-		Off	≤ 1W	Off
2	Audio output	Source	Min	Typ	Max	Min : -10% Max : +30%
		PC	2.7W	3W	3.9W	
		AV	2.7W	3W	3.9W	
		TV	2.7W	3W	3.9W	
3	D-SUB Pin configuration	1 : RED 3 : Blue 5 : S.T (GND) 7 : Green GND 9 : N.C 11: ID0(GND) 13: H-Sync 15: SCL		2 : Green 4 : ID2 (GND) 6 : RED GND 8 : Blue GND 10 : D-GND 12 :SDA 14 : V-Sync Shell : GND		10 : Digital GND
4	MTBF	Hours(Min)		Lamp Life : 50,000 Hours(MIN)		
5	Operating Environment	Temp : 10 ~ 35 deg Humidity : 20 ~ 80 %				
6	Storage Environment	Temp : -10 ~ 60 deg Humidity : 5 ~ 90 %				Non condensing Non condensing

4. Optical Characteristic

No	Item	Specification				Remark	
			Min	Typ	Max		
1	Viewing Angle <CR≥10>	R/L		89/89			
		U/D		89/89			
2	Luminance	Luminance (cd/m²)	320	400		PSM : Dynamic, CSM: Cool White (100 IRE)	
		White luminance uniformity	75%	80%			
3	Contrast Ratio	CR	2400	3000		All white/ All black	
4	CIE Color Coordinates	White (Warm)	Wx Wy	0.298 0.314	0.313 0.329	0.328 0.344	In AV input PSM : Dynamic White (85 IRE)
		White (Normal)	Wx Wy	0.270 0.278	0.285 0.293	0.300 0.308	
		White (Cool)	Wx Wy	0.261 0.268	0.276 0.283	0.291 0.298	

5. Outgoing Condition

No	Item		Condition		Remark
1	Power		Off		
2	Volume Level		30		
3	Main Picture Input		TV		
4	Main Last Channel		Pr 01		
5	Mute		Off		
6	STATION	Auto Programme	To set	System Storage from Search	
		Manual Programme	To set	Storage System Band Channel Fine Search Name	
		Programme Edit	To set		
		Favourite Programme	Off		
7	PICTURE	PSM	Dynamic		
			Standard		
			Mild		
			Game		
			User	Contrast	100
			Brightness	50	
			Colour	60	
			Sharpness	50	
			Tint	0	
		CSM	Cool		
Normal					
Warm					
User	Red		0		
	Green		0		
	Blue	0			
	Reset	To set			
8	SOUND	SSM	Flat		
			Music		
			Movie		
			Sports		
			User		
		AVL	Off		
	Balance	0			
9	TIME	Clock	-- : --		
		Off time	-- : -- Off		
		On time	-- : -- Pr.1 Vol. 30 Off		
		Auto sleep	Off		
10	SPECIAL	Language	English		16 Language
		Country	Others		30 Teletext Language
		Child Lock	Off		

ADJUSTMENT INSTRUCTION

1. Application Range

These documents is applied to 17" LCD TV(chassis : LP68A)


2. Designation

- 1) The adjustment is according to the order which is designated and which must be followed, according to the plan which can be changed only on agreeing.
- 2) Power Adjustment : Free Voltage
- 3) Magnetic Field Condition : Nil.
- 4) Input signal Unit : Product Specification Standard
- 5) Reserve after operation : Above 30 Minutes
- 6) Adjustment equipments: Color Analyzer(CA-210 or CA-110), Pattern Generator (MSPG-925L or Equivalent), DDC Adjustment Jig equipment, SVC remote controller


3. Main PCB check process

3.1. Download


- 1) Execute ISP program "Mstar ISP Utility" and then click "Config" tab.
- 2) Set as below, and check the following tabs.
Port type - Choose the your port type, Normally "LPT1" or "LPT2".
Speed - Choose the speed from 70 to 99.
JIG - Choose the your JIG type, Normally "Mstar" or "LGE".




- 3) Click "Read" tab, and then load download file(XXXX.bin) by clicking "Read".



- 4) Click "Auto" tab and set as below, and then click "Run".




- 5) After downloading, check "OK" message.



* APC - After Manual-Insert, executing APC

3.2. ADC Process

- (1) PC input ADC
 - 1) Auto RGB Gain/Offset Adjustment
 - (a) Convert to PC in Input-source
 - (b) Signal equipment displays.
Output Voltage : 730 mVp-p
Impress Resolution XGA(1024x768@60Hz)
Pattern:gray pattern that left & right is black and center is white signal(Refer below picture)
(Model:60, Pattern:28 at MSPG925L)



- (c) Adjust by commanding AUTO_COLOR_ADJUST (0xF1) 0x00 0x02 instruction.

- 2) Confirmation
 - (a) We confirm whether "0x8C" address of EEPROM "0xB4" is "0xAA" or not.
 - (b) If "0x8C" address of EEPROM "0xB4" isn't "0xAA", we adjust once more.
 - (c) We can confirm the ADC values from "0x00~0x05" addresses in a page "0xB4".

3.3. Function Check

- : Check Input and Signal items (cf. work instruction)
- (1) TV
 - (2) AV1 (SCART)
 - Input the SCART-RGB signal and check the display.
(MSPG-925F Model: 232, Pattern;12)
 - (3) AV2 (CVBS/ S-Video)
 - (4) H/P Sound Output

* Display and Sound check is executed by Remote control.

4. Total Assembly line process

4.1. Adjustment Preparation

- (1) Above 30 minutes Heat-run in RF no signal
- (2) 15 Pin D-Sub Jack is connected to the signal of Pattern Generator.

4.2. Confirm color coordinate of AV2

- (1) Set Input to AV2.
- (2) Input signal : CVBS, PAL @ 50Hz
Full White 216/255 gray level (85 IRE, Model : 202 Patter : 78 at MSPG925L)
- (3) Set PSM : Dynamic / CSM : Cool
- (4) Confirm whether $x=0.276\pm 0.03$, $y=0.283\pm 0.03$, $z\geq 0.250$ or not.

4.3. Other quality

- (1) Confirm that each items satisfy under standard condition that was written product spec..
- (2) Confirm Video and Sound at each source.
 - 1) AV
 - (a) Select input AV1 and check whether picture is displayed or not. - Check whether SCART output picture is displayed or not.
 - (b) Select input AV2(S-video) and check whether picture is displayed or not.
 - (c) Select input AV2(CVBS) and check whether picture is displayed or not.
 - 2) TV : Select input TV and check below item.(In Gumi factory)
 - C05(E05) – Check TELETEXT Function (Applicable to the model that has Teletext code set-up item in Product spec)
 - C07(E07) – Check Nicam DUAL
 - C52 (E52) – Check Nicam Stereo
 - * Refer to “6.Preset CH information”

4.4. Power consumption confirmation

- (1) Check if Power LED Color and Power Consumption operate as standard.
- (2) Measurement Condition : 230V~, 50Hz (Analog)
- (3) Confirm Stand-by operation.

4.5. Outgoing condition Configuration

- (1) After all function test, press IN-STOP Key by Service Remote control. And make outgoing condition.
- (2) When pressing IN-STOP key by service remote control, LED is power off in a little time and then automatically LED is changed the stand-by status(RED Color).(Must not AC power OFF at that time)

4.6. Option data setting (SVC OSD setting)

- Tool Option		20LS5R-ZA	REMARK
		8 9 6	
Resolution		0	
Module		0	
TV		1	
SCART		1	
AV2		1	
COMPONENT		0	
PC-RGB		0	
DVI		0	
HDMI		0	
- Area Option [A B]			
(A) 0 : FACTORY MODE OFF 1 : FACTORY MODE ON [Caution] FACTORY MODE ON only used in factory.			
(B) 0: default Option setting. 1~4: The other Area Option setting.(Reserved) [Caution] Initial Setting of Area Option is [1 0] in production line. After IN-STOP, Area Option will change [0 0]. If Area Option isn't 00 after IN-STOP, must change to 00. (Using ► key on R/C)			
No	Item	Condition	Remark
OPTION 1 [6]			
1	200PR	0	0 : 200 PR Off 1 : 200 PR On
2	ACMS	1	0 : ACMS Off 1 : ACMS On
3	TEXT	1	0 : TOP 1 : FLOF
4	CH+AU	0	0 : Except below area 1 : China, Australia
5	BOOSTER	0	
OPTION 2 [2]			
1	SYS	0	0 : BG//DK/L 1 : BG//DK/M
2	A2 ST	1	Acting FM-ST after checking Nicam
3	I II SAVE	0	0 : I II SAVE Off 1 : I II SAVE On
4	HDEV	0	0 : Except below area 1 : China
5	V-Curve	0	0 : Turbo Volume Off 1 : Turbo Volume On
6	MONO	0	
OPTION 3 [2]			
1	KEY-TYPE	2	2 : 8Key
OPTION 4 [3]			
1	Default Lang	3	
2	Lang	0	Chesky Dansk Deutsch English Español Français Italiano Magyar Nederlands Norsk Polski Português Romaneste Suomi Svenska
3	T- Lang	0	AUSTRIA NORWAY BULGARIA POLAND CROATIA PORTUGAL CZECH RUMANIA DENMARK RUSSIA ENGLAND SERBIA ESTONIA SLOVAKIA FINLAND SLOVENIA FRANCE SPAIN GERMANY SWEDEN GREECE SWITZERLAND HUNGARY TURKEY ITALY ARAB LATVIA HEBREW NETHERLANDS Others
OPTION 5 [9]			
1	2HR-OFF	1	0 : 2 Hour off option -OFF 1 : 2 Hour off option -ON
2	TV-LINK-TUNER	0	
3	FACTORY-MODE	0	0 : EEPROM Write Protection On 1 : EEPROM Write Protection Off
4	CHANNEL-MUTE	1	0 : Channel Mute Off 1 : Channel Mute On


5. Adjustment Command

5.1. Adjustment Command (LENGTH=84)

No.	Adjustment Contents	CMD(hex)	ADR	VAL	Description
1	EEPROM ALL INIT.	E4	00	00	EEPROM all clear
2	EEPROM Read	E7	00	00	EEPROM Read
3	EEPROM Write	E8	00	data	EEPROM Write by some values
4	COLOR SAVE (R/G/B cutoff, Drive, Contrast, Bright)	EB	00	00	Color Save
5	H POSITION	20	00	00 – 100	They have different range each mode, FOS Adjustment
6	V POSITION	30	00	00 – 100	
7	CLOCK	90	00	00 – 100	
8	PHASE	92	00	00 – 100	
9	R DRIVE	16	00	00 – FF	Drive adjustment
10	G DRIVE	18	00	00 – FF	
11	B DRIVE	1A	00	00 – FF	
12	R CUTOFF	80	00	00 – 7F	Offset adjustment
13	G CUTOFF	82	00	00 – 7F	
14	B CUTOFF	84	00	00 – 7F	
15	BRIGHT	10	00	00 – 3F	Bright adjustment
16	CONTRAST	12	00	00 – 64	Luminance adjustment
17	AUTO_COLOR_ADJUST	F1	00	02	Auto COLOR Adjustment
18	CHANGE_COLOR_TEMP	F2	00	0, 1, 2, 3	0: COOL 1: NORMAL 2: WARM 3: USER
19	FACTORY_DEFAULT	F3	00	00	00: Factory mode Off FF: Factory mode On
20	AUTO_INPUTCHANGE	F4	00	00	0: TV 1: AV1 2: AV2 3: Component 4: RGB 5: DVI

5.2. EEPROM DATA READ

(1) Signal Table




(2) Command Set

Adjustment Contents	CMD(hex)	ADR(hex)	ADL(hex)	Details
EEPROM READ	E7	A0	0	0-Page 0~7F Read
			80	0-Page 80~FF Read
		A2	0	1-Page 0~7F Read
			80	1-Page 80~FF Read
		A4	0	2-Page 0~7F Read
			80	2-Page 80~FF Read
		A6	0	3-Page 0~7F Read
			80	3-Page 80~FF Read

Purpose : To read the appointment Address of E2PROM by 128(80h)-byte

5.3. E²PROM Data Write

(1) Signal Table



LEN : 84h+Bytes
 CMD : 8Eh
 ADH : E²PROM Slave Address(A0,A2,A4,A6,A8), Not 00h(Reserved by BufferToEEPROM)
 ADL : E2PROM Sub Address(00~FF)
 Data : Write data

(2) Command Set


No.	Adjustment contents	CMD(hex)	LEN	Details
1	EEPROM WRITE	E8	94	16-Byte Write
2			84+n	n-byte Write

<Purpose>


- 1) EDID write : 16-byte by 16-byte, 8 order (128-byte) write (TO "00 – 7F" of "EEPROM Page A4")
- 2) FOS Default write : 16-mode data (HFh, HFI, VF, STD, HP, VP, Clk, ClkPh, PhFine) write
- 3) Random Data write : write the appointment Address of E2PROM

5.4. VRAM Read

- 1) Send CMD(70h) to read Video RAM value from MICOM And save its value to 128-Bytes Buffer(Common Buffer for the use of EDID).




- 2) Delay 500ms(Time to wait and read vZideo RAM from MICOM)
- 3) Be transmitted the contents of MICOM's 128-bytes Buffer to PC.(128th Data is the CheckSum of 127-bytes data : That's OK if the value of adding 128-bytes Data is Zero)





6. Preset CH information


		PIF[MHz]	SYSTEM	VIDEO	SOUND		TXT	NAME
					System	Mode		
LGE Gumi	PR 0	575.25	SECAM-DK	DIGITAL		DUAL		C 34
	PR 1	45.25	PAL-BG	PHILIPS		MONO		C 01
	PR 2	175.25	PAL-BG	PHILIPS		STEREO	FLOF	C 05
	PR 3	231.25	PAL-I	FUBK		MONO		S 11
	PR 4	62.25	SECAM-BG	PHILIPS		DUAL		C 04
	PR 5	189.25	PAL-BG	Crosshatch		DUAL		C 07
	PR 6	703.25	PAL-BG	RGB, WHITE	NICAM	MONO	FLOF	C 50
	PR 7	719.25	PAL-BG	MATRIX C/B		STEREO		C 52
	PR 8	631.25	PAL-I	PHILIPS	NICAM	STEREO		C 41
	PR 9	807.25	PAL-I	Crosshatch	NICAM	STEREO		C 63
	PR 10	55.75	PAL-L	Crosshatch		MONO		C 02
	PR 11	152.75	PAL-L	PHILIPS	NICAM	DUAL		S 07
PR 12	591.25	PAL-L	Colorbar	NICAM	STEREO		C 36	
LGEMA	PR 13	175.25	PAL-B	Crosshatch+Circle	NICAM	DUAL	FLOF	C 05
	PR 14	711.25	PAL-G	DIGITAL	NICAM	STEREO	FLOF	C 51
	PR 15	631.25	PAL-I	Crosshatch	NICAM	STEREO	FLOF	C41
	PR 16	93.25	SECAM-D	DIGITAL		MONO		C 05
	PR 17	62.25	PAL-B	Crosshatch	A2	STEREO		C 04
	PR 18	551.25	PAL-G	Colorbar	A2	DUAL	TOP	C 31
	PR 19	471.25	PAL-I	DIGITAL		STEREO	FLOF	C 21
	PR 20	855.25	PAL-I	DIGITAL		MONO	FLOF	C 69
	PR 21	687.25	NTSC-M	DIGITAL		MONO		C 08
	PR 22	200.25	SECAM-L	DIGITAL	NICAM	DUAL		C 45
	PR 23	663.25	SECAM-L	Crosshatch(16:9)		MONO	FLOF	C 25
	PR 24	189.25	PAL-B			STEREO		C 07
	PR 25	327.25	NTSC-M		A2	STEREO	FLOF	S 24
	PR 26	615.25	PAL-B		NICAM	STEREO	FLOF	C 39
	PR 27	535.25	PAL-BG		NICAM	STEREO		C 29
LGEWA	PR 28	45.25	PAL-BG	Monoscope		MONO	FLOF	C 01
	PR 29	575.25	PAL-DK	Monoscope	NICAM	STEREO	FLOF	C 34
	PR 30	175.25	PAL-BG	SMPTE		MONO		C 04
	PR 31	231.25	PAL-I	Colorbar	NICAM	DUAL		S 11
	PR 32	62.25	PAL-BG	White Raster		MONO		C 04
	PR 33	703.25	SECAM-DK	White Raster		MONO		C 50
	PR 34	719.25	PAL-BG	Crosshatch+Circle		MONO		C 52
	PR 35	591.25	SECAM-L	Colorbar	NICAM	STEREO		C 36
LGENT	PR36	175.25	PAL-B/G	Philips	1Khz			C 05
	PR 37	503.25	PAL-B/G	Color Bar (2)	Ger, Stereo 1K,3Khz		FLOF	C 25
	PR 38	623.25	PAL-B/G	Monoscope	Sweep			C 40
	PR 39	49.75	SECAM D/K	Color Bar(2)	400Hz			C 01
	PR 40	200.25	PAL-D/K	Color Bar	Sweep			C 10
	PR 41	695.25	PAL-D/K	Philips	CHI Dual 1K, 3Khz		FLOF	C 36

TROUBLESHOOTING










BLOCK DIAGRAM



BLOCK DIAGRAM DESCRIPTION

Power Supply Block (LIPS)

This Block Generates DC Voltage (5V,15V) to Main Control system from AC Power (100-240 V, 50/60 Hz, 1.0A)
Also it has the inverter function that converts input voltage to AC Rms value for the LCD lamp.

Voltage Regulator

Voltage regulator convert the input 5V,15V to proper 1.8V, 3.3V, 5V, 12V for Main control system.
For shooting heat trouble, we use the voltage regulator IC.

Digital Audio Amplifier

This block is composed of YDA138-EZ and peripheral device
The function of the audio amplifier is that to amplify audio L / R signal transmitted from audio decoder. The audio signal is amplified according to pre-defined DC volume control curve.

Audio / Video Decoder / Scaler

This block is composed of LGE9655 and peripheral devices.

1) Video Decoder

This Block Selects input Video signals (like CVBS, Y/C, SCART RGB) and output LVDS/ TTL signal through Scaler.

On decoding, We can control signal like Contrast, Brightness, Sharpness, Color, tint signals including Adaptive Comb Filter.

2) Audio Decoder

This block analyzes audio input signal through A/V Jack (and PC audio) and Tuner SIF.
The analyzed signals transmitted to audio amplifier.

On decoding, We can control signal like Bass, treble.

3) Scaler

This IC includes A/D Converter and LVDS Transmitter

This IC is directly Inputted Analog Signal and transmits it to LCD Module

4) Micom

This block controls each IC through IIC communication line.

DAC IC (CS4352)

It is composed of CS4352.

The CS4352 is a complete stereo digital-to-analog system including digital interpolation, fifth-order multi-bit delta-sigma digital-to-analog conversion, digital de-emphasis, analog filtering, and on-chip 2 Vrms line-level driver.


TUNER


Micom controls this through IIC Line.

TUNER makes CVBS/SIF and transmits CVBS/SIF signal to LGE9655.



MEMO

EXPLODED VIEW











THE Δ SYMBOL MARK OF THIS SCHEMATIC DIAGRAM INCORPORATES SPECIAL FEATURES IMPORTANT FOR PROTECTION FROM X-RADIATION, FILTRATION AND ELECTRICAL SHOCK HAZARDS. WHEN SERVICING IF IS ESSENTIAL THAT ONLY MANUFACTURERS SPECIFIED PARTS BE USED FOR THE CRITICAL COMPONENTS IN THE Δ SYMBOL MARK OF THE SCHEMATIC.



THE Δ SYMBOL MARK OF THIS SCHEMATIC DIAGRAM INCORPORATES SPECIAL FEATURES IMPORTANT FOR PROTECTION FROM X-RADIATION, FILTRATION AND ELECTRICAL SHOCK HAZARDS. WHEN SERVICING IF IS ESSENTIAL THAT ONLY MANUFACTURERS SPECIFIED PARTS BE USED FOR THE CRITICAL COMPONENTS IN THE Δ SYMBOL MARK OF THE SCHEMATIC.







P/NO : MFL37159905

Feb., 2007
Printed in Korea

