


# Service Manual

## Colour Television



### TX-29E220T

GP2 Chassis

## Specification

Power Source	AC AUTO 220-240V, 50/60 Hz	Sound	33.57 MHz (PAL) /
Power Consumption	164 W	Colour	33.6 MHz (SECAM)
	Standby condition : 7 W		34.42 MHz (NTSC) /
Aerial Terminal	Impedance : 75Ω, Coaxial type		33.75 MHz (SECAM)
Tuning System	<b>Frequency Synthesizer</b>	Video/Audio/Terminals	
	Auto Search Tuning	AV 1, 2, 3, 4	S-Video In
	Pos : 100 Positions		Y:1 Vp-p, 75Ω
Receiving System	21 Systems		C:0.3 Vp-p, 75Ω
Receiving Channels	Regular TV	DVD	
VHF BAND	0-12 (PAL/SECAM B, K1)	Y	1.0Vp-p, 75Ω
	0-12 (PAL B AUST.)	P <sub>B</sub>	0.7Vp-p, 75Ω
	1-9 (PAL B N.Z.)	P <sub>R</sub>	0.7Vp-p, 75Ω
	1-12 (PAL/SECAM D)	Video In	1Vp-p, 75Ω
	1-12 (NTSC M JAPAN)	Audio In	Approx. 0.5V, 47KΩ
	2-13 (NTSC M U.S.A.)	Monitor Out	
UHF BAND	21-69 (PAL G, H, I/SECAM G, K, K1)	Video In	1Vp-p, 75Ω
	28-69 (PAL B AUST.)	Audio In	Approx. 0.5V, 47KΩ
	13-57 (PAL D, K)	High Voltage	31.0 ± 1.0 at zero beam current
	13-62 (NTSC M JAPAN)		
	14-69 (NTSC M U.S.A.)	Picture Tube	A68LZU185X Type 29 (68 cm)
CATV	S1-S20 (OSCAR)		Measured diagonally
	1-125 (U.S.A. CATV)		104° deflection
	C13-C49 (JAPAN)	Audio Output	20 W speaker
	S21-S41 (HYPER)	Dimensions (W x D x H)	757 mm x 514 mm x 576 mm
	Z1-Z37 (CHINA)	Weight (Mass)	42.5 kg (Net)
	5A, 9A (AUST.)		
Intermediate Frequency	38.0 MHz		
Video	31.5 MHz (D, K) / 32.5 MHz (B, G)	<b>Note:</b>	
	32.0 MHz (I) / 32.5 MHz (M)		

# Panasonic®

© 2005 Matsushita Electric Industrial Co., Ltd. All rights reserved. Unauthorized copying and distribution is a violation of law.

Specifications are subject to change without notice. Mass and dimensions shown are approximate.

## **WARNING**

This service information is designed for experienced repair technicians only and is not designed for use by the general public. It does not contain warnings or cautions to advise non-technical individuals of potential dangers in attempting to service a product. Products powered by electricity should be serviced or repaired only by experienced professional technicians. Any attempt to service or repair the product or products dealt with in this service information by anyone else could result in serious injury or death.

# CONTENTS

	Page		Page
<b>1 Safety Precautions</b> .....	<b>3</b>	4.4. White Balance (Market Mode CHK 4) .....	9
1.1. General Guide .....	3	4.5. Adjustment of CRT VRS .....	10
1.2. Leakage Current Cold Check .....	3	<b>5 Conductor Views</b> .....	<b>11</b>
1.3. Leakage Current Hot Check (See Fig. 1) .....	3	<b>6 Schematic Diagrams</b> .....	<b>12</b>
1.4. X-Radiation .....	3	6.1. Schematic Diagram for GP2 Chassis .....	12
1.5. GP2 Block Diagram .....	4	6.2. D Board .....	14
<b>2 Service Hints</b> .....	<b>5</b>	6.3. G Board .....	21
2.1. How to move chassis into service position .....	5	6.4. L Board .....	24
<b>3 Market Mode Function</b> .....	<b>6</b>	6.5. A Board .....	28
<b>4 Adjustment Procedure</b> .....	<b>7</b>	<b>7 Parts Location</b> .....	<b>35</b>
4.1. Adjustment Procedure .....	7	<b>8 Replacement Parts List</b> .....	<b>36</b>
4.2. Colour Purity .....	8	8.1. Replacement Parts List .....	37
4.3. Convergence .....	8		

# 1 Safety Precautions

## 1.1. General Guide

1. It is advisable to insert an isolation transformer in the AC supply before servicing a hot chassis. Fig. 1.




Fig. 1

2. When servicing, observe the original lead dress, especially the lead dress in the high voltage circuits. If a short circuit is found, replace all parts which have been overheated or damaged by the short circuit.
3. After servicing, observe that all the protective devices such as insulation barriers, insulation papers, shields, and isolation R-C combinations, are properly installed.
4. When the receiver is not to be used for a long period of time, unplug the power cord from the AC outlet.
5. Potential, as high as **32kV** is present when this receiver is in operation. Operation of the receiver without the receiver power supply. Servicing should not be attempted by anyone who is not thoroughly familiar with the precautions necessary when working on high voltage equipment. Always discharge the anode of the picture tube to the receiver chassis before handling the tube.

After servicing make the following leakage current checks to prevent the customer from being exposed to shock hazards.

## 1.2. Leakage Current Cold Check

1. Unplug the AC cord and connect a jumper between the two prongs on the plug. Fig. 2.




Fig. 2

2. Turn on the receiver's power switch.
3. Measure the resistance value, with an ohmmeter, between the jumpered AC plug and each exposed metallic cabinet part on the receiver, such as screw heads, arials, connectors, control shafts, etc. When the exposed metallic part has a return path to the chassis, the reading should be between **4MΩ and 20MΩ**. When the exposed metal does not have a return path to the chassis, the reading must be zero.

## 1.3. Leakage Current Hot Check (See Fig. 1)

1. Plug the AC cord directly into the AC outlet. Do not use an isolation transformer for this check.
2. Connect a  $2\text{ k}\Omega$ , 10 W resistor in series with an exposed metallic part on the receiver and an earth such as a water pipe.
3. Use an AC voltmeter, with high impedance type, to measure the potential across the resistor.
4. Check each exposed metallic part, and measure the voltage at each point. Fig. 3.




Fig. 3

5. Reverse the AC plug in the AC outlet and repeat each of the above measurements.
6. The potential any point should not exceed **1.0V rms**. In the case of a measurement being outside of the limits specified, there is a possibility of a shock hazard, and the receiver should be repaired and re-checked before it is returned to the customer. Fig. 4.




Fig. 4

## 1.4. X-Radiation


Warning :

1. The potential sources of X-Radiation in TV sets are the EHT section and the picture tube.
2. When using a picture tube test rig for service, ensure that the rig is capable of handling **30 kV** without causing X-Radiation.

**Note:** It is important to use an accurate periodically calibrated high voltage meter.

1. Set the brightness to minimum.
2. Measure the High Voltage. The meter reading should indicate **31.0 ± 1.0kV**. If the meter indication is out of tolerance, immediate service and correction is required to prevent the possibility of premature component failure.
3. To prevent the possibility of X-Radiation, it is essential to use the specified picture tube.


## 1.5. GP2 Block Diagram




## 2 Service Hints

### 2.1. How to move chassis into service position


1. Remove 9 screws.



2. Draw out Main Chassis.



3. Stand the Main Chassis.



### 3 Market Mode Function

#### Outline:

MPU controls the functions switching for each ICs through IIC bus in this chassis. The following setting and adjustment can be adjusted by remote control in Market Mode.

#### 1. Selection of Market Mode

Adjust the VOLUME “zero” and set OFF TIMER Button to 30 min. Then, simultaneously press the RECALL Button on the remote control and the VOLUME DOWN button - the TV set.

#### 2. Selection of Service Mode

Press green button to select for adjustment mode, to adjust press yellow or blue button.

#### 3. Set to normal mode

Press the volume down button on front control, together press the off timer button on remote control.

#### a. Service 1

H-Pos ..... 33

V-pos ..... -19

H-Pos ..... -17

V-Amp ..... 6

Ew-AMP ..... 6

Lower Corner ..... 20

Trapez 1 ..... -2

Upper Corner ..... 15

V-Lin ..... -8

V-Sym ..... 56

Angle ..... 2

Bow ..... -4

DVCO ..... 3

#### b. HIGH ..... 0327, 0323, 0324

#### c. LOW ..... 0173, 0204, 0232

Sub Brightness 67

## 4 Adjustment Procedure

### 4.1. Adjustment Procedure

#### 4.1.1. +B Voltage

##### Item / preparation

1. Operate the TV set.
2. Set control as follows :  
Brightness ..... minimum  
Contrast ..... minimum

##### Adjustment procedure

1. Confirm the DC voltage at the indicated test points, as follows :  
TPD 2 :  $144.8 \pm 1V$   
TPD 21 :  $10.5V \pm 1V$   
TPD 3 ~ TPD 4 :  $33V \pm 3V$

#### 4.1.2. RF AGC

##### Item / preparation

1. Receive a colour bar signal at an RF level of 69 +1-2 dBu with  $75\Omega$  loaded.
2. Connect digital multimeter to RF AGC at Tuner.

##### Adjustment procedure

1. Select "RF AGC" indication in CHK2, on Screen by remote control at factory mode.
2. Set RF AGC by using remote control Volume (+) or Volume (-) button until voltage AGC at Tuner reaches  $2.6 \pm 0.1V$  at TPA 15 (Tuner point).
3. Increase RF signal strength by 2dB, confirm AGC at Tuner voltage drop.

#### 4.1.3. High Voltage

##### Item / preparation

1. Receive the crosshatch pattern.
2. Set to 0 Beam.  
Screen VR ..... minimum  
Contrast ..... minimum

##### Adjustment procedure

1. Connect a DC voltage meter to TPD 2 and confirm the +B voltage is  $144.8 \pm 1V$ .
2. Connect a high frequency voltmeter to heater and confirm that voltage reads  $6.3 \pm 0.24$  (VRMS).
3. Normalize the brightness and contrast.

#### 4.1.4. NTSC TINT COLOUR

##### Item / preparation

1. Connect oscilloscope probe to TPL1 (R OUT) with  $10k\Omega$  series resistor.
2. Press Main Menu and set system to use AV-NTSC (3.58 MHz).  
DYNAMIC ..... Normal  
Channel CLR Set ..... STD

##### Adjustment procedure

1. Adjust Sub-Tint so that No. 2, 3 and 4 becomes level waveform is similar to Fig. 3.
2. Confirm phase at Tint is changes more than  $\pm 15$  by Tint control.
3. Confirm that colour level is maximum when colour DAC is adjusted to maximum position.

**Note:** Use remote control only when adjusting user mode to Sub-Tint.






Fig. 3

## 4.2. Colour Purity


1. Set Bright and Contrast controls to their maximum positions.
2. Operate the TV set over 60 minutes.
3. Full degauss the picture tube by using an external degaussing coil. By rotating R-B static convergence magnet.
4. Apply a crosshatch pattern signal and adjust roughly the static convergence magnets.
5. Apply a green pattern signal.
6. Loosen a clamp screw for the Deflection Yoke and move the Deflection Yoke as close to the purity magnet as possible.
7. Adjust the purity magnet so that a vertical green field is obtained at the center of the screen.



8. Slowly press the Deflection Yoke and set it where a uniform green field is obtained.




9. Adjust roughly the Low Light controls and make sure that a uniform white field is obtained.
10. Tighten the clamp screw.




## 4.3. Convergence

1. Apply a crosshatch pattern signal and set Contrast control to the maximum position.
2. Adjust Bright control to obtain a clear pattern.
3. Adjust Red and Blue line at center of the screen.



4. Adjust Red and Blue with Green line at center of the screen by rotating (RB)-G static convergence magnet.
5. Lock convergence magnets with silicone sealer.
6. Remove the DY wedges and slightly tilt the Deflection Yoke vertically.



7. Fix the Deflection Yoke by re-inserting the DY wedges.
8. If purity error is found, repeat "Colour Purity" adjustment.



## 4.4. White Balance (Market Mode CHK 4)

### Preparation

1. Receive a colour bar signal with colour "OFF", and operate the TV set for more than 30 minutes.
2. Set the picture menu to "DYNAMIC NORMAL" and the AI to off.
3. Connect an oscilloscope to TPL5 with DC mode.
4. Set the TV set to Market Mode : white balance adjustment (CHK 4).
5. Screen VR : Min.
6. Set the data level of RGB CUT OFF / DRIVE and SUB BRIGHT.  
Display : Data Level  
R-CUT OFF : 63  
G-CUT OFF : 128  
B-CUT OFF : 63  
R-DRIVE : 128  
B-DRIVE : 128  
SUB BRIGHT : 63

### Adjustment

1. Select G-CUTOFF adjustment mode and collapse vertical scan.
2. Adjust G-CUTOFF control to become the DC=0 V to video level at 180 V as shown in Fig. 1.





Fig. 1


3. Slowly turn the screen control clockwise until a green colour horizontal line appears on the picture tube. This is the setting point for the screen control.

Note:

Do not adjust the G-CUTOFF setting in the following procedure.



4. Adjust the remaining R and B-CUTOFF controls so as to get a white horizontal line on the screen.



5. Return to full field SCAN by pushing the position 5 key on the remote control.
6. Adjust the R-Drive and B-Drive controls as to obtain a uniform white on the white bar of the greyscale pattern.
7. Confirm correct B/W rendition and greyscale tracking or repeat CUTOFF and drive control setup.

### Note:

Write down the original value for each address adjustment before adjusting anything.




Fig. 2

8. Wedge A shown in Fig. 2 should be fixed within a range of 45° to the left of the vertical line as shown.
9. After inserting wedge A, insert wedges B, C and D. The wedges should be set 90° apart from each other.
10. Be certain that the four wedges are firmly fixed and the Deflection Yoke is tightly clamped in place otherwise the Deflection Yoke may shift its position and cause a loss of convergence and purity.

## 4.5. Adjustment of CRT VRS

**NOTE: FOR FLAT CRT ONLY**

### PREPARATION

1. Set DY to CRT not to tilt up and down left and right deflection.
2. Set CY to CRT and set CY magnet primarily.  
 Pur Mg : Set Pur Mg that 2 magnets are (top position)  
 VRS Mag : Set VRS Mg that 2 magnets are (horizontal position) only 21", 25" & 29"
3. Set geomagnetic corection DAC. AS IN TABLE 1.

### ADJUSTMENT

1. Receive the white balance pattern.
2. Adjust V-CENTER.
3. Set R, B CUT OFF to minimum, and set G CUT OFF to center.
4. Receive the aging pattern.
5. Set 2 magnet of vertical position to up and down equally so that center part of CRT (Fig 4)

	MANUAL	AUTO
DAC	0	1

TABLE 1




FIG. 3





FIG. 4

# 5 Conductor Views



## 6 Schematic Diagrams

### 6.1. Schematic Diagram for GP2 Chassis

#### Important Safety Notice

Components identified by  $\triangle$  mark have special characteristics important for safety.  
When replacing any of these components, use only manufacturer's specified parts.

#### Notes:

##### 1. Resistor

All resistors are carbon 1/4W resistor, unless marked as follows:

Unit of resistance is OHM [ $\Omega$ ] (K=1,000, M=1,000,000).

$\bigcirc$	: Nonflammable	$\boxtimes$	: Metal Oxide
$\triangle$	: Solid	$\odot$	: Metal Film
$\boxplus$	: Wire Wound	$\otimes$	: Fuse

##### 2. Capacitor

All capacitors are ceramic 50V capacitor, unless marked as follows:

Unit of capacitance is  $\mu$ F, unless otherwise noted.

$\otimes$	: Temperature Compensation	$\begin{array}{c} + \\ \text{---} \text{H} \text{---} \\ \text{---} \end{array}$	: Electrolytic
$\textcircled{M}$	: Polyester	$\begin{array}{c} \text{NP} \\ \text{---} \text{H} \text{---} \\ \text{---} \end{array}$	: Bipolar
$\textcircled{m}$	: Metalized Polyester	$\textcircled{1}$	: Dipped Tantalum
$\boxtimes$	: Polypropylene	$\textcircled{Z}$	: Z-Type

##### 3. Coil

Unit of inductance is  $\mu$ H, unless otherwise noted.

##### 4. Test Point

$\bigcirc$  : Test Point position

##### 5. Earth Symbol

$\text{---} \text{H} \text{---}$  : Chassis Earth (Cold)  $\downarrow$  : Line Earth (Hot)

##### 6. Voltage Measurement

Voltage is measured by a DC voltmeter.

Conditions of the measurement are the following:

Power Source ..... AC 110-240 V, 50/60 Hz

Receiving Signal ..... Colour Bar signal (RF)

All customer's controls ..... Maximum positions

##### 7. Number in red circle indicates waveform number.

(See waveform pattern table.)

##### 8. When arrow mark ( $\nearrow$ ) is found, connection is easily found from the direction of arrow

##### 9. Indicates the major signal flow. $\Rightarrow$ : Video $\Rightarrow$ : Audio


##### 10. This schematic diagram is the latest at the time of printing and subject to change without notice.

**Remarks:**


1. The Power Circuit contains a circuit area which uses a separate power supply to isolate the earth connection.  
The circuit is defined by HOT and COLD indications in the schematic diagram. Take the following precautions.  
All circuits, except the Power Circuit, are cold.  
Precautions
  - a. Do not touch the hot part or the hot and cold parts at the same time or you may be shocked.
  - b. Do not short-circuit the hot and cold circuits or a fuse may blow and parts may break.
  - c. Do not connect an instrument, such as an oscilloscope, to the hot and cold circuits simultaneously or a fuse may blow.  
Connect the earth of instruments to the earth connection of the circuit being measured.
  - d. Make sure to disconnect the power plug before removing the chassis.
2. Following diodes are interchangeable.  
MA150- MA162 (Replacement part)

## 6.2. D Board


### 6.2.1. D Board (1/7)



## 6.2.2. D Board (2/7)




## 6.2.3. D Board (3/7)







#### 6.2.4. D Board (4/7)




## 6.2.5. D Board (5/7)



### 6.2.6. D Board (6/7)




6.2.7. D Board (7/7)




## 6.3. G Board


### 6.3.1. G Board (1/3)



### 6.3.2. G Board (2/3)




### 6.3.3. G Board (3/3)




## 6.4. L Board

### 6.4.1. L Board (1/4)







## 6.4.2. L Board (2/4)



## 6.4.3. L Board (3/4)




## 6.4.4. L Board (4/4)




## 6.5. A Board


### 6.5.1. A Board (1/7)




### 6.5.2. A Board (2/7)




### 6.5.3. A Board (3/7)



## 6.5.4. A Board (4/7)




### 6.5.5. A Board (5/7)






### 6.5.6. A Board (6/7)




### 6.5.7. A Board (7/7)



## 7 Parts Location

### PARTS LOCATION

Note: The number on mechanical parts indicates Ref. No. of Replacement Parts List.



## 8 Replacement Parts List

## Important Safety Notice

*Components identified by  $\Delta$  mark have special characteristics important for safety. When replacing any of these components, use only manufacturer's specified parts.*

**RTL (Retention Time Limited)**

**Note:** Printed circuit board assembly with “NLA” is no longer available after production discontinuation of the complete set.

Abbreviation of part name and description

### 1. Resistor

Example:

ERD25TJ104    C 100KOHM, J, 1/4W

Type	Allowance
------	-----------

## 2. Capacitor

Example:

ECKF1H103ZF    C    0.01UF, Z,    50V

                         Type                    Allowance

Type	Allowance
C : Carbon	F : $\pm 1\%$
F : Fuse	G : $\pm 2\%$
M : Metal Oxide	J : $\pm 5\%$
Metal Film	K : $\pm 10\%$
S : Solid	M : $\pm 20\%$
W : Wire Wound	

Type	Allowance
C : Ceramic	C : $\pm 0.25\text{pF}$
E : Electrolytic	D : $\pm 0.5\text{pF}$
P : Polyester	F : $\pm 1\text{pF}$
Polypropy- lene	G : $\pm 3\text{pF}$
T : Tantalum	J : $\pm 5\text{pF}$
	K : $\pm 10\text{pF}$
	L : $\pm 15\text{pF}$
	M : $\pm 20\text{pF}$
	P : +100%, -0%
	Z : +80%, -20%

## 8.1. Replacement Parts List

Ref. No.	Part No.	Part Name & Description	Remarks
1	A68LZU185X-D	PICTURE TUBE	△
2	EASG15S509A2	SPEAKER	
3	KDY4UWH11F	DEFLECTION YOKE	△
	KRCBC160928B	CORE CLAMPER	
	N2QAJB000107	REMOTE CONTROL	
4	TBM4G1274	MODEL NAME PLATE	△
5	TBM4G3013	PANASONIC BADGE	
6	TBX4G90600	POWER BUTTON	
	TES4G406	COIL SPRING	
	TJB1726400	75OHM ADAPTOR	
	TKP4G13071	REAR AV BRACKET	
7	TKU4GA2111-1	BACK COVER	
8	TLCA005	CONVERGENCE YOKE	△
9	TLK4G9081X	DEGAUSSING COIL	△
10	TLK4G9083X	ROTATION COIL	△
11	TMM4G503	RUBBER WEDGE	
	TMM4G902-3	RUBBER WASHER	
NLA	TNP4G293BB	D BOARD	△
NLA	TNP4G294AM	G BOARD	△
NLA	TNP4G295AA	L BOARD	△
NLA	TNP4G335AQ.A	A BOARD	△
	TPD4G1167-1	CUSHION (TOP)	
	TPD4G2146	CUSHION (BOTTOM)	
	TPE4G14038	SET COVER	
	TQB4G3926	FAN BAG	
	TSMA011	MAGNET	
	TSN63115-4	PURITY MAGNET	
	TSX4G190L	AC POWER CORD	△
12	TXFKP01DR11	DOOR PANEL ASSY	
13	TXFKY05DR10	CABINET ASSY	
	TXFPC01DR10	CARTON	
	CAPACITORS		
C1002	ECA1CM101B	E 100UF, 16V	
C1003	ECUX1H104KBX	C 0.1UF, K, 50V	
C1004	ECJ2FB1E105K	C 1UF, K, 25V	
C1007	ECJ2VC1H270J	C 27PF, J, 50V	
C102	ECA0JM471B	E 470UF, 6.3V	
C103	ECJ2VF1H103Z	C 0.01UF, Z, 50V	
C109	ECJ2FB1H104K	C 0.1UF, K, 50V	
C110	ECJ2VB1H103K	C 0.01UF, K, 50V	
C1101	ECJ2VF1E104Z	C 0.1UF, Z, 25V	
C1102	ECEA1AKA101	E 100UF, 10V	
C1103	ECJ2VF1E104Z	C 0.1UF, Z, 25V	
C1104	ECEA1AKA101	E 100UF, 10V	
C1105	ECJ4YB0J476M	C 47UF, J, 6.3V	
C1106	ECJ4YB0J476M	C 47UF, J, 6.3V	
C1107	ECUX1H220JCX	C 22PF, J, 50V	
C1108	ECUX1H220JCX	C 22PF, J, 50V	
C1109	ECJ2VB1H103K	C 0.01UF, K, 50V	
C111	ECA1HMR33B	E 0.33UF, 50V	
C1111	ECJ1VF1E104Z	C 0.1UF, Z, 25V	
C1112	ECUX1H151JCX	C 150PF, J, 50V	
C1114	ECJ1VF1H103Z	C 0.01UF, Z, 50V	
C1115	ECJ1VB1H472K	C 4700PF, K, 50V	
C1116	ECJ2VF1E104Z	C 0.1UF, Z, 25V	
C1119	ECJ2VF1E104Z	C 0.1UF, Z, 25V	
C1120	ECJ2VF1E104Z	C 0.1UF, Z, 25V	
C1121	ECJ2VF1E104Z	C 0.1UF, Z, 25V	
C1122	ECJ2VF1E104Z	C 0.1UF, Z, 25V	
C1123	ECJ2VF1E104Z	C 0.1UF, Z, 25V	
C1124	ECJ2VF1E104Z	C 0.1UF, Z, 25V	
C1125	ECJ2VF1E104Z	C 0.1UF, Z, 25V	
C1126	ECJ1VC1H101J	C 100PF, J, 50V	
C1127	ECJ2VF1E104Z	C 0.1UF, Z, 25V	
C1130	ECEA1EKS4R7	E 4.7UF, 25V	
C1131	ECEA1EKS4R7	E 4.7UF, 25V	
C1132	ECEA1EKS4R7	E 4.7UF, 25V	
C117	ECJ2VB1H103K	C 0.01UF, K, 50V	
C118	ECJ2VF1H104Z	C 0.1UF, Z, 50V	
C119	ECA1CM221B	E 220UF, 16V	
C122	ECJ2FB1H104K	C 0.1UF, K, 50V	

Ref. No.	Part No.	Part Name & Description	Remarks
C125	ECJ2VC1H331J	C 330PF, J, 50V	
C126	ECJ2VC1H561J	C 560PF, J, 50V	
C130	ECJ2VB1H103K	C 0.01UF, K, 50V	
C131	ECJ2VB1C104K	C 0.1UF, K, 16V	
C137	ECJ2VC1H560K	C 56PF, K, 50V	
C138	ECJ2VC1H560K	C 56PF, K, 50V	
C1501	ECJ2VC1H150J	C 15PF, J, 50V	
C1502	ECJ2VC1H150J	C 15PF, J, 50V	
C1503	ECJ2VF1E104Z	C 0.1UF, Z, 25V	
C1504	ECJ1VF1H104Z	C 0.1UF, Z, 50V	
C1505	ECJ1VF1H104Z	C 0.1UF, Z, 50V	
C1506	ECJ2VF1E104Z	C 0.1UF, Z, 25V	
C1507	ECJ2VF1E104Z	C 0.1UF, Z, 25V	
C1508	ECJ1VF1H104Z	C 0.1UF, Z, 50V	
C1509	ECJ1VB1H103K	C 0.01UF, K, 50V	
C1510	ECJ2VF1E104Z	C 0.1UF, Z, 25V	
C1511	ECJ1VF1H104Z	C 0.1UF, Z, 50V	
C1512	ECJ1VF1H104Z	C 0.1UF, Z, 50V	
C1514	ECJ2VF1E104Z	C 0.1UF, Z, 25V	
C1515	ECEA1CKA100	E 10UF, 16V	
C1516	ECJ2VF1E104Z	C 0.1UF, Z, 25V	
C1519	ECEA1CKA100	E 10UF, 16V	
C1520	ECJ2VB1H103K	C 0.01UF, K, 50V	
C1522	ECJ1VF1E104Z	C 0.1UF, Z, 25V	
C1524	ECJ2VF1E104Z	C 0.1UF, Z, 25V	
C1525	ECJ2VF1E104Z	C 0.1UF, Z, 25V	
C1526	ECJ2VC1H271J	C 270PF, J, 50V	
C1530	ECJ2VF1E104Z	C 0.1UF, Z, 25V	
C1532	ECJ2VF1E104Z	C 0.1UF, Z, 25V	
C1533	ECJ2VB1H103K	C 0.01UF, K, 50V	
C1535	ECJ2VF1E104Z	C 0.1UF, Z, 25V	
C1537	ECJ2VF1E104Z	C 0.1UF, Z, 25V	
C1543	ECJ1VF1H104Z	C 0.1UF, Z, 50V	
C1544	ECJ1VF1H104Z	C 0.1UF, Z, 50V	
C1545	ECEA1AKA221	E 220UF, 10V	
C1546	ECJ1VF1H104Z	C 0.1UF, Z, 50V	
C1547	ECJ1VF1H104Z	C 0.1UF, Z, 50V	
C1549	ECEA1CKA470	E 47UF, 16V	
C1550	ECJ1VF1E104Z	C 0.1UF, Z, 25V	
C1552	ECQB1H104JF	P 0.1UF, 50V	
C1553	ECEA1HKA2R2	E 2.2UF, 50V	
C1554	ECEA1CKA101	E 100UF, 16V	
C1555	ECJ2VB1H103K	C 0.01UF, K, 50V	
C1557	ECA1HM010B	E 1UF, 50V	
C1558	ECEA1HKN010	E 1UF, 50V	
C1559	ECJ1VB1H473K	C 0.047UF, K, 50V	
C1560	ECJ2VF1E104Z	C 0.1UF, Z, 25V	
C1562	ECA1HMR33B	E 0.33UF, 50V	
C1563	ECA1HM220B	E 22UF, 50V	
C1565	ECJ1VF1H104Z	C 0.1UF, Z, 50V	
C1566	ECEA1CN470U	E 47UF, 16V	
C1567	ECA1CM101B	E 100UF, 16V	
C1568	ECA1AM221B	E 220UF, 10V	
C1569	ECA1AM221B	E 220UF, 10V	
C1573	ECJ1VF1H104Z	C 0.1UF, Z, 50V	
C1574	ECJ1VF1H104Z	C 0.1UF, Z, 50V	
C1575	ECJ1VF1H104Z	C 0.1UF, Z, 50V	
C1580	F2A1H100A145	E 10UF, 50V	
C1581	F2A1H100A145	E 10UF, 50V	
C1701	ECUX1H220JCX	C 22PF, J, 50V	
C1702	ECUX1H220JCX	C 22PF, J, 50V	
C1703	ECJ2VF1E104Z	C 0.1UF, Z, 25V	
C1704	ECA1AM221B	E 220UF, 10V	
C1705	ECJ2VB1H222K	C 2200PF, K, 50V	
C1706	ECEA1CKA100	E 10UF, 16V	
C1707	ECJ1VC1H270J	C 27PF, J, 50V	
C1708	ECA1AM221B	E 220UF, 10V	
C1709	ECJ2VB1H103K	C 0.01UF, K, 50V	
C1710	ECJ1VB1H103K	C 0.01UF, K, 50V	
C1711	ECJ1VB1H682K	C 6800PF, K, 50V	
C1713	ECEA1CKA100	E 10UF, 16V	
C1714	ECJ2VF1E104Z	C 0.1UF, Z, 25V	
C1716	ECJ2VF1E104Z	C 0.1UF, Z, 25V	

Ref. No.	Part No.	Part Name & Description	Remarks
C1719	ECJ1VB1H103K	C 0.01UF, K, 50V	
C1720	ECJ1VB1H103K	C 0.01UF, K, 50V	
C1721	ECJ1VB1H103K	C 0.01UF, K, 50V	
C1722	ECJ2VB1H103K	C 0.01UF, K, 50V	
C1723	ECEA1CKA101	E 100UF, 16V	
C1724	ECJ1VB1H222K	C 2200PF, K, 50V	
C1725	ECEA1CKA100	E 10UF, 16V	
C1726	ECJ2VF1E104Z	C 0.1UF, Z, 25V	
C1727	ECEA1CKA470	E 47UF, 16V	
C1728	ECJ2VF1E104Z	C 0.1UF, Z, 25V	
C1731	ECJ2VF1E104Z	C 0.1UF, Z, 25V	
C1732	ECJ2VF1E104Z	C 0.1UF, Z, 25V	
C1733	ECJ2VF1E104Z	C 0.1UF, Z, 25V	
C1734	ECJ1VC1H101J	C 100PF, J, 50V	
C1735	ECJ1VC1H101J	C 100PF, J, 50V	
C1736	ECJ1VC1H101J	C 100PF, J, 50V	
C1737	ECJ1VB1C224K	C 0.22UF, K, 16V	
C1739	ECA1CM101B	E 100UF, 16V	
C1740	ECJ2VF1E104Z	C 0.1UF, Z, 25V	
C1742	ECJ1VB1H472K	C 4700PF, K, 50V	
C1743	ECA1HM3R3B	E 3.3UF, 50V	
C1744	ECJ2VF1E104Z	C 0.1UF, Z, 25V	
C1745	ECJ2VF1E104Z	C 0.1UF, Z, 25V	
C1746	ECJ1VF1E104Z	C 0.1UF, Z, 25V	
C1752	ECJ1VB1H471K	C 470PF, K, 50V	
C1754	ECJ1VC1H221J	C 220PF, J, 50V	
C1755	ECJ1VC1H221J	C 220PF, J, 50V	
C1756	ECJ1VC1H221J	C 220PF, J, 50V	
C1785	ECKR3A151KBP	C 150PF, K, 1KV	
C2001	ECA1CM100B	E 10UF, 16V	
C2002	ECJ2VB1H152K	C 1500PF, K, 50V	
C2003	ECJ2VC1H471J	C 470PF, J, 50V	
C2004	ECJ2VC1H221J	C 220PF, J, 50V	
C2005	ECJ2FB1H104K	C 0.1UF, K, 50V	
C2009	ECJ2VB1H332K	C 3300PF, K, 50V	
C2010	ECJ2VB1H332K	C 3300PF, K, 50V	
C2011	ECJ2VB1H102K	C 1000PF, K, 50V	
C2012	ECA1HM4R7B	E 4.7UF, 50V	
C2013	ECA1HM4R7B	E 4.7UF, 50V	
C2014	ECJ2VC1H471J	C 470PF, J, 50V	
C2015	ECJ2VB1H152K	C 1500PF, K, 50V	
C2016	ECA1HM100B	E 10UF, 50V	
C2017	ECJ2VB1H102K	C 1000PF, K, 50V	
C2018	ECJ2VB1H102K	C 1000PF, K, 50V	
C2021	ECA1HM3R3B	E 3.3UF, 50V	
C2022	ECJ2FB1H104K	C 0.1UF, K, 50V	
C2023	ECJ2VC1H221J	C 220PF, J, 50V	
C2024	ECJ2VC1H221J	C 220PF, J, 50V	
C2025	ECA1CM100B	E 10UF, 16V	
C2026	ECJ2FB1H104K	C 0.1UF, K, 50V	
C2027	ECJ2VC1H221J	C 220PF, J, 50V	
C2028	ECA1CM100B	E 10UF, 16V	
C2029	ECJ2VB1H152K	C 1500PF, K, 50V	
C2030	ECJ2VC1H471J	C 470PF, J, 50V	
C2031	ECJ2VC1H070D	C 7PF, D, 50V	
C2032	ECJ2VC1H470J	C 47PF, J, 50V	
C2033	ECJ2VC1H470J	C 47PF, J, 50V	
C2034	ECJ2VC1H010C	C 1PF, C, 50V	
C2035	ECJ2VC1H010C	C 1PF, C, 50V	
C2041	ECJ2VF1C334Z	C 0.33UF, Z, 16V	
C2042	ECJ2VF1C334Z	C 0.33UF, Z, 16V	
C2043	ECJ2VB1H103K	C 0.01UF, K, 50V	
C2044	F2A1C331A159	E 330UF, 16V	
C2048	ECJ2VF1C334Z	C 0.33UF, Z, 16V	
C2049	ECJ2VF1C334Z	C 0.33UF, Z, 16V	
C2050	ECJ2VF1C334Z	C 0.33UF, Z, 16V	
C2051	ECJ2VF1C334Z	C 0.33UF, Z, 16V	
C2052	ECJ2VC1H221J	C 220PF, J, 50V	
C2053	ECJ2VC1H221J	C 220PF, J, 50V	
C2054	ECJ2VC1H221J	C 220PF, J, 50V	
C2055	ECJ2VC1H221J	C 220PF, J, 50V	
C2056	ECA1CM470B	E 47UF, 16V	
C2057	ECA1CM470B	E 47UF, 16V	

Ref. No.	Part No.	Part Name & Description	Remarks
C2060	ECJ2VF1C334Z	C 0.33UF, Z, 16V	
C2061	ECJ2VF1C334Z	C 0.33UF, Z, 16V	
C2062	ECJ2VC1H221J	C 220PF, J, 50V	
C2063	ECJ2VC1H221J	C 220PF, J, 50V	
C2361	F2A1V1020042	E 1000UF, 35V	
C2362	F2A1V1020042	E 1000UF, 35V	
C2363	ECJ2VC1H102J	C 1000PF, J, 50V	
C2364	ECJ2VC1H102J	C 1000PF, J, 50V	
C251	ECA1HM010B	E 1UF, 50V	
C252	ECA1HM010B	E 1UF, 50V	
C253	ECA1HM4R7B	E 4.7UF, 50V	
C254	ECJ2VB1H102K	C 1000PF, K, 50V	
C255	ECA1HM4R7B	E 4.7UF, 50V	
C256	ECJ2VB1H102K	C 1000PF, K, 50V	
C259	ECQV1H684JM	P 0.68UF, J, 50V	
C260	ECQV1H684JM	P 0.68UF, J, 50V	
C261	ECA1HM100B	E 10UF, 50V	
C262	ECA1HM100B	E 10UF, 50V	
C263	ECA1HM101B	E 100UF, 50V	
C264	ECQV1H154JM	P 0.15UF, J, 50V	
C265	ECQV1H154JM	P 0.15UF, J, 50V	
C266	ECJ2FB1H104K	C 0.1UF, K, 50V	
C267	ECJ2FB1H104K	C 0.1UF, K, 50V	
C269	F2A1V332A206	E 3300UF, 35V	
C270	ECQB1H183JF	P 0.018UF, J, 50V	
C3001	ECJ2VF1H224Z	C 0.22UF, Z, 50V	
C3002	ECJ2VF1H224Z	C 0.22UF, Z, 50V	
C3003	ECJ2VF1H224Z	C 0.22UF, Z, 50V	
C3004	ECJ2VF1H224Z	C 0.22UF, Z, 50V	
C3010	ECJ2VF1H224Z	C 0.22UF, Z, 50V	
C3011	ECJ2VF1H224Z	C 0.22UF, Z, 50V	
C3012	ECJ2VF1H224Z	C 0.22UF, Z, 50V	
C3013	ECA1CM101B	E 100UF, 16V	
C3020	ECEA1HKN010	E 1UF, 50V	
C3021	ECEA1HKN010	E 1UF, 50V	
C3030	ECA1CM100B	E 10UF, 16V	
C3031	ECJ2VF1H104Z	C 0.1UF, Z, 50V	
C3053	ECJ2VF1C474Z	C 0.47UF, Z, 16V	
C3054	ECJ2VF1H104Z	C 0.1UF, Z, 50V	
C3055	ERJ6GEY0R00	M 0OHM, J, 1/10W	
C3056	ECJ2VF1H224Z	C 0.22UF, Z, 50V	
C3057	ECA1CM101B	E 100UF, 16V	
C3060	ERJ6GEY0R00	M 0OHM, J, 1/10W	
C3070	ECA1CM100B	E 10UF, 16V	
C3071	ECJ2VF1H104Z	C 0.1UF, Z, 50V	
C3080	ECJ2VF1C474Z	C 0.47UF, Z, 16V	
C3081	ECJ2VF1H104Z	C 0.1UF, Z, 50V	
C3140	ECJ1VC1H561K	C 560PF, K, 50V	
C3141	ECJ1VC1H561K	C 560PF, K, 50V	
C3180	ECJ1VC1H561K	C 560PF, K, 50V	
C3181	ECJ1VC1H561K	C 560PF, K, 50V	
C3185	ECJ2VC1H561K	C 560PF, K, 50V	
C3186	ECJ2VC1H561K	C 560PF, K, 50V	
C3190	ECJ2VC1H561K	C 560PF, K, 50V	
C3191	ECJ2VC1H561K	C 560PF, K, 50V	
C3201	ECJ2VB1H103K	C 0.01UF, K, 50V	
C3202	ECJ2VB1H103K	C 0.01UF, K, 50V	
C3203	ECJ2VC1H561J	C 560PF, J, 50V	
C3204	ECJ2VC1H561J	C 560PF, J, 50V	
C3210	ECJ2VB1H103K	C 0.01UF, K, 50V	
C3213	ECJ2VC1H561J	C 560PF, J, 50V	
C3214	ECJ2VC1H561J	C 560PF, J, 50V	
C3215	ECA1HM470B	E 47UF, 50V	
C3216	ECA1HM470B	E 47UF, 50V	
C3217	ECJ2VC1H561J	C 560PF, J, 50V	
C3218	ECJ2VC1H561J	C 560PF, J, 50V	
C351	ECJ2VC1H180J	C 18PF, J, 50V	
C352	ECJ2VF1H104Z	C 0.1UF, Z, 50V	
C353	ECUX1H104KBX	C 0.1UF, K, 50V	
C354	ECQE2104KF	P 0.1UF, K, 250V	
C355	F1B2H102A022	C 1000PF, 500V	
C358	ECJ2VF1H104Z	C 0.1UF, Z, 50V	
C360	ECJ2VF1E104Z	C 0.1UF, Z, 25V	

Ref. No.	Part No.	Part Name & Description	Remarks
C361	ECJ2VC1H180J	C 18PF, J, 50V	
C362	ECJ2VF1H104Z	C 0.1UF, Z, 50V	
C363	ECUX1H104KBX	C 0.1UF, K, 50V	
C364	ECQE2104KF	P 0.1UF, K, 250V	
C365	F1B2H102A022	C 1000PF, 500V	
C366	ECA1CM101B	E 100UF, 16V	
C368	F2A1C4710045	E 470UF, 16V	
C371	ECJ2VC1H180J	C 18PF, J, 50V	
C372	ECJ2VF1H104Z	C 0.1UF, Z, 50V	
C373	ECUX1H104KBX	C 0.1UF, K, 50V	
C374	ECQE2104KF	P 0.1UF, K, 250V	
C375	F1B2H102A022	C 1000PF, 500V	
C382	ECA1HM100B	E 10UF, 50V	
C383	F1B1H101A130	C 100PF, 50V	
C385	ECA2EM100B	E 10UF, 250V	
C386	ECKW3D152JBR	C 1500PF, J, 2KV	
C451	ECJ2VB1H102K	C 1000PF, K, 50V	
C453	ECJ2FB1H104K	C 0.1UF, 50V	
C454	ECJ2FB1H104K	C 0.1UF, 50V	
C456	ECA1HM221B	E 220UF, 50V	
C459	ECQB1224KF	P 0.22UF, K, 100V	
C463	ECA1HM221B	E 220UF, 50V	
C4801	ECA1HM4R7B	E 4.7UF, 50V	
C4802	ECA1CM101B	E 100UF, 16V	
C4803	ECQV1H334JM	P 0.33UF, J, 50V	
C4804	ECQV1H334JM	P 0.33UF, J, 50V	
C4805	ECA1VM470B	E 47UF, 35V	
C4806	ECA1HM4R7B	E 4.7UF, 50V	
C4808	ECA1HM330B	E 33UF, 50V	
C507	ECUX1H331KBX	C 330PF, K, 50V	
C508	ECQB1H392JF	P 3900PF, J, 50V	
C509	ECA1VM470B	E 47UF, 35V	
C518	ECKW3D152KBP	C 1500PF, K, 2KV	
C551	ECWH20102JVV	P 1000PF, J, 2KV	
C552	ECWH20102JVV	P 1000PF, J, 2KV	
C557	F1B2H471A025	C 470PF, 500V	
C558	ECA1HHG471	E 470UF, 50V	
C560	ECQE2393KF	P 0.039UF, K, 250V	
C561	ECA1EM222E	E 2200UF, 25V	
C562	F1B2H101A025	C 100PF, 500V	
C563	ECA2EM100B	E 10UF, 250V	
C564	ECEA2CN2R2S	E 2.2UF, 160V	
C565	FOA1H273A039	C 0.027UF, 50V	
C566	F1B2H471A025	C 470PF, 500V	
C567	ECA1EM222E	E 2200UF, 25V	
C568	F1B2H471A025	C 470PF, 500V	
C577	ECA1HM100B	E 10UF, 50V	
C581	ECWF4684JBB	P 0.68UF, J, 400V	
C582	ECWF4684JBB	P 0.68UF, J, 400V	
C583	ECWH20472JVB	P 4700PF, J, 2KV	
C584	ECWH20472JVB	P 4700PF, J, 2KV	
C585	ECQF4123JZ	P 0.012UF, J, 400V	
C586	ECQF4153JZ	P 0.015UF, J, 400V	
C588	ECWF4514JBB	P 0.51UF, J, 400V	
C701	F1B2H152A023	C 1500PF, 500V	
C702	ECQE1335KF	P 3.3UF, K, 100V	
C705	ECQE1685KF	P 6.8UF, K, 100V	
C706	F1B2H471A025	C 470PF, 500V	
C710	ECA1HM101B	E 1UF, 50V	
C801	ECQU2A224BN9	P 0.22UF, 250V	△
C804	ECQU2A224BN9	P 0.22UF, 250V	△
C805	ECKWAE472ZED	C 4700PF, Z, 500V	△
C806	ECKWAE472ZED	C 4700PF, Z, 500V	△
C807	ECKWAE472ZED	C 4700PF, Z, 500V	△
C808	ECKWAE472ZED	C 4700PF, Z, 500V	△
C817	ECA1CM221B	E 220UF, 16V	
C818	F1B1H103A013	C 0.01UF, 50V	
C820	F2B2G5610003	E 560UF, 400V	
C821	ECA1HM101B	E 1UF, 50V	
C822	ECJ2VB1H103K	C 0.01UF, K, 50V	
C823	ECA1HM100B	E 10UF, 50V	
C824	ECJ2VB1H221K	C 220PF, K, 50V	
C825	ECJ2VB1H471K	C 470PF, K, 50V	

Ref. No.	Part No.	Part Name & Description	Remarks
C826	ECKW3D681KBP	C 680PF, K, 2KV	
C827	ECQM4103RJZ	P 0.01UF, 400V	
C828	ECKW3D331JBR	C 330PF, J, 2KV	
C830	ECKCNA152ME7	C 1500PF, M,	
C835	FOA1H183A039	P 0.018UF, 50V	
C836	ECKCNA152ME7	C 1500PF, M,	
C839	ECJ2VF1C105Z	C 1UF, Z, 16V	
C844	ECKCNA471MB7	C 470PF, M,	
C860	ECJ2VF1H103Z	C 0.01UF, Z, 50V	
C861	ECA1HM101B	E 100UF, 50V	
C862	ECA1CM101B	E 100UF, 16V	
C866	ECKW3D471KBP	C 470PF, K, 2KV	
C867	F2B2C2710002	E 270UF, 160V	
C868	F2A2C2210013	E 220UF, 160V	
C870	F2A1C3320025	E 3300UF, 16V	
C871	F1B2H471A025	C 470PF, 500V	
C872	F2A1C682A260	E 6800UF, 16V	
C873	F1B2H471A025	C 470PF, 500V	
C874	F1B2H471A025	C 470PF, 500V	
C875	ECA1HHG102E	E 1000UF, 50V	
C876	ECQV1H104JL	P 0.1UF, J, 50V	
C878	ECA1CM100B	E 10UF, 16V	
C882	ECA1CM100B	E 10UF, 16V	
C883	F2A1E101A134	E 100UF, 25V	
C884	ECA1CM100B	E 10UF, 16V	
C886	ECA1CM100B	E 10UF, 16V	
C888	ECJ2FB1H104K	C 0.1UF, 50V	
C889	ECA1CM101B	E 100UF, 16V	
C891	ECA1CM101B	E 100UF, 16V	
C892	ECJ2FB1H104K	C 0.1UF, 50V	
C893	ECA1CM101B	E 100UF, 16V	
C896	ECJ2FB1H104K	C 0.1UF, 50V	
C901	ECA1CM101B	E 100UF, 16V	
C902	ECJ2VF1H103Z	C 0.01UF, Z, 50V	
C903	ERJ6GEY0R00	M 00HM, J, 1/10W	
C904	ECJ2VB1H472K	C 4700PF, K, 50V	
C905	ECA2CM220B	E 22UF, 160V	
C906	ECA2CM220B	E 22UF, 160V	
C907	ECA2CM220B	E 22UF, 160V	
C908	ECQM4472JZ	P 4700PF, J, 400V	
		DIODES	
D1004	MTZJ8.2C	ZENER DIODE	
D1008	B3AGA0000089	DIODE	
D1009	B0BA5R100013	ZENER DIODE	
D103	MA4056H	DIODE	
D1102	B0ACCK000005	DIODE	
D1104	B0ACCK000005	DIODE	
D1105	B0ACCK000005	DIODE	
D1106	B0ACCK000005	DIODE	
D1107	MAZ80300LL	DIODE	
D1108	MAZ80390HL	DIODE	
D1160	MAZ80560ML	DIODE	
D1501	MAZ80390HL	DIODE	
D1502	MAZ80390HL	DIODE	
D1701	B0ADCU000015	DIODE	
D1702	B0ADCU000015	DIODE	
D1703	B0ACCK000005	DIODE	
D1705	B0AACK000004	DIODE	
D1706	MAZ80390HL	DIODE	
D1707	MAZ80390HL	DIODE	
D1708	MAZ80560HL	DIODE	
D1709	MAZ80620HL	DIODE	
D2005	B0AACK000004	DIODE	
D2006	B0AACK000004	DIODE	
D2008	B0AACK000004	DIODE	
D2009	B0AACK000004	DIODE	
D2010	MTZJ4.7B	ZENER DIODE	
D2011	MTZJ5.6B	ZENER DIODE	
D2021	B0BA8R700009	ZENER DIODE	
D2030	MTZJ5.6B	ZENER DIODE	
D251	MA2C700A0F	DIODE	
D252	MA2C700A0F	DIODE	
D3170	MA3091LTX	ZENER DIODE	

Ref. No.	Part No.	Part Name & Description	Remarks
D3201	MTZJ8.2C	ZENER DIODE	
D3202	MTZJ8.2C	ZENER DIODE	
D3204	B0BC022A0007	DIODE	
D3205	MTZJ8.2C	ZENER DIODE	
D3210	MAZ40910MF	DIODE	
D351	B0ACCK000005	DIODE	
D354	B0ACCK000005	DIODE	
D355	MA723	DIODE	
D361	B0ACCK000005	DIODE	
D371	B0ACCK000005	DIODE	
D454	B0JAME000058	DIODE	
D456	MTZJ5.6B	ZENER DIODE	
D457	B0AACK000004	DIODE	
D458	B0JAME000058	DIODE	
D501	B0AACK000004	DIODE	
D502	EU02	DIODE	
D553	EU02	DIODE	
D554	EU02	DIODE	
D557	B0HAKM000011	DIODE	
D558	B0HAKM000011	DIODE	
D559	B0AACK000004	DIODE	
D560	RH3GLF102	DIODE	
D563	EU02	DIODE	
D565	EU02	DIODE	
D566	EU02	DIODE	
D577	MA171	DIODE	
D578	MA4104J	DIODE	
D580	B0HBRV000001	DIODE	
D706	EU02	DIODE	
D707	EU02	DIODE	
D708	MA165	DIODE	
D710	B0BA01600007	ZENER DIODE	
D712	B0AACK000004	DIODE	
D801	ERZV10D621CS	VARISTOR	△
D802A	B0FBAT000008	DIODE	
D809	AU02A	DIODE	
D811	B2AAFR000002	THYRISTOR	△
D820	MTZJ6.8B	ZENER DIODE	
D821	B0HAJL000001	DIODE	
D822	B0EAKT000018	DIODE	
D823	B0HAJL000001	DIODE	
D824	B0HAJL000001	DIODE	
D825	B0HAJL000001	DIODE	
D826	B0BC022A0007	DIODE	
D829	MAZ20820A0LS	DIODE	
D831	MA4360M	DIODE	
D832	B0HAJL000001	DIODE	
D846	B0HAJL000001	DIODE	
D851	B0AACK000004	DIODE	
D854	MTZJ7.5C	ZENER DIODE	
D855	MA165	DIODE	
D866	FMGG2CSLF665	DIODE	
D868	B0BA5R100013	ZENER DIODE	
D869	MA4030L	DIODE	
D872	B0JAPK000011	DIODE	
D873	B0HARR000008	DIODE	
D877	B0AACK000004	DIODE	
D878	B0AACK000004	DIODE	
D880	B0AACK000004	DIODE	
D881	B0BA01700031	ZENER DIODE	
D882	MTZJ16A	ZENER DIODE	
D883	B0JAPG000029	DIODE	
D889	B0HAJL000001	DIODE	
D890	B0AACK000004	DIODE	
D891	B0AACK000004	DIODE	
D895	MTZJ5.1B	ZENER DIODE	
D896	B0AACK000004	DIODE	
D901	SR2KNLFA1	DIODE	
	INTEDGRATED CIRCUITS		
IC1101	C2BBYC000011	IC	
IC1103	TVR4G8-25	FLASH MEMORY IC	
IC1104	TVR4GAS367	EEPROM IC	

Ref. No.	Part No.	Part Name & Description	Remarks
IC1105	C0EBJ00000288	IC	
IC1106	C0EBE00000388	IC	
IC1108	C0ZBZ00000893	IC	
IC1501	C1AB000002065	IC	
IC1502	C0CBAAG000020	IC, POWER SUPPLY	
IC1505	C1AB000002021	IC	
IC1701	C1AB000001986	IC	
IC2001	C1AB000001987	IC	
IC251	C1BA000000381	IC	
IC3001	C1AB000002370	IC	
IC351	C1AA000000325	IC	
IC361	C1AA000000325	IC	
IC371	C1AA000000325	IC	
IC451	C1AA000000689	IC	
IC4801	PUB4301	TRANSISTOR ARRAY	
IC4802	AN6564NS	LINEAR IC	
IC801	C0EAS00000026	IC	△
IC820	C5HABZZ00120	IC, POWER SUPPLY	
IC852	AN78L05	LINEAR IC	
IC853	C0CBABF000021	IC, POWER SUPPLY	
IC856	C0CACHF000001	IC, POWER SUPPLY	
IC880	C0CACYG000001	IC, POWER SUPPLY	
IC885	B3PAA00000261	PHOTO COUPLER	△
	COILS		
L001	J0JKB00000034	EMI FILTER	
L103	EXCELSA35T	BEAD CORE	
L104	J0JKB00000034	EMI FILTER	
L1061	G0C331KA0073	PEAKING COIL	
L107	G0C100KA0065	PEAKING COIL	
L1101	TALV35VB5R6K	PEAKING COIL	
L1103	TLTACT4R7J	PEAKING COIL	
L1104	TLTACT4R7J	PEAKING COIL	
L116	TALV35VB6R8K	PEAKING COIL	
L1501	TLTACT4R7J	PEAKING COIL	
L1502	TLTACT4R7J	PEAKING COIL	
L1503	G0C100K000008	COIL	
L1701	EXC3BB221H	CHIP BEAD CORE	
L2001	TLTACT4R7J	PEAKING COIL	
L2005	TLTACT4R7J	PEAKING COIL	
L2006	ELJFC4R7KF	CHIP INDUCTOR	
L2007	ELJFC4R7KF	CHIP INDUCTOR	
L2008	EXCELSA35T	BEAD CORE	
L2109	EXCELSA35T	BEAD CORE	
L2111	EXCELSA35T	BEAD CORE	
L2352	J0JKB00000034	EMI FILTER	
L3010	G0C100K000008	COIL	
L3070	G0C100K000008	COIL	
L3140	EXCELD35V	CORE	
L3141	EXCELD35V	CORE	
L3145	G0C100K000008	COIL	
L3180	EXCELD35V	CORE	
L3181	EXCELD35V	CORE	
L3185	EXCELD35V	CORE	
L3186	EXCELD35V	CORE	
L3190	EXCELD35V	CORE	
L3191	EXCELD35V	CORE	
L3201	TALV35VB6R8K	PEAKING COIL	
L3202	TALV35VB6R8K	PEAKING COIL	
L3204	TALV35VB6R8K	PEAKING COIL	
L3205	TALV35VB6R8K	PEAKING COIL	
L3206	EXCELSA35T	BEAD CORE	
L3208	EXCELSA35T	BEAD CORE	
L3250	G0BYYYG000005	BEAD CORE	
L382	J0JKB00000034	EMI FILTER	
L501	EXCELSA35T	BEAD CORE	
L522	J0JKB00000034	EMI FILTER	
L546	G0A4R7H000002	CHOKE COIL	
L559	EXCML20A390U	EMI FILTER	
L582	ELC18E181L	CHOKE COIL	
L584	ELH5L7719	LINEARITY COIL	
L701	G0A221H000003	CHOKE COIL	
L704	ELC18B801E	CHOKE COIL	
L804	ETQR45T001A	CHOKE COIL	



Ref. No.	Part No.	Part Name & Description	Remarks
L810	J0JKB0000034	EMI FILTER	
L838	EXC3BB102H	CHIP BEAD CORE	
L865	EXCELSA35B	BEAD CORE	
L866	EXCELSA35B	BEAD CORE	
L867	TALL08T680KA	INDUCTION COIL	
L871	EXCELSA35T	BEAD CORE	
L872	EXCELSA35T	BEAD CORE	
L874	EXCELSA35T	BEAD CORE	
L901	ERC14GK220	SOLID RESISTOR	△
	TRANSISTORS		
Q1002	2SD0601A0L	TRANSISTOR	
Q1008	2SD0601A0L	TRANSISTOR	
Q101	2SD0601A0L	TRANSISTOR	
Q109	2SD0601A0L	TRANSISTOR	
Q1103	2SD0601A0L	TRANSISTOR	
Q1109	B1CFHG000008	TRANSISTOR	
Q1110	B1CFHG000008	TRANSISTOR	
Q1112	2SD0601A0L	TRANSISTOR	
Q1116	BIADDF000005	TRANSISTOR	
Q1117	2SD0601A0L	TRANSISTOR	
Q120	2SD0601A0L	TRANSISTOR	
Q1501	2SD0601A0L	TRANSISTOR	
Q1508	BIADDF000005	TRANSISTOR	
Q1570	2SD0601A0L	TRANSISTOR	
Q1701	2SD0601A0L	TRANSISTOR	
Q1702	2SD0601A0L	TRANSISTOR	
Q1703	2SD0601A0L	TRANSISTOR	
Q1704	2SD0601A0L	TRANSISTOR	
Q1705	2SD0601A0L	TRANSISTOR	
Q1706	B1HFCFA00006	TRANSISTOR	
Q1707	B1HFCFA00006	TRANSISTOR	
Q1708	B1HFCFA00006	TRANSISTOR	
Q1711	2SD0601A0L	TRANSISTOR	
Q1712	2SD0601AQL	TRANSISTOR	
Q1713	2SD0601A0L	TRANSISTOR	
Q1715	2SD0601A0L	TRANSISTOR	
Q1719	2SD0601AQL	TRANSISTOR	
Q2006	BIADDF000005	TRANSISTOR	
Q251	2SD0601A0L	TRANSISTOR	
Q252	2SD0601A0L	TRANSISTOR	
Q3030	2SD0601A0L	TRANSISTOR	
Q3031	2SD0601A0L	TRANSISTOR	
Q3032	2SD0601A0L	TRANSISTOR	
Q3140	2SD0601A0L	TRANSISTOR	
Q3141	2SD0601A0L	TRANSISTOR	
Q3142	2SD0601A0L	TRANSISTOR	
Q3270	2SD0601A0L	TRANSISTOR	
Q351	BIADDF000005	TRANSISTOR	
Q352	BIADDF000005	TRANSISTOR	
Q503	B1BBDJ000004	TRANSISTOR	
Q551	2SC5686000RK	TRANSISTOR	
Q556	2SD0601A0L	TRANSISTOR	
Q703	B1DFDG000015	TRANSISTOR	
Q706	2SD0601A0L	TRANSISTOR	
Q707	2SA1018Q	TRANSISTOR	
Q850	2SD0601A0L	TRANSISTOR	
Q852	2SD0601A0L	TRANSISTOR	
Q865	B1BCCM000002	TRANSISTOR	
Q866	2SC54190RA	TRANSISTOR	
Q870	2SD0601A0L	TRANSISTOR	
Q871	BIADDF000005	TRANSISTOR	
Q873	2SD0601A0L	TRANSISTOR	
Q874	B1BACG000035	TRANSISTOR	
Q898	2SD0601A0L	TRANSISTOR	
Q901	BIADDF000005	TRANSISTOR	
Q902	2SD0601A0L	TRANSISTOR	
Q903	2SA1535ARLB	TRANSISTOR	
Q904	2SC3944ARLB	TRANSISTOR	
	RESISTORS		
R004	ERJ6ENF2152	M21.5KOHM, 1/10W	
R1007	ERJ6GEYJ103	M 10KOHM, J, 1/10W	
R1008	ERJ6GEYJ271	M 270OHM, J, 1/10W	
R1009	ERJ6GEYJ112	M 1.1KOHM, J, 1/10W	

Ref. No.	Part No.	Part Name & Description	Remarks
R101	ERJ6GEYJ101	M 100OHM, J, 1/10W	
R1010	ERJ6GEYJ472	M 4.7KOHM, J, 1/10W	
R1011	ERJ6GEYJ473	M 47KOHM, J, 1/10W	
R1017	ERJ6GEYJ102	M 1KOHM, J, 1/10W	
R1018	ERJ6GEYJ472	M 4.7KOHM, J, 1/10W	
R102	ERJ6GEYJ101	M 100OHM, J, 1/10W	
R103	ERJ6GEYJ221	M 220OHM, J, 1/10W	
R1043	ERJ6ENF2211	F 2.21KOHM, 1/10W	
R1044	ERJ6ENF3241	M3.24KOHM, 1/10W	
R1045	ERJ6ENF5111	F 5.11KOHM, 1/10W	
R1046	ERJ6ENF9091	M9.09KOHM, 1/10W	
R110	ERJ6GEYJ101	M 100OHM, J, 1/10W	
R1100	ERJ6GEYJ102	M 1KOHM, J, 1/10W	
R1101	ERJ3GEYJ101	M 100OHM, J, 1/16W	
R1102	ERJ3GEYJ103	M 10KOHM, J, 1/16W	
R1103	ERJ6GEYJ101	M 100OHM, J, 1/10W	
R1104	ERJ6GEYJ101	M 100OHM, J, 1/10W	
R1105	ERJ6GEYJ101	M 100OHM, J, 1/10W	
R1106	ERJ6GEYJ101	M 100OHM, J, 1/10W	
R1107	ERJ3GEYJ562	M 5.6KOHM, J, 1/16W	
R1108	ERJ3GEYJ103	M 10KOHM, J, 1/16W	
R1109	ERJ3GEYJ101	M 100OHM, J, 1/16W	
R1111	ERJ3GEYJ101	M 100OHM, J, 1/16W	
R1112	ERJ3GEYJ101	M 100OHM, J, 1/16W	
R1114	ERJ3GEYJ101	M 100OHM, J, 1/16W	
R1116	ERJ3GEYJ101	M 100OHM, J, 1/16W	
R1118	ERJ3GEYJ101	M 100OHM, J, 1/16W	
R112	ERJ6GEYJ101	M 100OHM, J, 1/10W	
R1120	ERJ3GEYJ101	M 100OHM, J, 1/16W	
R1122	ERJ6GEYJ103	M 10KOHM, J, 1/10W	
R1123	ERJ6GEYJ472	M 4.7KOHM, J, 1/10W	
R1124	ERJ6GEYJ332	M 3.3KOHM, J, 1/10W	
R1125	ERJ6GEYJ101	M 100OHM, J, 1/10W	
R1126	ERJ6GEYJ101	M 100OHM, J, 1/10W	
R1127	ERJ3GEYJ101	M 100OHM, J, 1/16W	
R1128	ERJ3GEYJ683	M 68KOHM, J, 1/16W	
R1129	ERJ3GEYJ562	M 5.6KOHM, J, 1/16W	
R113	ERJ6GEYJ223	M 22KOHM, J, 1/10W	
R1132	ERJ6GEYJ103	M 10KOHM, J, 1/10W	
R1133	ERJ3EKF1002	M 10KOHM, F, 1/16W	
R1134	ERJ6GEYJ471	M 470OHM, J, 1/10W	
R1135	ERJ6GEYJ101	M 100OHM, J, 1/10W	
R1136	ERJ6GEYJ103	M 10KOHM, J, 1/10W	
R1137	ERJ3GEYJ822	M 8.2KOHM, J, 1/16W	
R1138	ERJ3GEYJ153	M 15KOHM, J, 1/16W	
R1139	ERJ3GEYJ101	M 100OHM, J, 1/16W	
R114	ERJ6GEYJ471	M 470OHM, J, 1/10W	
R1140	ERJ3GEYJ101	M 100OHM, J, 1/16W	
R1141	ERJ3GEYJ101	M 100OHM, J, 1/16W	
R1142	ERJ3GEYJ101	M 100OHM, J, 1/16W	
R1143	ERJ3GEYJ103	M 10KOHM, J, 1/16W	
R1144	ERJ3GEYJ473	M 47KOHM, J, 1/16W	
R1145	ERJ6GEYJ103	M 10KOHM, J, 1/10W	
R1147	ERJ3GEYJ103	M 10KOHM, J, 1/16W	
R115	ERJ6GEYJ102	M 1KOHM, J, 1/10W	
R1150	ERJ6GEYJ391	M 390OHM, J, 1/10W	
R1151	ERJ3GEYJ683	M 68KOHM, J, 1/16W	
R1152	ERJ6GEYJ332	M 3.3KOHM, J, 1/10W	
R1153	ERJ6GEYJ472	M 4.7KOHM, J, 1/10W	
R1154	ERJ6GEYJ472	M 4.7KOHM, J, 1/10W	
R1155	ERJ3GEYJ101	M 100OHM, J, 1/16W	
R1156	ERJ3GEYJ101	M 100OHM, J, 1/16W	
R1157	ERJ6GEYJ101	M 100OHM, J, 1/10W	
R1158	ERJ6GEYJ101	M 100OHM, J, 1/10W	
R1159	ERJ6GEYJ472	M 4.7KOHM, J, 1/10W	
R116	ERJ6GEYJ101	M 100OHM, J, 1/10W	
R1160	ERJ6GEYJ472	M 4.7KOHM, J, 1/10W	
R1161	ERJ6GEYJ102	M 1KOHM, J, 1/10W	
R1162	ERJ6GEYJ102	M 1KOHM, J, 1/10W	
R1163	ERJ6GEYJ103	M 10KOHM, J, 1/10W	
R1164	ERJ6GEYJ103	M 10KOHM, J, 1/10W	
R1165	ERJ6GEYJ103	M 10KOHM, J, 1/10W	
R1166	ERJ6GEYJ103	M 10KOHM, J, 1/10W	

Ref. No.	Part No.	Part Name & Description	Remarks
R1167	ERJ6GEYJ101	M 100OHM,J,1/10W	
R1168	ERJ6GEYJ101	M 100OHM,J,1/10W	
R1169	ERJ6GEYJ101	M 100OHM,J,1/10W	
R1170	ERJ6GEYJ101	M 100OHM,J,1/10W	
R1171	ERJ6GEYJ101	M 100OHM,J,1/10W	
R1172	ERJ6GEYJ103	M 10KOHM,J,1/10W	
R1173	ERJ6GEYJ103	M 10KOHM,J,1/10W	
R1174	ERJ6GEYJ103	M 10KOHM,J,1/10W	
R1175	ERJ6GEY0R00	M 0OHM,J,1/10W	
R1176	ERJ3GEYJ103	M 10KOHM,J,1/16W	
R1177	ERJ6GEYJ101	M 100OHM,J,1/10W	
R1178	ERJ6GEYJ101	M 100OHM,J,1/10W	
R1179	ERJ6GEYJ103	M 10KOHM,J,1/10W	
R1180	ERJ6GEYJ103	M 10KOHM,J,1/10W	
R1184	ERJ3GEYJ680	M 68OHM,J,1/16W	
R1185	ERJ6GEYJ101	M 100OHM,J,1/10W	
R1186	ERJ6GEYJ103	M 10KOHM,J,1/10W	
R1187	ERJ3GEY0R00	M 0OHM,J,1/16W	
R1188	ERJ3GEYJ101	M 100OHM,J,1/16W	
R1189	ERJ6GEYJ101	M 100OHM,J,1/10W	
R1190	ERJ6GEYJ101	M 100OHM,J,1/10W	
R1191	ERJ6GEYJ223	M 22KOHM,J,1/10W	
R1192	ERJ3GEYJ101	M 100OHM,J,1/16W	
R1193	ERJ6GEYJ472	M 4.7KOHM,J,1/10W	
R1194	ERJ6GEYJ472	M 4.7KOHM,J,1/10W	
R1198	ERJ3GEYJ680	M 68OHM,J,1/16W	
R1199	ERJ3GEYJ101	M 100OHM,J,1/16W	
R120	ERJ6GEYJ561	M 560OHM,J,1/10W	
R1200	ERJ6GEYJ101	M 100OHM,J,1/10W	
R1204	ERJ6GEYJ103	M 10KOHM,J,1/10W	
R1206	ERJ6GEY0R00	M 0OHM,J,1/10W	
R1207	ERJ6GEY0R00	M 0OHM,J,1/10W	
R1209	EXB38V680J	M 68OHM,J,1/16W	
R121	ERJ6GEYJ222	M 2.2KOHM,J,1/10W	
R1210	ERJ6GEY0R00	M 0OHM,J,1/10W	
R1211	D1HG6808A002	FIXED RESISTOR	
R1212	D1HG6808A002	FIXED RESISTOR	
R1213	ERJ6GEYJ680	M 68OHM,J,1/10W	
R1214	EXB38V680J	M 68OHM,J,1/16W	
R1215	ERJ3GEYJ680	M 68OHM,J,1/16W	
R1216	ERJ3GEY0R00	M 0OHM,J,1/16W	
R1217	ERJ3GEY0R00	M 0OHM,J,1/16W	
R1218	ERJ6GEYJ101	M 100OHM,J,1/10W	
R1219	ERJ6GEYJ101	M 100OHM,J,1/10W	
R122	ERJ6GEYJ102	M 1KOHM,J,1/10W	
R1220	ERJ6GEYJ332	M 3.3KOHM,J,1/10W	
R1221	ERJ6GEYJ332	M 3.3KOHM,J,1/10W	
R1222	ERJ6GEY0R00	M 0OHM,J,1/10W	
R1223	ERJ6GEY0R00	M 0OHM,J,1/10W	
R1224	ERJ3GEYJ103	M 10KOHM,J,1/16W	
R1228	ERJ6GEYJ332	M 3.3KOHM,J,1/10W	
R1229	ERJ6GEY0R00	M 0OHM,J,1/10W	
R123	ERJ6GEYJ271	M 270OHM,J,1/10W	
R1230	ERJ3GEY0R00	M 0OHM,J,1/16W	
R1231	ERJ3GEY0R00	M 0OHM,J,1/16W	
R1234	ERJ6GEYJ103	M 10KOHM,J,1/10W	
R1237	ERJ3GEYJ102	M 1KOHM,J,1/16W	
R124	ERJ6GEYJ271	M 270OHM,J,1/10W	
R1240	ERJ6GEYJ222	M 2.2KOHM,J,1/10W	
R125	ERJ6GEY0R00	M 0OHM,J,1/10W	
R1251	ERJ6ENF2321	F 2.32KOHM, 1/10W	
R1280	ERJ6GEY0R00	M 0OHM,J,1/10W	
R129	ERJ6GEYJ101	M 100OHM,J,1/10W	
R133	ERJ6GEYJ222	M 2.2KOHM,J,1/10W	
R134	ERJ6GEYJ101	M 100OHM,J,1/10W	
R135	ERJ6GEYJ101	M 100OHM,J,1/10W	
R136	ERJ6GEY0R00	M 0OHM,J,1/10W	
R141	ERJ6GEYJ102	M 1KOHM,J,1/10W	
R1501	ERJ3GEY0R00	M 0OHM,J,1/16W	
R1503	ERJ3GEYJ152	M 1.5KOHM,J,1/16W	
R1513	ERJ6GEY0R00	M 0OHM,J,1/10W	
R1514	ERJ3GEYJ101	M 100OHM,J,1/16W	
R1515	ERJ3GEY0R00	M 0OHM,J,1/16W	

Ref. No.	Part No.	Part Name & Description	Remarks
R1516	ERJ3GEYJ101	M 100OHM,J,1/16W	
R1519	ERJ6GEYJ101	M 100OHM,J,1/10W	
R1522	ERJ6ENF75R0	M 75OHM, 1/10W	
R1523	ERJ6ENF75R0	M 75OHM, 1/10W	
R1528	ERJ3GEY0R00	M 0OHM,J,1/16W	
R1540	ERJ3GEYJ101	M 100OHM,J,1/16W	
R1548	ERJ6GEY0R00	M 0OHM,J,1/10W	
R1549	ERJ3GEY0R00	M 0OHM,J,1/16W	
R1552	ERJ3GEYJ221	M 220OHM,J,1/16W	
R1554	ERJ6ENF68R0	F 68OHM, 1/10W	
R1555	ERJ6ENF75R0	M 75OHM, 1/10W	
R1556	ERJ6ENF68R0	F 68OHM, 1/10W	
R1562	ERJ3GEYJ221	M 220OHM,J,1/16W	
R1570	ERJ6GEYJ471	M 470OHM,J,1/10W	
R1571	ERJ6GEYJ223	M 22KOHM,J,1/10W	
R1572	ERJ6GEYJ223	M 22KOHM,J,1/10W	
R1573	ERJ6GEYJ181	M 180OHM,J,1/10W	
R1574	ERJ6ENF75R0	M 75OHM, 1/10W	
R1575	ERJ6GEYJ103	M 10KOHM,J,1/10W	
R1594	ERJ3GEYJ103	M 10KOHM,J,1/16W	
R1595	ERJ6GEYJ752	M 7.5KOHM,J,1/10W	
R1596	ERJ6GEYJ361	M 360OHM,J,1/10W	
R1597	ERJ3GEYJ562	M 5.6KOHM,J,1/16W	
R1598	ERJ3GEY0R00	M 0OHM,J,1/16W	
R1599	ERJ6GEY0R00	M 0OHM,J,1/10W	
R1600	ERJ6GEYJ202	M 2KOHM,J,1/10W	
R1601	ERJ6GEYJ103	M 10KOHM,J,1/10W	
R1602	ERJ3GEYJ101	M 100OHM,J,1/16W	
R1603	ERJ3GEYJ101	M 100OHM,J,1/16W	
R1604	ERJ3GEYJ101	M 100OHM,J,1/16W	
R1605	ERJ3GEYJ101	M 100OHM,J,1/16W	
R1606	ERJ3GEYJ103	M 10KOHM,J,1/16W	
R1607	ERJ3GEYJ103	M 10KOHM,J,1/16W	
R1608	ERJ3GEYJ101	M 100OHM,J,1/16W	
R1609	ERJ3GEYJ101	M 100OHM,J,1/16W	
R1610	ERJ6ENF75R0	M 75OHM, 1/10W	
R1701	ERJ6GEY0R00	M 0OHM,J,1/10W	
R1704	ERJ6GEY0R00	M 0OHM,J,1/10W	
R1705	ERJ6GEYJ122	M 1.2KOHM,J,1/10W	
R1706	ERJ6GEYJ272	M 2.7KOHM,J,1/10W	
R1707	ERJ6GEYJ102	M 1KOHM,J,1/10W	
R1708	ERJ3GEYJ473	M 47KOHM,J,1/16W	
R1709	ERJ6GEYJ103	M 10KOHM,J,1/10W	
R1710	ERJ6GEYJ563	M 56KOHM,J,1/10W	
R1712	ERJ6GEYJ102	M 1KOHM,J,1/10W	
R1714	ERJ3GEYJ103	M 10KOHM,J,1/16W	
R1716	ERJ3GEYJ103	M 10KOHM,J,1/16W	
R1717	ERJ3GEYJ271	M 270OHM,J,1/16W	
R1719	ERJ6GEYJ223	M 22KOHM,J,1/10W	
R1720	ERJ3GEYJ822	M 8.2KOHM,J,1/16W	
R1721	ERJ3GEYJ682	M 6.8KOHM,J,1/16W	
R1723	ERJ6GEYJ561	M 560OHM,J,1/10W	
R1724	ERJ3GEYJ103	M 10KOHM,J,1/16W	
R1725	ERJ3GEYJ103	M 10KOHM,J,1/16W	
R1726	ERJ3GEYJ103	M 10KOHM,J,1/16W	
R1727	ERJ3GEYJ101	M 100OHM,J,1/16W	
R1728	ERJ3GEYJ101	M 100OHM,J,1/16W	
R1730	ERJ6GEY0R00	M 0OHM,J,1/10W	
R1732	ERJ3GEYJ331	M 330OHM,J,1/16W	
R1733	ERJ3GEYJ331	M 330OHM,J,1/16W	
R1734	ERJ3GEYJ331	M 330OHM,J,1/16W	
R1736	ERJ6GEYJ102	M 1KOHM,J,1/10W	
R1737	ERJ3GEYJ620	F 62OHM,J, 1/10W	
R1738	ERJ6GEYJ271	M 270OHM,J,1/10W	
R1739	ERJ6GEYJ102	M 1KOHM,J,1/10W	
R1740	ERJ3GEYJ620	F 62OHM,J, 1/10W	
R1741	ERJ6GEYJ271	M 270OHM,J,1/10W	
R1742	ERJ6GEYJ102	M 1KOHM,J,1/10W	
R1743	ERJ3GEYJ620	F 62OHM,J, 1/10W	
R1744	ERJ6GEYJ271	M 270OHM,J,1/10W	
R1745	ERJ3GEYJ103	M 10KOHM,J,1/16W	
R1746	ERJ3GEYJ472	M 4.7KOHM,J,1/16W	
R1750	ERJ3GEYJ152	M 1.5KOHM,J,1/16W	

Ref. No.	Part No.	Part Name & Description	Remarks
R1751	ERJ3GEYJ244	F 240KOHM,J, 1/16W	
R1752	ERJ3GEYJ560	M 560OHM,J,1/16W	
R1755	ERJ3GEYJ471	M 470OHM,J,1/16W	
R1756	ERJ3GEY0R00	M 00HM,J,1/16W	
R1757	ERJ6GEYJ821	M 820OHM,J,1/10W	
R1759	ERJ6GEYJ101	M 100OHM,J,1/10W	
R1760	ERJ3GEY0R00	M 00HM,J,1/16W	
R1762	ERJ3GEYJ101	M 100OHM,J,1/16W	
R1763	ERJ3GEYJ103	M 10KOHM,J,1/16W	
R1764	ERJ3GEYJ103	M 10KOHM,J,1/16W	
R1780	ERJ3GEYJ331	M 330OHM,J,1/16W	
R1781	ERJ6GEYJ101	M 100OHM,J,1/10W	
R1782	ERJ3GEYJ102	M 1KOHM,J,1/16W	
R1783	ERJ3GEYJ271	M 270OHM,J,1/16W	
R1784	ERJ3GEYJ472	M 4.7KOHM,J,1/16W	
R1788	ERJ3GEYJ122	M 1.2KOHM,J,1/16W	
R2007	ERJ6GEY0R00	M 00HM,J,1/10W	
R2008	ERJ6GEY0R00	M 00HM,J,1/10W	
R2011	ERJ6GEYJ183	M 18KOHM,J,1/10W	
R2012	ERJ6GEYJ101	M 100OHM,J,1/10W	
R2013	ERJ6GEYJ101	M 100OHM,J,1/10W	
R2015	ERJ6GEYJ101	M 100OHM,J,1/10W	
R2016	ERJ6GEYJ101	M 100OHM,J,1/10W	
R2018	ERDS2TJ101	C 100OHM,J, 1/4W	
R2019	ERJ6GEYJ222	M 2.2KOHM,J,1/10W	
R2020	ERJ6GEYJ101	M 100OHM,J,1/10W	
R2021	ERJ6GEYJ562	M 5.6KOHM,J,1/10W	
R2024	ERJ6GEY0R00	M 00HM,J,1/10W	
R2029	ERJ6GEYJ101	M 100OHM,J,1/10W	
R2032	ERJ6GEYJ101	M 100OHM,J,1/10W	
R2037	ERJ6GEYJ102	M 1KOHM,J,1/10W	
R2038	ERJ6GEYJ562	M 5.6KOHM,J,1/10W	
R2039	ERJ6GEYJ221	M 220OHM,J,1/10W	
R2040	ERJ6GEYJ222	M 2.2KOHM,J,1/10W	
R2041	ERJ6GEY0R00	M 00HM,J,1/10W	
R2042	ERJ6GEY0R00	M 00HM,J,1/10W	
R2043	ERJ6GEY0R00	M 00HM,J,1/10W	
R250	ERJ6GEYJ103	M 10KOHM,J,1/10W	
R251	ERJ6GEYJ471	M 470OHM,J,1/10W	
R252	ERJ6GEYJ103	M 10KOHM,J,1/10W	
R253	ERJ6GEYJ471	M 470OHM,J,1/10W	
R254	ERJ6GEYJ103	M 10KOHM,J,1/10W	
R255	ERJ6GEYJ104	M 100KOHM,J,1/10W	
R256	ERJ6GEYJ104	M 100KOHM,J,1/10W	
R257	ERJ6GEYJ150	M 15OHM,J,1/10W	
R258	ERJ6GEYJ150	M 15OHM,J,1/10W	
R259	ERJ6GEYJ121	M 120OHM,J,1/10W	
R260	ERJ6GEYJ121	M 120OHM,J,1/10W	
R261	ERJ6GEYJ152	M 1.5KOHM,J,1/10W	
R262	ERJ6GEYJ152	M 1.5KOHM,J,1/10W	
R263	ERDS2TJ2R2	C 2.2OHM,J, 1/4W	
R264	ERDS2TJ2R2	C 2.2OHM,J, 1/4W	
R269	ERJ6GEY0R00	M 00HM,J,1/10W	
R273	ERJ6GEY0R00	M 00HM,J,1/10W	
R3001	ERJ6GEY0R00	M 00HM,J,1/10W	
R3003	ERJ6GEY0R00	M 00HM,J,1/10W	
R3004	ERJ6GEYJ101	M 100OHM,J,1/10W	
R3005	ERJ6GEY0R00	M 00HM,J,1/10W	
R3006	ERJ6ENF75R0	M 75OHM, 1/10W	
R3007	ERJ3GEYJ104	M 100KOHM,J,1/16W	
R3008	ERJ3GEYJ104	M 100KOHM,J,1/16W	
R3010	ERJ6GEYJ101	M 100OHM,J,1/10W	
R3011	ERJ6GEY0R00	M 00HM,J,1/10W	
R3012	ERJ6ENF75R0	M 75OHM, 1/10W	
R3015	ERJ6GEY0R00	M 00HM,J,1/10W	
R3016	ERJ6ENF75R0	M 75OHM, 1/10W	
R3017	ERJ3GEYJ104	M 100KOHM,J,1/16W	
R3018	ERJ3GEYJ104	M 100KOHM,J,1/16W	
R3020	ERJ6GEY0R00	M 00HM,J,1/10W	
R3022	ERJ6GEY0R00	M 00HM,J,1/10W	
R3023	ERJ6ENF75R0	M 75OHM, 1/10W	
R3024	ERJ6GEY0R00	M 00HM,J,1/10W	
R3025	ERJ6GEY0R00	M 00HM,J,1/10W	

Ref. No.	Part No.	Part Name & Description	Remarks
R3027	ERJ6GEY0R00	M 00HM,J,1/10W	
R3030	ERJ6GEYJ103	M 10KOHM,J,1/10W	
R3031	ERJ6GEYJ103	M 10KOHM,J,1/10W	
R3032	ERJ6GEYJ102	M 1KOHM,J,1/10W	
R3033	ERJ6GEYJ102	M 1KOHM,J,1/10W	
R3034	ERJ6ENF75R0	M 75OHM, 1/10W	
R3035	ERJ6ENF75R0	M 75OHM, 1/10W	
R3044	ERJ6GEY0R00	M 00HM,J,1/10W	
R3045	ERJ6GEY0R00	M 00HM,J,1/10W	
R3046	ERJ6GEY0R00	M 00HM,J,1/10W	
R3058	ERJ6GEYJ103	M 10KOHM,J,1/10W	
R3059	ERJ6GEYJ102	M 1KOHM,J,1/10W	
R3062	ERJ6GEY0R00	M 00HM,J,1/10W	
R3063	ERJ6GEYJ750	M 75OHM, 1/10W	
R3067	ERJ6GEY0R00	M 00HM,J,1/10W	
R3070	ERJ6GEY0R00	M 00HM,J,1/10W	
R3071	ERJ6GEY0R00	M 00HM,J,1/10W	
R3075	ERJ6GEY0R00	M 00HM,J,1/10W	
R3076	ERJ6GEY0R00	M 00HM,J,1/10W	
R3077	ERJ6GEY0R00	M 00HM,J,1/10W	
R3078	ERJ6GEY0R00	M 00HM,J,1/10W	
R3081	ERJ6GEY0R00	M 00HM,J,1/10W	
R3082	ERJ6ENF75R0	M 75OHM, 1/10W	
R3093	ERJ6GEY0R00	M 00HM,J,1/10W	
R3094	ERJ6GEY0R00	M 00HM,J,1/10W	
R3095	ERJ6GEY0R00	M 00HM,J,1/10W	
R3096	ERJ6GEY0R00	M 00HM,J,1/10W	
R3097	ERJ6GEY0R00	M 00HM,J,1/10W	
R3098	ERJ3GEY0R00	M 00HM,J,1/16W	
R3121	ERJ6GEY0R00	M 00HM,J,1/10W	
R3124	ERJ6GEY0R00	M 00HM,J,1/10W	
R3126	ERJ6GEY0R00	M 00HM,J,1/10W	
R3132	ERJ6GEY0R00	M 00HM,J,1/10W	
R3135	ERJ3GEY0R00	M 00HM,J,1/16W	
R3136	ERJ6GEY0R00	M 00HM,J,1/10W	
R3139	ERJ6GEY0R00	M 00HM,J,1/10W	
R3142	ERJ3GEYJ101	M 100OHM,J,1/16W	
R3143	ERJ3GEYJ101	M 100OHM,J,1/16W	
R3144	ERJ6GEYJ104	M 100KOHM,J,1/10W	
R3145	ERJ6GEYJ104	M 100KOHM,J,1/10W	
R3146	ERJ3GEYJ103	M 10KOHM,J,1/16W	
R3147	ERJ3GEYJ103	M 10KOHM,J,1/16W	
R3148	ERJ3GEYJ223	M 22KOHM,J,1/16W	
R3149	ERJ3GEYJ103	M 10KOHM,J,1/16W	
R3150	ERJ3GEY0R00	M 00HM,J,1/16W	
R3151	ERJ3GEY0R00	M 00HM,J,1/16W	
R3152	ERJ3GEY0R00	M 00HM,J,1/16W	
R3153	ERJ6GEY0R00	M 00HM,J,1/10W	
R3154	ERJ6GEY0R00	M 00HM,J,1/10W	
R3157	ERJ6ENF75R0	M 75OHM, 1/10W	
R3158	ERJ6ENF75R0	M 75OHM, 1/10W	
R3159	ERJ6ENF75R0	M 75OHM, 1/10W	
R3160	ERJ6GEY0R00	M 00HM,J,1/10W	
R3161	ERJ6GEY0R00	M 00HM,J,1/10W	
R3162	ERJ6GEY0R00	M 00HM,J,1/10W	
R3165	ERJ3GEY0R00	M 00HM,J,1/16W	
R3166	ERJ3GEY0R00	M 00HM,J,1/16W	
R3167	ERJ6ENF75R0	M 75OHM, 1/10W	
R3168	ERJ6GEYJ750	M 75OHM, 1/10W	
R3169	ERJ6GEYJ750	M 75OHM, 1/10W	
R3170	ERJ6GEYJ102	M 1KOHM,J,1/10W	
R3171	ERJ6GEY0R00	M 00HM,J,1/10W	
R3175	ERJ6GEY0R00	M 00HM,J,1/10W	
R3176	ERJ6GEY0R00	M 00HM,J,1/10W	
R3180	ERJ3GEYJ102	M 1KOHM,J,1/16W	
R3181	ERJ3GEYJ102	M 1KOHM,J,1/16W	
R3182	ERJ3GEYJ184	M 180KOHM,J,1/16W	
R3183	ERJ3GEYJ184	M 180KOHM,J,1/16W	
R3184	ERJ3GEYJ101	M 100OHM,J,1/16W	
R3185	ERJ3GEYJ101	M 100OHM,J,1/16W	
R3186	ERJ6GEYJ102	M 1KOHM,J,1/10W	
R3187	ERJ6GEYJ102	M 1KOHM,J,1/10W	
R3188	ERJ6GEYJ184	M 180KOHM,J,1/10W	

Ref. No.	Part No.	Part Name & Description	Remarks
R3189	ERJ6GEYJ184	M 180KOHM,J,1/10W	
R3190	ERJ6GEYJ101	M 100OHM,J,1/10W	
R3191	ERJ6GEYJ101	M 100OHM,J,1/10W	
R3192	ERJ6GEYJ102	M 1KOHM,J,1/10W	
R3193	ERJ6GEYJ102	M 1KOHM,J,1/10W	
R3194	ERJ6GEYJ184	M 180KOHM,J,1/10W	
R3195	ERJ6GEYJ184	M 180KOHM,J,1/10W	
R3196	ERJ6GEYJ101	M 100OHM,J,1/10W	
R3197	ERJ6GEYJ101	M 100OHM,J,1/10W	
R3198	ERJ6ENF75R0	M 75OHM, 1/10W	
R3201	ERJ6GEYJ103	M 10KOHM,J,1/10W	
R3202	ERJ6GEYJ103	M 10KOHM,J,1/10W	
R3203	ERG2FJ151H	M 150OHM, J, 2W	
R3205	ERDS1TJ151	C 150OHM,J, 1/2W	
R3208	ERG2FJ151H	M 150OHM, J, 2W	
R3212	ERJ6GEYJ101	M 100OHM,J,1/10W	
R3213	ERJ6GEYJ101	M 100OHM,J,1/10W	
R3214	ERJ6GEYJ153	M 15KOHM,J,1/10W	
R3215	ERJ6GEYJ153	M 15KOHM,J,1/10W	
R3216	ERJ6GEYJ102	M 1KOHM,J,1/10W	
R3217	ERDS1TJ151	C 150OHM,J, 1/2W	
R3255	ERJ3GEY0R00	M 0OHM,J,1/16W	
R3256	ERJ3GEY0R00	M 0OHM,J,1/16W	
R3257	ERJ6GEY0R00	M 0OHM,J,1/10W	
R3258	ERJ6GEY0R00	M 0OHM,J,1/10W	
R3259	ERJ6GEY0R00	M 0OHM,J,1/10W	
R3260	ERJ6GEY0R00	M 0OHM,J,1/10W	
R3261	ERJ6GEY0R00	M 0OHM,J,1/10W	
R3262	ERJ6GEY0R00	M 0OHM,J,1/10W	
R3263	ERJ6GEY0R00	M 0OHM,J,1/10W	
R3270	ERJ6GEYJ102	M 1KOHM,J,1/10W	
R3271	ERJ6GEYJ750	M 75OHM, 1/10W	
R3272	ERJ6GEYJ241	M 240OHM,J,1/10W	
R350	ERQ12AJ151P	F 150OHM,J, 1/2W	
R351	ERJ6GEYJ101	M 100OHM,J,1/10W	
R352	ERJ6GEYJ132	M 1.3KOHM,J,1/10W	
R353	ERJ6GEYJ821	M 820OHM,J,1/10W	
R354	ERJ6GEYJ102	M 1KOHM,J,1/10W	
R355	ERGLSJ683P	M 68KOHM,J,1W	
R356	ERJ6GEY0R00	M 0OHM,J,1/10W	
R357	ERJ6GEYJ221	M 220OHM,J,1/10W	
R358	ERDS1TJ821	C 820OHM,J, 1/2W	
R359	ERJ6GEYJ391	M 390OHM,J,1/10W	
R360	ERJ6GEYJ102	M 1KOHM,J,1/10W	
R362	ERJ6GEYJ132	M 1.3KOHM,J,1/10W	
R363	ERJ6GEYJ821	M 820OHM,J,1/10W	
R364	ERJ6GEYJ102	M 1KOHM,J,1/10W	
R365	ERGLSJ683P	M 68KOHM,J,1W	
R366	ERJ6GEY0R00	M 0OHM,J,1/10W	
R367	ERJ6GEY0R00	M 0OHM,J,1/10W	
R368	ERDS1TJ821	C 820OHM,J, 1/2W	
R369	ERJ6GEY0R00	M 0OHM,J,1/10W	
R370	ERQ1CJP3R9S	F 3.9OHM,J, 1W	
R371	ERJ6GEY0R00	M 0OHM,J,1/10W	
R372	ERJ6GEYJ132	M 1.3KOHM,J,1/10W	
R373	ERJ6GEYJ821	M 820OHM,J,1/10W	
R375	ERGLSJ683P	M 68KOHM,J,1W	
R376	ERJ6GEY0R00	M 0OHM,J,1/10W	
R378	ERDS1TJ821	C 820OHM,J, 1/2W	
R380	ERJ6GEYJ392	M 3.9KOHM,J,1/10W	
R381	ERJ6ENF1401	M 1.4KOHM, 1/10W	
R451	ERJ6GEYJ223	M 22KOHM,J,1/10W	
R453	ERDS2T0T	C 0OHM, 1/4W	
R454	ERJ6GEYJ273	M 27KOHM,J,1/10W	
R455	ERDS2TJ223	C 22KOHM,J, 1/4W	
R458	ERDS1TJ1R0	C 10HM,J, 1/2W	
R460	ERG3FJ121H	M 120OHM,J, 3W	
R461	ERX2SJSR82H	M 0.82OHM,J, 1/2W	
R463	ERJ6GEYJ821	M 820OHM,J,1/10W	
R464	ERJ6GEYJ512	M 5.1KOHM,J,1/10W	
R465	ERJ6GEYJ751	M 750OHM,J,1/10W	
R467	ERJ6GEY0R00	M 0OHM,J,1/10W	
R4803	ERX12SJ2R7E	M 2.7OHM,J, 1/2W	

Ref. No.	Part No.	Part Name & Description	Remarks
R4804	ERJ6GEYJ272	M 2.7KOHM,J,1/10W	
R4805	ERJ6ENF1331	M1.33KOHM, 1/10W	
R4806	ERJ6ENF3320	M 332OHM, 1/10W	
R4807	ERJ6ENF1001	M 1KOHM, 1/10W	
R4808	ERJ6ENF3832	M38.3KOHM, 1/10W	
R4809	ERJ6ENF9091	M9.09KOHM, 1/10W	
R4810	ERJ6ENF2213	M 221KOHM, 1/10W	
R4811	ERJ6ENF6201	M 6.2KOHM, 1/10W	
R4812	ER0S2CKF5621	M5.62KOHM,F, 1/4W	
R4816	ERDS1FJ390	C 39OHM,J, 1/2W	
R503	ERJ6GEYJ103	M 10KOHM,J,1/10W	
R507	ERG3FJ121H	M 120OHM,J,3W	
R509	ERG2FJ222H	M 2.2KOHM,J, 2W	
R510	ERG2FJ222H	M 2.2KOHM,J, 2W	
R545	ERQ2CJP151S	F 150OHM,J, 2W	
R552	ERDS1TJ124	C 120KOHM,J, 1/2W	
R553	ERX2FZJR18H	M 0.18OHM,J, 2W	
R557	ERJ6GEYJ101	M 100OHM,J,1/10W	
R558	ERDS1TJ124	C 120KOHM,J, 1/2W	
R567	ERG3FJ121H	M 120OHM,J,3W	
R568	ERDS1TJ120	C 12OHM,J, 1/2W	
R576	ERQ12HKR39P	F 0.39OHM,J, 1/2W	
R577	ERQ14AJ100E	F 10OHM,J, 1/4W	
R578	ERJ6ENF1152	M11.5KOHM, 1/10W	
R579	ERJ6ENF8661	F 8.66KOHM,J, 1/10W	
R580	ERJ6GEYJ392	M 3.9KOHM,J,1/10W	
R701	ERJ6GEYJ101	M 100OHM,J,1/10W	
R702	ERX3SJS2R7H	M 2.7OHM,J, 3W	
R703	D0DK3R3J0002	W 3.3OHM,J, 10W	
R704	ERDS2TJ472	C 4.7KOHM,J, 1/4W	
R710	ERJ6GEY0R00	M 0OHM,J,1/10W	
R711	ERDS1TJ104	C 100KOHM,J, 1/2W	
R715	ERG2SJ272E	M 2.7KOHM,J,1/2W	
R716	ERQ12AJ680P	F 68OHM, 1/2W	
R717	ERJ6GEYJ272	M 2.7KOHM,J,1/10W	
R719	ERJ6GEYJ102	M 1KOHM,J,1/10W	
R720	ERJ6GEYJ302	M 3KOHM,J,1/10W	
R727	ERJ6GEYJ513	M 51KOHM,J,1/10W	
R728	ERJ6GEYJ103	M 10KOHM,J,1/10W	
R729	D0D7101JA005	W 100OHM,K, 7W	
R801	ERC12ZGK825C	S 8.2,OHM, 1/2W	△
R802	D0D72R7KA002	W 2.7OHM,K, 7W	
R805	ERG2FJ104H	M 100KOHM,J, 2W	
R806	ERDS2TJ681	C 680OHM,J, 1/4W	
R807	ERDS1TJ682	C 6.8KOHM,J, 1/2W	
R809	ERJ6GEYJ153	M 15KOHM,J,1/10W	
R820	D0D2R15KA003	W 0.15OHM,K, 2W	
R821	D0D2R12KA003	W 0.12OHM,K, 2W	
R822	ERDS2TJ473	C 47KOHM,J, 1/4W	
R823	ERDS1TJ221	C 220OHM,J, 1/2W	
R824	ERDS2TJ183	C 18KOHM,J, 1/4W	
R825	ERDS1TJ102	C 1KOHM,J, 1/2W	
R827	ERDS1TJ182	C 1.8OHM,J, 1/2W	
R828	ERDS1TJ330	C 33OHM,J, 1/2W	
R829	ERG2FJ470H	M 47OHM,J, 2W	
R830	ERDS1TJ684	C 680KOHM,J, 1/2W	
R831	ERD75TAJ825	C 8.2MOHM,J, 3/4W	
R838	ERJ6GEYJ683	M 68KOHM,J,1/10W	
R840	ERJ6GEYJ122	M 1.2KOHM,J,1/10W	
R842	ERDS1TJ330	C 33OHM,J, 1/2W	
R845	ERJ6GEYJ103	M 10KOHM,J,1/10W	
R846	ERQ1ABJ6R8E	F 6.8OHM,J,1W	
R847	ERJ6ENF3012	F 30.1KOHM,J,1W	
R848	ERJ6ENF1873	F 187KOHM,J,1W	
R854	ERJ6GEYJ103	M 10KOHM,J,1/10W	
R858	ERJ6GEYJ680	M 68OHM,J,1/10W	
R861	ERDS2TJ223	C 22KOHM,J, 1/4W	
R862	ERDS2TJ182	C 1.8KOHM,J, 1/4W	
R863	ERDS2TJ101	C 100OHM,J, 1/4W	
R864	ERDS2TJ472	C 4.7KOHM,J, 1/4W	
R865	ERG3FJ470H	M 47OHM,J, 3W	
R867	ERJ6GEYJ682	M 6.8KOHM,J,1/10W	
R868	ERDS2TJ271	C 270OHM,J, 1/4W	

Ref. No.	Part No.	Part Name & Description	Remarks
R869	ERJ6GEYJ152	M 1.5KOHM,J,1/10W	
R871	ERJ6GEY0R00	M 0OHM,J,1/10W	
R882	ERJ6GEYJ153	M 15KOHM,J,1/10W	
R883	ERJ6GEYJ473	M 47KOHM,J,1/10W	
R884	ERJ6GEYJ753	M 75KOHM,J,1/10W	
R885	ERJ6GEYJ752	M 7.5KOHM,J,1/10W	
R886	ERJ6GEYJ752	M 7.5KOHM,J,1/10W	
R887	ERG3FJ183	M 18KOHM,J,3W	
R889	ERJ6GEYJ752	M 7.5KOHM,J,1/10W	
R892	ERDS2TJ391	C 390OHM,J, 1/4W	
R893	ERJ6GEYJ123	M 12KOHM,J,1/10W	
R894	ERQ14AJ2R2E	F 2.2OHM,J,1/4W	
R896	ERJ6GEYJ122	M 1.2KOHM,J,1/10W	
R899	ERX2FJ3R9H	M 3.9OHM,J, 2W	
R901	ERJ6GEYJ471	M 470OHM,J,1/10W	
R902	ERDS2TJ122	C 1.2KOHM,J, 1/4W	
R903	ERDS2TJ100	C 10OHM,J, 1/4W	
R904	ERG5FJ102H	M 1KOHM,J,5W	
R905	ERJ6GEYJ471	M 470OHM,J,1/10W	
R906	ERDS2TJ122	C 1.2KOHM,J, 1/4W	
R907	ERDS2TJ124	C 120KOHM,J, 1/4W	
R908	ERDS2TJ124	C 120KOHM,J, 1/4W	
R909	ERDS2TJ100	C 10OHM,J, 1/4W	
R910	ERG2SJ181E	M 180OHM,J, 2W	
R914	ERJ6GEYJ331	M 330OHM,J,1/10W	
	TRANSFORMERS		
T501	ETH19Y212AZ	H DRIVE TRANS	△
T551	ZTFN35009A	FLYBACK TRANS	△
T849	G4D4Z0000002	SWITCHING TRANS	△
	OTHERS		
A2	K1KA08BA0055	CONNECTOR	
A50	K1KA07AA0093	CONNECTOR	
A9	K1KA02AA0180	CONNECTOR	
CF805	D4DDD1200001	POSISTOR	△
CF806	D4DDD1200001	POSISTOR	△
D6	TJSF19916	16P CONNECTOR	
D7	TJSF19916	16P CONNECTOR	
D12	K1KA07AA0190	CONNECTOR	
D16	K1KA03AA0190	CONNECTOR	
D17	K1KA05A00370	CONNECTOR	
F801	K5D502BK0003	FUSE	△
FL1510	ELKE103FA	NOISE FILTER	
FL1511	ELKE103FA	NOISE FILTER	
FL1512	ELKE103FA	NOISE FILTER	
FL1513	ELKE103FA	NOISE FILTER	
FL1705	ELKE103FA	NOISE FILTER	
FL1706	ELKE103FA	NOISE FILTER	
FL1713	JOHAAB000012	EMI FILTER	
G6	K1KB16AA0064	CONNECTOR	
G7	K1KB16AA0064	CONNECTOR	
G14	K1KA04AA0190	CONNECTOR	
G16	K1KB05AA0081	CONNECTOR	
JA1	ERJ6GEY0R00	M 0OHM,J,1/10W	
JA1	ERJ6GEY0R00	M 0OHM,J,1/10W	
JA1	ERJ6GEY0R00	M 0OHM,J,1/10W	
JA10	ERJ6GEY0R00	M 0OHM,J,1/10W	
JA11	ERJ6GEY0R00	M 0OHM,J,1/10W	
JA12	ERJ6GEY0R00	M 0OHM,J,1/10W	
JA15	ERJ6GEY0R00	M 0OHM,J,1/10W	
JA16	ERJ6GEY0R00	M 0OHM,J,1/10W	
JA17	ERJ6GEY0R00	M 0OHM,J,1/10W	
JA19	ERJ6GEY0R00	M 0OHM,J,1/10W	
JA2	ERJ6GEY0R00	M 0OHM,J,1/10W	
JA2	ERJ6GEY0R00	M 0OHM,J,1/10W	
JA20	ERJ6GEY0R00	M 0OHM,J,1/10W	
JA21	ERJ6GEY0R00	M 0OHM,J,1/10W	
JA22	ERJ6GEY0R00	M 0OHM,J,1/10W	
JA23	ERJ6GEY0R00	M 0OHM,J,1/10W	
JA24	ERJ6GEY0R00	M 0OHM,J,1/10W	
JA3	ERJ6GEY0R00	M 0OHM,J,1/10W	
JA4	ERJ6GEY0R00	M 0OHM,J,1/10W	
JA5	ERJ6GEY0R00	M 0OHM,J,1/10W	
JA5	ERJ6GEY0R00	M 0OHM,J,1/10W	

Ref. No.	Part No.	Part Name & Description	Remarks
JA6	ERJ6GEY0R00	M 0OHM,J,1/10W	
JA6	ERJ6GEY0R00	M 0OHM,J,1/10W	
JA7	ERJ6GEY0R00	M 0OHM,J,1/10W	
JA7	ERJ6GEY0R00	M 0OHM,J,1/10W	
JA8	ERJ6GEY0R00	M 0OHM,J,1/10W	
JK3001	K4BK35A00001	AV TERMINAL	
JK3201	K4BK09B00004	AV TERMINAL	
JS201	ERJ6GEY0R00	M 0OHM,J,1/10W	
JS3135	ERJ3GEY0R00	M 0OHM,J,1/16W	
JS3136	ERJ3GEY0R00	M 0OHM,J,1/16W	
JS3142	ERJ3GEY0R00	M 0OHM,J,1/16W	
JS3143	ERJ3GEY0R00	M 0OHM,J,1/16W	
JS4805	ERJ6GEY0R00	M 0OHM,J,1/10W	
JS4815	ERJ6GEY0R00	M 0OHM,J,1/10W	
JS868	ERJ6GEY0R00	M 0OHM,J,1/10W	
JS891	ERJ6GEY0R00	M 0OHM,J,1/10W	
JSD025	ERJ6GEY0R00	M 0OHM,J,1/10W	
JSD026	ERJ6GEY0R00	M 0OHM,J,1/10W	
JSD091	EXCELSA39V	BEAD CORE	
L2	K1KA08AA0190	CONNECTOR	
L3	K1KA07AA0190	CONNECTOR	
L8	K1ZZ00001301	CONNECTOR	
L11	K1KA03AA0190	CONNECTOR	
L12	K1ZZ00001300	CONNECTOR	
LF801	TLP4GD020	LINE FILTER	△
LF802	TLP4GD020	LINE FILTER	△
LF803	TLP4GD016P	LINE FILTER	△
RL801	K6B1CDA00027	RELAY	△
RM1001	B3RAC0000013	REMOCON RECEIVER	
RT1	K1KA03AA0190	CONNECTOR	
SC381	K3B122A00001	CRT SOCKET	△
SW1003	EVQ11G05R	SWITCH	
SW1004	EVQ11G05R	SWITCH	
SW1005	EVQ11G05R	SWITCH	
SW1006	EVQ11G05R	SWITCH	
SW1007	EVQ11G05R	SWITCH	
SW1008	EVQ11G05R	SWITCH	
SW801	ESB92DA1B	SWITCH	△
TU101	ENG39A02GF	TUNER	△
X1101	H1A6004A0001	CRYSTAL OSC	
X1501	H1A2025A0001	CRYSTAL OSC	
X1502	H2A503300008	CERAMIC RESONATOR	
X1701	H1A5004A0001	CRYSTAL OSC	
X2001	H1A1845A0003	CRYSTAL OSC	